



5 (Cont.) Use the Intel® RAID BIOS Console to Create a RAID Volume


10. Click **Accept**.



11. Click **Yes**.



12. Click **Yes**, then **Exit**.



Creation of a RAID Volume is now complete.

6 Install the Server Operating System

Microsoft Windows* Server 2003/
Microsoft* Windows* 2000
Advanced Server Installation*

Step A: Install Microsoft* Windows* Server 2003 or Microsoft* Windows* 2000 Advanced Server

IMPORTANT: When the blue setup screen first appears, press **<F6>**.

1. Boot the system with the Windows* Server 2003 or Windows* 2000 Advanced Server CD-ROM.
2. Press **<F6>** as soon as the first blue screen appears to bypass mass storage detection.
3. When prompted to specify a mass storage controller:

- Select **"S"** to specify additional storage devices.

- Insert Microsoft* Windows* Server 2003 or Microsoft* Windows* 2000 Advanced Server installation driver diskette (created in Step 1 of this Quick Start User's Guide).

- Press **<Enter>** to select the "Installation Driver" and continue with Windows installation.

Step B: Install the Intel® RAID Web Console Package

Install the Intel® RAID Web Console Package from the Resource CD. For more details, see the Software Guide.

Step C: To manage a RAID array from within Microsoft* Windows*

Open your Web browser and point to <http://localhost:3570>. For more information, see the Software Guide.

OR

Red Hat Linux 9.0 Installation*

IMPORTANT: Complete the steps on the reverse side before beginning your OS installation. If you are installing a version other than Red Hat* Linux 9.0, refer to <http://support.intel.com/support/motherboards/server> for installation instructions.

Step A: Install Red Hat* Linux

Read the Red Hat documentation to understand the disk space / size requirements for Red Hat* Linux 9.0.

1. Boot the system with the Red Hat* Linux 9.0 CD-ROM
2. At the boot prompt, insert the Linux driver disk that you created in Step 1 on the reverse side of this document.
3. Type **Linux dd**. Press **<Enter>**.
4. Follow the on-screen instructions to complete the installation. The RAID controller driver will be automatically detected and installed.

Step B: Install the Intel® RAID Web Console Package

Install the Intel® RAID Web Console Package from the Resource CD. For more details, see the Software Guide.

Step C: To manage a RAID array from within Red Hat* Linux

Open your Web browser and point to <http://localhost:3570>. For more information, see the Software Guide.

Understanding the Audible Alarm

The audible alarm will beep under two conditions: When a drive has failed, and during and following a rebuild.

The drive failure alarms are as follows:

- Degraded Array: Short tone, one second on, one second off
- Failed Array: Long tone, three seconds on, one second off
- Hot Spare Commissioned: Short tone, one second on, three seconds off


The drive failure tones will repeat until the problem is corrected or until the alarm is silenced or disabled.

The rebuild alarm tone remains on during the rebuild. After the rebuild completes, an alarm with a different tone will sound, signaling the completion of the rebuild. This is a one-time (non-repeating) tone.

The alarm can be *disabled* either in the BIOS Console or in the Web Console management utilities. When disabled, the alarm will not sound unless it is re-enabled in one of the utilities.

The alarm can be *temporarily silenced* either in the BIOS Console or in the Web Console management utilities. The alarm is not disabled and will sound again if another event occurs. The temporarily silenced alarm will be enabled if the system is power cycled.

Intel® RAID Controller SRCS16 Diagram



Choosing the Right RAID Level

