

AC450NX Rack Server System Product Guide

Order Number: 702026-003

Information in this document is provided in connection with Intel products. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document. Except as provided in Intel's Terms and Conditions of Sale for such products, Intel assumes no liability whatsoever, and Intel disclaims any express or implied warranty, relating to sale and/or use of Intel products including liability or warranties relating to fitness for a particular purpose, merchantability, or infringement of any patent, copyright or other intellectual property right. Intel products are not designed, intended or authorized for use in any medical, life saving, or life sustaining applications or for any other application in which the failure of the Intel product could create a situation where personal injury or death may occur. Intel may make changes to specifications and product descriptions at any time, without notice. No part of this document may be copied or reproduced in any form or by any means without prior consent of Intel.

† Third party brands and names are property of their respective owners.

Copyright © 1998-1999, Intel Corporation. All Rights Reserved.

Quick Reference and Conventions

For translated warnings, see Appendix C, “Warnings”

Part I: User’s Guide

- 1 Introduction to the High-performance Server
- 2 On-site Installation: Installing the Server
- 3 Power-on Self Test: Description/Running
- 4 Setup Utility: When to Run
- 5 System Setup Utility: When to Run
- 6 SCSI Configuration Utility
- 7 Emergency Management Port Console: How to Use
- 8 FRU and SDR Load Utility: When to Run
- 9 Hot-swappable Fans: Hot Swapping
- 10 Hot-swappable SCSI Hard Disk Drives: Installing/Hot Swapping
- 11 Hot-swappable Power Supplies: Hot Swapping

Part II: Service Technician’s Guide

Safety Guidelines

- 12 Server Covers: Removing/Reinstalling
- 13 Server Components: Removing/Reinstalling
- 14 Removable Media Drives: Installing/Removing/Replacing
- 15 Midplane: Description/Voltages
- 16 Peripheral Bay Backplane: Description
- 17 PHP I/O Baseboard: Description/Setting Configuration Jumpers
- 18 CPU Baseboard: Description/Setting Configuration Jumpers

19 Memory Modules: Description/Adding Memory

20 Power System: Description/Calculating Power Usage

21 Back-up Battery: Replacing/Disposing

22 Solving Problems: Troubleshooting/Error Messages

23 Front Panel: Description/Voltages

24 Peripheral Bay Blindmate Board: Description

A Regulatory Specifications

B Equipment Log

C Warnings

Conventions



WARNING

WARNING indicates a hazard that *can* cause personal injury or equipment damage if the hazard is not avoided.



CAUTION

CAUTION indicates a hazard that might cause personal injury, damage to hardware, or software if the hazard is not avoided.



NOTE

Notes provide information and may be used to emphasize a recommended sequence of steps.

- <F1> A letter, number, symbol, or word enclosed in < > represents a key on your keyboard. For example, the instruction "press <F1>" means press the key labeled "F1" on your keyboard.
- <Enter> The <Enter> key is used to enter commands and responses to prompts. Some manuals refer to <Enter> as RETURN, CARRIAGE RETURN, <CR>, or use an arrow. All of these terms are interchangeable.
- <x + y> Two or three key names, separated by plus signs, indicate multiple-key entries. For example, <Ctrl + Alt + Del> means hold down <Ctrl> and <Alt> and press .
- L In all tables in this guide, active-low signal names have an "L" symbol following the name; for example, DSTBN3L. Active-high signal names do not have a "L" suffix.

Contents

Quick Reference and Conventions

<i>For translated warnings, see Appendix C, "Warnings".....</i>	iii
Part I: User's Guide	iii
Part II: Service Technician's Guide.....	iii
Conventions	iv

Part I: User's Guide

1 Introduction to the High-performance Server

Server Features.....	18
Chassis	21
Controls and Indicators.....	24
Server Security.....	26
Password Protection.....	26
Secure Boot Mode.....	26
Boot Sequence Control.....	26
Boot Without Keyboard.....	27
Locked Power and Reset Switches.....	27
Diskette Write Protect.....	27
Video Blanking.....	27
Emergency Management Port (EMP)	27

2 On-site Installation: Installing the Server

Selecting a Site	29
Physical Specifications	30
Environmental Specifications.....	30
After Unpacking the Server	31
Connecting Peripheral Devices	31
Obtaining a Power Cord Set.....	33
Turning on Your Server	33
Power-on Self Test	35
Booting From the Server Configuration Software CD	36
Copying Configuration Software to Diskettes.....	37
Installing Video Drivers.....	37
Installing SCSI Drivers.....	37
Server Won't Boot From the CD.....	38

3 Power-on Self Test: Description/Running

Power-on Self Test (POST).....	41
--------------------------------	----

4 Setup Utility: When to Run

When to Run the BIOS Setup Utility	43
Running the Setup Utility	43
Main Menu.....	45

Advanced Menu.....	47
Security Menu.....	51
Server Menu.....	52
Boot Menu.....	54
Exit Menu Selections.....	55
5 System Setup Utility: When to Run	
When to Run the System Setup Utility.....	57
What You Need to Do.....	58
Running the SSU.....	58
Starting the SSU.....	59
Customizing the SSU.....	60
Launching a Task.....	60
Resource Configuration Add-in (RCA) Window.....	61
Multiboot Add-in.....	67
Security Add-in.....	68
System Event Log Manager Add-in.....	70
Sensor Data Record (SDR) Manager Add-In.....	71
Field Replaceable Unit (FRU) Manager.....	73
Exiting the SSU.....	74
6 SCSI Configuration Utility	
7 Emergency Management Port Console: How to Use	
How EMP Console Works.....	78
Requirements.....	80
Setting Up the Server for the EMP.....	81
Server Menu.....	81
Console Redirection Submenu.....	81
Main EMP Console Window.....	82
Toolbar.....	82
Status Bar.....	82
EMP Console Main Menu.....	83
Server Control Operations.....	84
Connect.....	84
Power On/Off.....	85
Reset.....	86
Phonebook.....	87
FRU Viewer.....	88
8 FRU and SDR Load Utility: When to Run	
When to Run the FRUSDR Load Utility.....	89
What You Need to Do.....	89
How You Use the FRUSDR Load Utility.....	90
Command Line Format.....	90
Parsing the Command Line.....	90
Displaying Usage Information.....	90

Displaying a Given Area	92
Using Specified CFG File.....	95
9 Hot-swappable Fans: Hot Swapping	
Tools and Supplies You Need	97
Equipment Log	97
Hot-Swapping a Fan.....	98
Removing a Fan	98
Replacing a Fan.....	100
10 Hot-swappable SCSI Hard Disk Drives: Installing/Hot Swapping	
Hot-docking Bays	101
Tools and Supplies You Need	101
Equipment Log	101
SCSI SCA Hard Disk Drives.....	102
Mounting a SCSI SCA Hard Disk Drive in a Carrier	102
Installing a SCSI SCA Hard Disk Drive in a Hot-docking Bay.....	104
Hot-swapping a SCSI SCA Hard Disk Drive.....	106
11 Hot-swappable Power Supplies: Hot Swapping	
Tools and Supplies You Need	109
Equipment Log	109
Hot Swapping a Power Supply	110
Removing a Power Supply.....	110
Replacing a Power Supply.....	112
Part II: Service Technician’s Guide	
Safety Guidelines	
Warnings and Cautions	115
Server Precautions	115
Equipment Rack Precautions.....	116
12 Server Covers: Removing/Reinstalling	
Warnings and Cautions	119
Tools and Supplies You Need	119
Equipment Log	119
Covers.....	119
Removing the Peripheral Bay Cover.....	120
Reinstalling the Peripheral Bay Cover.....	120
Removing the Front Bezel	121
Reinstalling the Front Bezel	121
Removing the Top Cover	121
Reinstalling the Top Cover.....	123
Removing the PCI Bus Hot-Plug Cover	123
Reinstalling the PCI Bus Hot-Plug Cover	124
Removing the Fan Array Assembly Cover	125

Reinstalling the Fan Array Assembly Cover	125
Removing the Memory Module Cover.....	125
Reinstalling the Memory Module Cover	126

13 Server Components: Removing/Reinstalling

Warnings and Cautions	127
Tools and Supplies You Need	127
Equipment Log	127
Fan Array Housing	128
Removing the Fan Array Housing.....	128
Reinstalling the Fan Array Housing.....	128
LCD Module	131
Removing the LCD Module.....	131
Reinstalling the LCD Module.....	131
Memory Modules.....	132
Removing a Memory Module	132
Reinstalling a Memory Module.....	133
Front Side Bus Terminator Module.....	135
Removing a Terminator Module.....	135
Reinstalling a Terminator Module	135
Processor	137
Removing a Processor	137
Installing a Processor	137
DC to DC Converter VRM	138
Removing a DC to DC Converter VRM.....	138
Installing a DC to DC Converter VRM.....	138
CPU Tray	140
Removing the CPU Tray.....	140
Reinstalling the CPU Tray.....	140
Front Panel Board	142
Removing the Front Panel Board.....	142
Reinstalling the Front Panel Board	143
CPU Baseboard	144
Removing the CPU Baseboard.....	144
Reinstalling the CPU Baseboard.....	144
Add-in Boards.....	146
Installing an Add-in Board.....	146
Removing an Add-in Board.....	149
I/O Riser Card	150
Removing the I/O Riser Card.....	150
Reinstalling the I/O Riser Card	150
I/O Tray	152
Removing the I/O Tray.....	152
Reinstalling the I/O Tray	152
Intelligent Chassis Management Bus (ICMB) Board.....	154
Removing the ICMB Board	154
Reinstalling the ICMB Board.....	154

PHP I/O Baseboard	156
Removing the PHP I/O Baseboard	156
Reinstalling the PHP I/O Baseboard	156
MidPlane	158
Removing the Midplane	158
Reinstalling the Midplane	158
AC Filter and Cable	158
Removing the AC Filter and Cable.....	158
Reinstalling the AC Filter and Cable	159
Peripheral Bay.....	159
Removing the Peripheral Bay	159
Reinstalling the Peripheral Bay	159
Peripheral Bay Backplane	160
Removing the Peripheral Bay Backplane	160
Reinstalling the Peripheral Bay Backplane.....	161
Peripheral Bay Blindmate Board.....	162
Removing the Peripheral Bay Blindmate Board	162
Reinstalling the Peripheral Bay Blindmate Board.....	162
14 Removable Media Drives: Installing/Removing/Replacing	
Warnings and Cautions	165
Tools and Supplies You Need	165
Equipment Log	165
Diskette Drive	165
Removing the Diskette Drive	166
Replacing the Diskette Drive.....	166
CD-ROM Drive	168
Removing the CD-ROM Drive.....	168
Replacing the CD-ROM Drive	170
15 Midplane: Description/Voltages	
Warnings and Cautions	171
Midplane Features.....	171
I ² C Bus	171
Detection Signals.....	172
5 V Quick Discharge	172
Midplane Connectors.....	173
Grand Connector	174
Grand Connector Power Module 1 Connector J2.....	177
Grand Connector Power Module 2 Connector J5.....	178
Memory Board 1 & 2 Interface Connector J6 & J7.....	179
Power Supply Connectors J8, J9, & J10	181
Peripheral Power Connector J11	181

16 Peripheral Bay Backplane: Description

Warnings and Cautions	183
Peripheral Bay Backplane	183
SCSI ID Configurations.....	184
Peripheral Bay Backplane Connectors	184

17 PHP I/O Baseboard: Description/Setting Configuration Jumpers

Warnings and Cautions	185
PHP Input/Output (I/O) Baseboard Features	185
32-bit PCI Expansion Slots	186
64-bit PCI Hot-plug Expansion Slots.....	186
ISA Expansion Slot.....	186
PCI Video Controller	187
Symbios 53C896 SCSI Controller.....	190
IDE Controller	190
Server Management (SM)	190
I/O Riser Card.....	192
PHP I/O Baseboard Configuration Jumpers	193
Restoring CMOS to Default Values.....	194
Clearing the Password.....	195
Updating the BIOS.....	195
Updating BMC, FPC, and HCS Firmware	198
Boot Sequence.....	199
PHP I/O Baseboard Layout	200
PHP I/O Baseboard Connectors.....	201
Expander Bus Connector: Signal Section	201
Expander Bus Connector: Power Section	204
32-bit PCI Connector	205
64-bit PCI Connector	206
ISA Connector	207
Diskette Drive Port.....	208
Wide/Fast 16-bit SCSI Port.....	209
IDE Port	210
I ² C Feature Connector.....	210
I ² C Connector	211
Front Panel Connector.....	211
Legacy Connector.....	212
USB Port.....	212
Keyboard and Mouse Ports	213
Serial Ports	213
Parallel Port	214
ICMB Connectors	214
VGA Video Port	215

18 CPU Baseboard: Description/Setting Configuration Jumpers

Warnings and Cautions	217
CPU Baseboard Features	217
Processors.....	217
Memory Interface.....	218
DC-to-DC Voltage Converters	218
I/O Interface.....	219
Front Side Bus.....	219
Front Side Bus Terminator Module	219
CPU Baseboard Configuration Jumpers.....	220
Changing a Jumper Setting	221
CPU Baseboard Layout.....	222
CPU Baseboard Connectors	223
Memory Connectors, J23 and J20:Rows A, B, and C	223
I/O Connector	226
Power Connectors	229
Front Panel Connector.....	230

19 Memory Modules: Description/Adding Memory

Warnings and Cautions	233
Module Features	233
EDO DRAM Array	234
Memory Module Layout.....	239
Installing DIMMs.....	240
Removing DIMMs.....	242
System Management Interface.....	243
Memory Module Connector	244

20 Power System: Description/Calculating Power Usage

Warnings and Cautions	249
AC Input Power	249
Jumper JP1 Installing/Removing.....	250
Power System	251
Power Supply Input Voltages.....	252
Power Supply Output Voltages	252
Server Current Usage	253
Calculating Power Usage	254

21 Back-up Battery: Replacing/Disposing

Warnings and Cautions	257
Tools and Supplies You Need	257
Equipment Log	257
Back-up Battery.....	258
Replacing the Back-up Battery	259

22 Solving Problems: Troubleshooting/Error Messages

Warnings and Cautions	261
Resetting the Server.....	261
Initial Startup of the Server	262
Checklist.....	262
Running New Application Software.....	263
Checklist.....	263
After the Server Has Been Running Correctly	263
Checklist.....	263
More Troubleshooting Procedures	264
Preparing the Server for Diagnostic Testing	264
Monitoring POST	264
Verifying Proper Operation of the Server Lights.....	265
Confirming Loading of the Operating System	265
Specific Problems and Corrective Actions	265
Power Light Does Not Light	266
Server Cooling Fans Do Not Rotate Properly	266
No Characters Appear on Screen.....	267
Characters Are Distorted or Incorrect	267
Incorrect or no Beep Codes.....	267
Diskette Drive Activity Light Does Not Light	268
Hard Disk Drive Activity Light Does Not Light	268
Problems With Application Software	269
Server Powers Up and Immediately Powers Down.....	269
Error Codes and Messages.....	269
Port 80h Codes.....	270
POST Error Codes and Messages.....	273

23 Front Panel: Description/Voltages

Warnings and Cautions	277
Front Panel Board	277
Fan Speed Control Voltage.....	278
Speaker.....	278
I ² C Bus	278

24 Peripheral Bay Blindmate Board: Description

Warnings and Cautions	279
Features	279
Peripheral Bay Blindmate Connectors	279
Blind Mate Connector J1	280
Power Connector J2.....	281
Diskette Connector J3	281
IDE Connector J4	282
Wide SCSI Connector J5.....	283

A Regulatory Specifications

Declaration of Compliance	285
Safety Compliance	285
Electromagnetic Compatibility (EMC)	285
Electromagnetic Compatibility Notice (USA)	286
Electromagnetic Compatibility Notices (International)	286

B Equipment Log

Equipment Log	287
---------------------	-----

C Warnings

WARNING: English (US)	290
AVERTISSEMENT: Français	292
WARNUNG: Deutsch	294
AVVERTENZA: Italiano	296
ADVERTENCIAS: Español	298

Index**Figures**

1-1. High-performance Server	17
1-2. Chassis, Board Set	21
1-3. Chassis, Front View	22
1-4. Chassis, Rear View	23
1-5. Server Controls and Indicators	25
2-1. Server I/O Connections	32
2-2. Server Power and Reset Switches	34
2-3. CD-ROM Drive	36
2-4. Boot Menu	38
2-5. CD-ROM Boot Menu	38
5-1. System Setup Utility Main Window	61
5-2. RCA Window	62
5-3. Define ISA Window	63
5-4. Configuration Window	65
5-5. System Resource Usage Window	66
5-6. Multiboot Main Window	67
5-7. Password Main Window	69
5-8. System Event Log Main Window	71
5-9. SDR Manager Main Window	72
5-10. FRU Manager Main Window	74
7-1. EMP Console in Command State	78
7-2. EMP Console in Redirect State	79
7-3. Connect Dialog	84
7-4. Power On/Off Dialog	85
7-5. Reset Dialog	86
7-6. Phonebook Dialog	87
9-1. Removing/Hot-swapping a Fan	99

10-1.	Hard Disk Drive and Carrier	103
10-2.	Hard Disk Drive and Carrier Assembly.....	103
10-3.	Installing a Hard Disk Drive.....	105
10-4.	Hot-swap SCSI Drive Indicators.....	107
11-1.	Removing a Power Supply.....	111
12-1.	Server Covers.....	120
12-2.	Peripheral Bay Cover and Front Bezel.....	121
12-3.	Top Cover.....	122
12-4.	PCI Regular Slot Cover.....	123
12-5.	PCI Bus Hot-Plug Cover.....	124
12-6.	Memory Module Cover.....	126
13-1.	Fan Removal	129
13-2.	Fan Array Housing.....	130
13-3.	LCD Module.....	132
13-4.	Memory Module.....	134
13-5.	Removing a Holddown.....	136
13-6.	DC to DC Converter VRM.....	139
13-7.	CPU Tray.....	141
13-8.	CPU Tray Support Rail	142
13-9.	Front Panel Board.....	143
13-10.	CPU Baseboard.....	145
13-11.	PHP I/O Baseboard Expansion Slots.....	147
13-12.	Expansion Slot Cover	147
13-13.	Installing an Add-in Board.....	148
13-14.	I/O Riser Card.....	151
13-15.	I/O Tray.....	153
13-16.	ICMB Board	155
13-17.	PHP I/O Baseboard	157
13-18.	Peripheral Bay	160
13-19.	Peripheral Bay Backplane.....	161
13-20.	Peripheral Bay Blind Mate Board	163
14-1.	Diskette Drive	167
14-2.	CD-ROM Drive.....	169
14-3.	Snap-in Plastic Slide Rails	170
15-1.	Midplane.....	173
16-1.	Peripheral Bay Backplane.....	184
17-1.	I/O Riser Card.....	192
17-2.	J2C1 Configuration Jumper Block.....	193
17-3.	PHP I/O Baseboard Layout.....	200
18-1.	J31 Jumper Block	220
18-2.	CPU Baseboard Layout	222
19-1.	4:1 Interleave With Four DIMMs	236
19-2.	4:1 Interleave With Eight DIMMs.....	237
19-3.	4:1 Interleave With 12 DIMMs.....	238
19-4.	Memory Module Layout	239
19-5.	DIMM Orientation.....	240
19-6.	Properly Seated DIMM.....	241
19-7.	Removing DIMMs	242

20-1. Jumper JP1 250
 21-1. Lithium Back-up Battery..... 260
 24-1. Peripheral Bay Blindmate Connectors 279

Tables

7-1. EMP Console Access Modes (Server configured for console redirection)..... 79
 7-2. EMP Console Access Modes (Server not configured for console redirection)..... 80
 17-1. onfiguration Jumpers (J2C1)..... 194
 18-1. J31 Jumpers for VRMs and Server Management 220
 18-2. J31 Jumpers for Bus Ratios 221
 19-1. Memory Module DIMM Support 234
 20-1. Power Supply AC Input Ratings 252
 20-2. Power Supply Output Ratings 252
 20-3. Server Board Set Voltages and Currents 253
 20-4. Worksheet for Calculating DC Power Usage..... 254
 20-5. Total Combined Power Used by Your Server..... 255
 23-1. Fan Speed Control..... 278

Part I: User's Guide


- 1 Introduction to the High-performance Server**
- 2 On-site Installation: Installing the Server**
- 3 Power-on Self Test: Description/Running**
- 4 Setup Utility: When to Run**
- 5 System Setup Utility: When to Run**
- 6 SCSI Configuration Utility**
- 7 Emergency Management Port Console: How to Use**
- 8 FRU and SDR Load Utility: When to Run**
- 9 Hot-swappable Fans: Hot Swapping**
- 10 Hot-swappable SCSI Hard Disk Drives: Installing/Hot Swapping**
- 11 Hot-swappable Power Supplies: Hot Swapping**

1 Introduction to the High-performance Server

The modular scalable architecture of your high-performance rack server supports symmetrical multiprocessing (SMP) and a variety of operating systems. The server comes with Peripheral Component Interconnect (PCI) and Industry Standard Architecture (ISA) buses. The server board set consists of eight individual boards.

- CPU baseboard
- Two memory modules
- Front side bus terminator module
- PCI hot-plug (PHP) I/O baseboard
- I/O riser card
- Front panel board
- Midplane
- LVDS (low-voltage differential signal) SCSI hot-swap peripheral bay backplane

The CPU baseboard is mounted horizontally toward the front of the chassis, and the PHP I/O baseboard is mounted horizontally towards the rear of the chassis. The baseboards plug into connectors on the midplane mounted between them. The midplane interconnects the baseboards with the memory modules and power supplies. The front panel board is mounted in front of the CPU baseboard in the same plane. It provides the user interface, server management, cooling system control, and power control.



OM07311

Figure 1-1. High-performance Server

The easy-to-integrate server can easily accommodate the needs of a variety of high performance applications—for example, network servers, multiuser systems, and large database operations. As your application requirements increase, you can upgrade your server with:

- More powerful processors
- Additional memory
- Other peripheral devices
- Add-in I/O boards

Server Features

Feature	Comment
Power system with redundancy	<p>The 750 watt, 220 VAC autoranging power supplies include integrated fans for cooling. In a rack server with three supplies (2 + 1), the third one is redundant. The supplies can be replaced—hot-swapped—without turning the server power off. The server requires a minimum of two power supplies. LEDs on the back of the power supply indicate power on, failure, and predictive failure.</p>
Server chassis	<p>The electrogalvanized metal used in manufacturing the server chassis minimizes electromagnetic interference (EMI) and radio frequency interference (RFI).</p> <p>3.5-inch diskette drive in the 3.5-inch bay.</p> <p>5.25-inch IDE CD-ROM drive in the 5.25-inch half-height bay.</p> <p>Two 3.5-inch wide by 1.0-inch or 1.6-inch hot-swappable LVDS hard disk drives mounted side-by-side in the 3.5-inch hot-docking bays. The hot-docking bays allow hot-swapping of hard disk drives without shutting down the server.</p> <p>Three power supply bays populated with either two or three power supplies.</p> <p>Ten I/O expansion slot covers.</p> <p>The plastic front bezel provides airflow and easy access to drives in the hot-docking bays. The removable top covers provide proper airflow and easy access to components inside the server. A padlock (not supplied) on the back of the chassis secures the covers to prevent unauthorized entry into the server—only technically qualified personnel should remove the server covers.</p>
Cooling system with redundancy	<p>Six fans (5 + 1) cool and circulate air through the server. The sixth fan is redundant. The fans can be replaced—hot-swapped—without turning the server power off. An LED mounted next to each fan guarantees positive identification of the failed fan.</p> <p>Integrated power supply fans—two or three—cool and circulate air through the power supplies and the bottom of the chassis.</p>

continued

Server Features (continued)

Feature	Comment
Front panel board	The front panel board provides the user interface to the server. The board allows other servers to communicate with this server, even while power is down, via an Intelligent Chassis Management Bus (ICMB).
	Push-button switches control power-up, reset, and nonmaskable interrupt (NMI) functions.
	LEDs indicate power on, power supply failure, hard drive failure, or a fan or other server cooling failure.
	An LCD panel provides information about boot status, available number of processors, and other server management information.
Server management	Interintegrated circuit bus (I ² C) for diagnostic and intrachassis communication. ICMB for interchassis platform management communications.
	Real-time clock/calendar (RTC).
	Front panel controls and indicators (LEDs).
	Basic Input/Output System (BIOS), Power-on Self Test (POST), and Setup Utility stored in a flash memory device.
	System Setup Utility (SSU).
	SCSI Configuration Utility.
	Emergency Management Port (EMP) Utility.
	Field Replacement Unit (FRU) and Sensor Data Record (SDR) Load Utility.
CPU baseboard	The baseboard supports up to four Pentium® II Xeon™ processors, each processor is packaged in a Single Edge Contact (S.E.C.) cartridge; the baseboard supports two memory modules.
Pentium II Xeon processor packaged in an S.E.C. cartridge	The cartridge includes the processor core and L2 cache components.
Memory module	Each memory module supports up to 4 GB of ECC memory using sixteen 72-bit dual inline memory modules (DIMMs). (The CPU baseboard requires two memory modules, one must contain DIMMS.)


continued

Server Features (continued)

Feature	Comment
PHP I/O baseboard	<p>One 16-bit ISA expansion slot shares a common chassis I/O expansion slot with a 32-bit PCI slot (you can use the shared slot for either ISA or PCI but not both).</p> <p>Six 32-bit PCI expansion slots; one of them shares a common chassis I/O expansion slot with the ISA slot (you can use the shared slot for either PCI or ISA but not both).</p> <p>Four 64-bit PCI hot-plug expansion slots.</p> <p>Integrated Cirrus Logic GD5446 VisualMedia[†] PCI super video graphics array (SVGA) controller with 2 MB of video memory.</p> <p>The Symbios[†] 53C896 LVDS SCSI controller supports two LVDS channels. One channel controls internal devices such as CD-ROMs, tape, and DVDs drives, in addition to the two hard drives in the peripheral bay. The other channel provides a connection to external devices.</p> <p>The diskette controller supports one drive.</p> <p>The PCI-enhanced Integrated Drive Electronics (IDE) interface supports one IDE bus.</p> <p>PS/2[†]-compatible keyboard/mouse controller.</p> <p>Two universal serial bus (USB) ports.</p>
I/O riser card	<p>This card contains all legacy I/O connections; it plugs into a card edge connector on the PHP I/O baseboard.</p> <p>PS/2-compatible keyboard and mouse ports (these are interchangeable).</p> <p>PS/2-compatible parallel port.</p> <p>Analog VGA, 15-pin video port.</p> <p>Two PS/2-compatible, 9-pin serial ports.</p>
Midplane	<p>The midplane</p> <ul style="list-style-type: none"> • electrically connects the PHP I/O, memory, power supplies and CPU baseboard • distributes DC power to the PHP I/O and CPU baseboards, peripheral bay backplane, cooling fans, and the front panel board • distributes the power load of the server among two or three 750 watt autoranging power supplies
Front side bus (FSB) terminator module	<p>This module plugs into any unpopulated slot 2 connector on the CPU baseboard. This module terminates the FSB GTL+ signals of the slot 2 connector when a processor S.E.C. cartridge is not installed in it.</p>
Peripheral bay backplane	<p>This backplane supports hot-swapping of SCA type SCSI drives, mounted in carriers, in and out of the hot-docking bays.</p>

Chassis


Figures 1-2 and 1-3 show the major components of the server.



OM07330

Figure 1-2. Chassis, Board Set


- A. Front panel board
- B. CPU baseboard and processors
- C. PHP I/O baseboard
- D. Midplane
- E. Memory modules



OM07349

Figure 1-3. Chassis, Front View

- A. 3.5-inch diskette drive (3.5-inch bay)
- B. CD-ROM drive (5.25-inch bay)
- C. Hot-swap bays




OM07300

Figure 1-4. Chassis, Rear View

- A. PCI and ISA add-in board expansion slots
- B. External LVDS connector
- C. PS/2-compatible keyboard/mouse port, 6-pin
- D. PS/2-compatible keyboard/mouse port, 6-pin
- E. PS/2-compatible serial ports 0 and 1, 9-pin RS-232 connector
- F. Super VGA compatible, 15-pin video connector
- G. PS/2-compatible parallel port (LPT), 25-pin bidirectional subminiature D connector
- H. USB ports 0 and 1, 4-pin connector
- I. Intelligent Chassis Management Bus (ICMB) connectors port 1 and 2
- J. Power Supplies
- K. Failure LED (yellow)
- L. Predictive failure LED (yellow) for power supply fan
- M. Power LED (green)
- N. AC input power connector

Controls and Indicators

Item	Feature	Description
Front Panel		
A	Power switch	When pressed, it turns on or off the DC power inside the server.
B	Reset switch	When pressed, it resets the server and causes the power-on self test (POST) to run.
C	NMI switch	When pressed, it causes a nonmaskable interrupt. This switch is recessed behind the front panel to prevent inadvertent activation. It must be pressed with a narrow non-conductive tool (not supplied).
D	Power LED (green)	When lit continuously, it indicates the presence of DC power in the server. It goes out when the power is turned off or the power source is disrupted.
E	Power fault LED (yellow)	When lit continuously, it indicates a power supply failure.
F	Cooling fault LED (yellow)	When lit, it indicates a fan failure has been detected in the server.
G	Drive fault LED (yellow)	When lit continuously, it indicates an asserted fault status on one or more hard disk drives in the hot-docking bay. When flashing, it indicates drive reset in progress.
H	Front panel LCD	It displays information about processor type and failure codes.
I	SCSI drive hot-docking bays	Two SCSI hot docking bays for 3.5-inch x 1.0 inch or 1.6-inch SCSI hard drives.
Status LEDs for SCSI Drives in Hot-docking Bays		
J	Drive fault LED (yellow)	When lit continuously, it indicates an asserted fault status on one or more hard disk drives in the hot-docking bay. When flashing, it indicates drive reset in progress.
K	Drive activity LED (green)	When flashing, it indicates drive activity.
L	Drive power LED (green)	When lit continuously, it indicates the presence of the drive and power on the drive.
CD-ROM Drive		
M	Open/close button	When pressed, it opens or closes the CD tray.
N	Activity LED	When lit, it indicates the drive is in use.
O	Volume control	It adjusts the volume of headphones or speakers.
P	Headphone jack	It provides a connection for headphones or speakers.
3.5-inch Floppy (Diskette) Drive		
Q	Activity LED	When lit, it indicates the drive is in use.
R	Ejector button	When pressed, it ejects the diskette.



OM07344

Figure 1-5. Server Controls and Indicators

Server Security

There are several ways to prevent unauthorized entry or use of the server.

Security with the Setup utility:

- Set server administrative and user passwords.
- Set secure mode to prevent keyboard or mouse input and to prevent use of the front panel controls.

Security with the System Setup Utility (SSU):

- Enable the keyboard lockout timer so that the server requires a password to reactivate the keyboard and mouse after a specified time-out period—1 to 128 minutes.
- Set an administrative password.
- Set a user password.
- Activate the secure mode hot-key.
- Disable writing to the diskette drive.

Password Protection

BIOS passwords prevent unauthorized tampering with the server. If you set the user password, but not the administrative password, the BIOS requires you to enter the user password before you can boot the server or run the SSU. If you set both passwords, entering either password lets you boot the server or enable the keyboard and mouse. Only the administrative password lets you change the server configuration with the flash-resident Setup utility.

Secure Boot Mode

The secure boot mode allows the server to boot and run the operating system (OS). However, you cannot use either the keyboard or the mouse until you enter the user password.

You can use Setup to put the server in the secure boot mode. If the BIOS detects a disk in the CD-ROM drive or a diskette in floppy drive A at boot time, it prompts you for a password. When you enter the password, the server boots from the disk in the CD-ROM drive or the diskette in drive A. Entering a password also disables the secure mode.

If there is no disk in the CD-ROM drive or diskette in drive A, the server boots from drive C. It automatically goes into secure mode. All enabled secure mode features go into effect at boot time.

If you set a hot-key combination, you can secure the server immediately.

Boot Sequence Control

The BIOS security features determine the boot devices and the boot sequence. They also control disabling writes to the diskette drive in secure mode. You can use the SSU to select each boot device. The default boot sequence is diskette, hard disk, CD-ROM, and Network.

Boot Without Keyboard

The server can boot with or without a keyboard. Before it boots, the BIOS displays a message about the keyboard stating whether or not it detects one. During POST, the BIOS automatically detects and tests the keyboard if it is present.

Locked Power and Reset Switches

The power and reset push-button switches on the front panel are locked when the server is in the secure mode. To exit from the secure mode, you must enter your user password.

Diskette Write Protect

If Diskette Write Protect is enabled in Setup, it write-protects the diskette drive only while the server is in the secure mode. To exit from the secure mode, you must enter your user password.

Video Blanking

If Video Blanking is enabled in Setup, the video display will be off when the server is in the secure mode. To exit from the secure mode, you must enter your user password.

Emergency Management Port (EMP)

The Emergency Management Port (EMP) is a feature of Server Management. EMP lets the Front Panel Controller (FPC) communicate with a EMP console via the serial port even if the server power is off. To enable this feature in the flash-resident Setup, an administrator must enter a unique EMP password. If the administrator enters a new EMP password or clears an old one, the BIOS sends the appropriate command via the I²C bus interface to the FPC. If the administrator wants to change the password from within Setup again, the new password must be entered twice.

If the administrator sets the Password Clear jumper to the Clear position, the BIOS clears the administrator and user passwords. It also attempts to clear the EMP password. If the FPC is not present or is not functioning properly, the BIOS times out and continues.

2 On-site Installation: Installing the Server

This chapter tells how to:

- Select a site
- Connect input and output devices
- Turn on the server and create installation diskettes from the Server System Configuration Software CD
- Read and print a copy of this manual
- Exit to DOS



WARNING

The minimum server configuration weighs about 51.4 kg (113 lbs), and the maximum one weighs close to 60 kg (132 lbs). To avoid personal injury, have someone help you move the server. Do not attempt to lift or move the server by holding the handles on the power supply.

Selecting a Site

The server operates reliably within the specified environmental limits (see page 30). The chosen site must be close to a grounded power outlet applicable for the electrical code of that region. The minimum available power requirements are described in Chapter 20, “Power System: Description/Calculating Power Usage”.



CAUTION

Ensure that the power service connection is through a properly grounded outlet.

The site must also be:

- Clean and dust-free
- Well ventilated and away from sources of heat
- Isolated from strong electromagnetic fields and electrical noise caused by electrical devices such as air conditioners, large fans, large electric motors, radio and TV transmitters, and high frequency security devices
- Spacious enough to provide sufficient room behind and around the server so that you can remove AC power from it by unplugging the power cord from the AC inlet filter or wall outlet
- Away from sources of vibration or physical shock

Physical Specifications

Height	31.12 cm (12.25 inches)
Width	44.45 cm (17.5 inches)
Depth	71.12 cm (28.0 inches)
Weight	51.4 kg (113 lbs) minimum configuration; 60 kg (132 lbs) maximum configuration

Environmental Specifications

Temperature	-40° to 70 °C (-40° to 158 °F)
Nonoperating	5° to 40 °C (41° to 104 °F); with maximum derated 1°C for every 1000 ft
Operating	(305 m) above 1524 m (5000 ft).
Humidity	
Operating wet bulb	Not to exceed 37.6 °C (100.4 °F) without peripherals
Nonoperating	95% noncondensing at 55 °C (131 °F)
Operating	85% noncondensing at 40 °C (104 °F)
Shock	
Nonoperating	30 g trapezoidal, 11 msec
Operating	2.0 g, 11 msec, 1/2 sine
Altitude	0 to 3048 m (0 to 10000 ft) Maximum ambient temperature is linearly derated between 1524 m (5000 ft) and 3048 m (10000 ft) by 1 °C per 305 m (1000 ft)
Acoustic	
Sound pressure	<=55dbA at ambient temperatures < 28 °C measured at bystander positions in operating mode.
Sound power	<= 6.5 BA at ambient temperatures < 28 °C in operating mode.
Electrostatic discharge (ESD)	Tested to 20 kilovolts (kV), no component damage. (CD-ROM drive tested to 15 kV, manufacturer's specification.)
AC Input Power	Two (or three) power supplies, fully loaded
100-120 V~	100-120 V~, 6.0 A, 50/60 Hz
200-240 V~	200-240 V~, 4.0 A, 50/60 Hz

After Unpacking the Server

Inspect the shipping box for evidence of mishandling during transit. If the shipping box is damaged, photograph it for reference. After removing the contents, keep the damaged box and the packing materials. If the contents appear damaged, file a damage claim with the carrier immediately.

Save the shipping boxes and packing materials to repackage the server in the event you decide to move it to another site.

Connecting Peripheral Devices



CAUTION


Before connecting peripheral devices to the server, verify that the power cord is unplugged from the AC inlet filter or wall outlet. Otherwise, equipment damage can result.

Only a *qualified service technician* is authorized to remove the server covers and to access any of the components inside the server.

If your server normally operates without a video monitor and keyboard—for example, as a network server—you must install them to configure it. You may remove them after running the SSU. See Chapter 5, “System Setup Utility: When to Run” for information about running this utility.

Connect your keyboard, mouse, monitor, and other peripheral devices after a *qualified service technician* installs internal options. See Figure 2-1.

Keyboard and Mouse	Connect the signal cable of a PS/2-compatible keyboard or mouse to either one of the 6-pin miniature Deutsche Industrie Norm (DIN) connectors on the server back panel. The BIOS detects and initializes the keyboard and mouse ports accordingly. Each port is overcurrent protected by a 1-ampere positive temperature coefficient (PTC) resistor.
Monitor	Connect the signal cable of the video monitor to the 15-pin connector of the Super VGA port on the back panel.
Other Devices	Connect other external peripheral devices by following the manufacturer’s documentation. The back panel also provides two serial ports, a parallel port, and two USB ports. The back of the chassis provides two Intelligent Chassis Management Bus (ICMB) ports.



OM07335

Figure 2-1. Server I/O Connections

- A. PS/2-compatible keyboard/mouse port, 6-pin connector
- B. PS/2-compatible keyboard/mouse port, 6-pin connector
- C. PS/2-compatible serial port 2 (COM2), 9-pin RS-232 connector
- D. PS/2-compatible serial port 1 (COM1), 9-pin RS-232 connector
- E. Super VGA compatible, 15-pin video connector
- F. PS/2-compatible parallel port (LPT), 25-pin bidirectional subminiature D connector
- G. USB ports 0 and 1, 4-pin connectors
- H. External LVDS SCSI connector
- I. Intelligent Chassis Management Bus (ICMB) port 1 and 2, SEMCONN[†] 6-pin connector

Obtaining a Power Cord Set

WARNING

Do not attempt to modify or use an AC power cord that is not the exact type required.

Because a power cord is not supplied for the server, you must obtain a power cord that meets the following criteria:


- For North America the cord must be UL Listed/CSA Certified, 14/3, 75 °C type SJT with NEMA 6-15P attachment plug and IEC 320, C19 outlet.
- For outside North America the cord must be flexible VDE certified or <HAR> (harmonized) rated 250 V, 0.75 mm² minimum conductor size with IEC 320, C19 outlet and rated for no less than the product ratings. The attachment plug shall be a three conductor grounding type, rated 125% of the total input current rating of the product and must be for the configuration in the specific region or country. The attachment plug must bear at least an accepted safety agency certification mark for the specific region or country.
- The cord must be no longer than 4.5 meters (14.76 ft).

Turning on Your Server

WARNING

The push-button on/off power switch on the front panel of the server does not turn off the AC power. To remove AC power from the server, you must unplug the power cord from the AC inlet filter or wall outlet.

1. Make sure all external devices, such as a video monitor, keyboard, and mouse (optional) have been connected.
2. Remove drive protection cards (if present) from the removable media drives.
3. Turn on your video monitor.
4. Plug the female end of the power cord into the AC inlet filter receptacle on the back of the chassis.
5. Plug the male end of the power cord into a properly grounded power outlet. See page 29 for power outlet requirements.
6. If the server does not come on when you plug the power cord into the power outlet, press the power switch on the front panel.
7. Verify that the power-on light on the front panel is lit. After a few seconds the power-on self test (POST) begins. See “Power-on Self Test” on page 35.



OM07334

Figure 2-2. Server Power and Reset Switches

- A. Power switch
- B. Reset switch
- C. NMI switch
- D. Power LED (green)
- E. Power fault LED (yellow)
- F. Cooling fault LED (yellow)
- G. Drive fault (yellow)
- H. Front panel LCD

Power-on Self Test

Each time you turn on the server the power LED on the front panel turns on and the power-on self test (POST) starts running. POST checks the I/O system board, processor system board, keyboard, and most installed peripheral devices.

During the memory test, POST displays the amount of memory that it is able to access and test. Depending on the amount of memory installed on each memory board, the test may take several minutes.

These screen prompts and messages appear after the memory test:

```
Mouse initialized....
```

```
Keyboard detected
```

```
Press <F2> to enter SETUP
```

Do *NOT* press <F2>. The above message remains for about a second, and POST continues. The server beeps once, and this message appears:

```
Operating system not found
```

Go to “Booting From the Server Configuration Software CD” on page 36.

Booting From the Server Configuration Software CD

CAUTION

The Server Configuration Software CD contains only a limited operating system. This limited operating system provides enough function to let you boot from the CD and copy and use the utility and manual files from the CD.

But this limited OS is *NOT* intended to be copied onto diskettes or onto your hard disk as a full-function OS that supports networking or Windows[†]. To run your server and applications, you must buy the OS of your choice and install it on the server.


See Figure 2-3.

1. Open the CD tray by pressing the open/close button on the front panel of the CD-ROM drive—the tray will slide out of the drive.
2. Open the CD case. Press down on the center hub of the case with your finger to release the hub tension on the CD.

CAUTION

Handle the CD only by the inner and outer edges. Do not touch the data side of the CD—the side without the label.

3. Gently grasp the center hole and outer edge of the CD, remove it from the case, and place it **label-side** up in the tray.
4. Press the open/close button or gently push on the tray—it will automatically slide into the drive.



OM06774

Figure 2-3. CD-ROM Drive

- A. Open/close push-button switch
- B. CD tray

5. Press the reset switch on the front panel to reboot the server.
6. When POST completes, the server beeps once, boots from the CD, installs a mouse driver, and displays the CD-ROM menu. Use the arrow keys to scroll through the menu bar and to view the tasks in the pop-up menus.

⇒ NOTE

If you do not see the CD-ROM menu but see the following message instead,

```
Operating system not found
```

you need to change the “Boot Device Priority” to the CD-ROM. See “Server Won’t Boot From the CD” on page 38 for instructions.

Copying Configuration Software to Diskettes

When you copy software from the CD onto diskettes, device drivers suitable for several different operating systems are copied onto the diskettes. However, your operating system will read only those drivers it can recognize, so you cannot usually check the directory of a diskette that is not formatted for your operating system. Instead, you may see a message to the effect, “disk not formatted, do you want to format it now?” Don’t worry; the drivers for YOUR operating system should be present on the diskette and available for you to load on the system.

1. Before starting, make sure that you have on hand several blank high-density diskettes.
2. From the CD-ROM menu bar, select Create Diskettes and press <Enter>.
3. Follow the prompts to copy the software onto the diskettes.
4. When finished, select Quit to DOS (on the CD-ROM menu bar), and press <Enter>.
5. Remove the CD from the drive.

Installing Video Drivers

After configuring the server, you can install various video drivers to take full advantage of the enhanced features provided by the onboard Cirrus Logic GD5446 PCI VisualMedia accelerator. The server may not operate properly without these drivers installed.

After copying the drivers from the Configuration Software CD to diskettes, read the README.TXT file on the Display Drivers and DOS Utilities diskette. The .TXT file contains the most current information about which video drivers you need to install on your server. Follow the installation instructions in the README.TXT file.

Follow these steps to install these drivers::

1. Fully configure your server. (This can include adding application software, an ISA add-in board, PCI add-in boards, and the like.)
2. Insert disk 1 of the video drivers and utilities for MS-DOS[†] and Windows into drive A.
3. At the DOS command prompt, type **A:install** and press <Enter>.
4. Follow the onscreen directions to install the video drivers.

Installing SCSI Drivers


After copying the SCSI drivers from the Configuration Software CD to diskettes, follow the instructions in the README.TXT file on the first diskette to install the drivers.

Server Won't Boot From the CD

It is possible that your server was shipped with the diskette drive or another device set as the first boot device. If so, the server will try to boot from a diskette or other device rather than from the CD we have provided. By pressing <Esc> during POST, you can override the boot sequence specified in Setup by selecting a different primary boot device. This override is valid only for that specific boot. Subsequent boots revert back to the sequence specified in Setup. If the chosen device fails to load the operating system, the BIOS reverts to the previous boot sequence. The <Esc> hot key is valid while the “Press <F2> key to enter Setup” message is displayed on the screen. At the end of POST, if the <Esc> key was pressed, a pop-up boot menu is displayed. It allows you to change the boot sequence, or to enter Setup and permanently change the sequence.

Follow these steps to install these drivers:


1. Press the reset switch on the front panel to reboot the server—the CD can be in the drive or not.
2. When POST displays this message:
Press <F2> to enter SETUP
3. Press <Esc> and wait for the following boot menu to display:



OM08360

Figure 2-4. Boot Menu

4. From the boot menu, select the CD-ROM drive, and press <Enter>.
5. When you see the following pop-up menu, press <Enter> to boot from the CD.



OM08361

Figure 2-5. CD-ROM Boot Menu

The server should now boot from the CD, displaying a menu bar that includes creating diskettes, diagnostics, reading/printing the manual, and quitting to DOS.



CAUTION

If the server does not operate as described in this chapter, contact a *qualified service technician*.

3 Power-on Self Test: Description/Running

Power-on Self Test (POST)

WARNING

The push-button on/off power switch on the front panel of the server does not turn off the AC power. To remove AC power from the server, you must unplug the power cord from the AC inlet filter or wall outlet.

Each time you turn on the server the power LED on the front panel turns on and POST starts running. It checks the PHP I/O baseboard, CPU baseboard, keyboard, and most installed peripheral devices. During the memory test, POST displays the amount of memory that it is able to access and test. Depending on the amount of memory installed on the memory module, it may take several minutes to complete the memory test.

Turn on your video monitor and server. After a few seconds the power-on self test (POST) begins.

You can enter Setup when POST displays this message:

Press <F2> to enter SETUP

If you press <F2>, follow the instructions on the monitor when Setup appears.

NOTE

Because POST must complete test and initialization functions after pressing <F2>, a few seconds may pass before entering Setup.

If you do not press <F2>, POST continues.

During boot, the server recognizes and displays the BIOS banner for the onboard S153C896 SCSI host adapter on the PHP I/O baseboard.

When the BIOS banner for the SCSI host adapter appears, you can run the included SCSI configuration utility by pressing <Ctrl+C> when this message appears:

Press <Ctrl><C> To Enter Configuration Utility!

If you have installed SCSI devices in the server, press <Ctrl+C>. When the utility appears, follow the instructions on the monitor to configure the host adapter. See Chapter 6, “SCSI Configuration Utility,” for instructions.

If POST detects an error, it displays the error code, the server beeps once, and this message appears:

Press <F1> to Resume, <F2> for Setup

To resume, press <F1>. However, if a drive with bootable media is not detected, the server beeps once, and this message appears:

Operating System not found

To enter Setup, Press <F2>. When the Setup utility appears, follow the instructions on the monitor.

If POST did not detect an error and you choose not to run the SCSI Configuration Utility, POST continues, the server beeps once, and this message appears:

Operating System not found

See Chapter 2, "On-site Installation: Installing the Server," for instructions on creating software installation diskettes.

If the server halts before POST completes running, it emits a beep code indicating a fatal system error that requires immediate attention. If POST can display a message on the video monitor, it causes the speaker to beep twice as the message appears.

Note the screen display and write down the beep code you hear; this information is useful for your service representative. For a listing of beep codes and error messages that POST can generate, see Chapter 22, "Solving Problems: Troubleshooting/Error Messages."

4 Setup Utility: When to Run

The flash-resident BIOS Setup utility is used to configure PHP I/O baseboard resources. It is stored in both flash memory (NVRAM) and the battery-backed memory of the real-time clock (RTC) on the PHP I/O baseboard.

When to Run the BIOS Setup Utility

The BIOS Setup is a flash-based configuration utility that is used to configure onboard resources and to set user-selectable options such as boot device ordering, keyboard autorepeat, and security. Use Setup to configure the server into a bootable state, and then use the SSU and other utilities to further configure the server.

Setup lets you change the server configuration defaults. It does not allow you to enter or change information about PCI or ISA add-in boards; you must use the SSU instead. Setup stores the configuration values in flash memory; they take effect when you boot the server. POST checks these values against the actual hardware configuration; if they do not agree, POST generates an error message. You must then run Setup to specify the correct configuration.

You can run Setup with or without an operating system being present.

Because values entered using Setup are overwritten when you run the SSU, you should run Setup only under the following conditions:

- If the diskette drive is disabled.
- If the server has a diskette drive that is disabled or improperly configured, use Setup to configure the server into a bootable state, and then use the SSU and other utilities to further configure the server. In Setup, you can enable the drive so you can use the SSU. If necessary, you can disable the diskette drive again after exiting the SSU.
- If the server does not have a diskette drive, or it is disabled, use Setup to configure the server.
- If you have installed only an ISA add-in board in your server.

If the server has a properly configured, enabled diskette drive, use the SSU to configure the server. Information entered using the SSU overrides any entered using Setup.

Running the Setup Utility

You can enter Setup under several conditions:

- when you turn on the server
- when you reboot the server by pressing the push-button reset switch on the front panel
- when you reboot the server by pressing <Ctrl+Alt+Del> while at the DOS operating system prompt
- when you turn on or reset your server after an orderly shutdown of an operating system other than DOS

Each time you turn on or reboot your server POST begins and, after a few seconds, displays this message:

Press <F2> to enter Setup

After pressing F2, a few seconds may pass before entering Setup while POST completes tests and initialization functions. When the F2 prompt disappears, pressing F2 will have no effect. When Setup is entered, the Main Menu options page is displayed.

Use the following keys to navigate through the menus and submenus.

Press	To
F1	Get help about an item
ESC	Go back to a previous item
↑	Select the previous value in a menu option list
↓	Select the next value in a menu option list
← →	Select a major menu
-	Change the value of the current menu item to the previous value
+	Change the value of the current menu item to the next value
Enter	Activate submenus, select feature options, and change feature values
F9	<p>Display the following message:</p> <pre style="text-align: center;"> Setup Confirmation Load default configuration now? [Yes] [No] </pre> <p>The [Yes] button will be highlighted. If you press <Enter>, all Setup fields return to their default values. If you press <ESC> or select No, the server returns to the configuration it had before you pressed <F9>, without affecting any existing field values.</p>
F10	<p>Display the following message:</p> <pre style="text-align: center;"> Setup Confirmation Save configuration changes and exit now? [Yes] [No] </pre> <p>The [Yes] button will be highlighted. If you press <Enter>, all current Setup values are saved, and the system is reset. If you press <ESC> or select No, the server returns to the configuration it had before you pressed <F10>, without affecting any existing values.</p>

Main Menu

Default values are in bold typeface, and auto-configured values are shaded.

Feature	Option	Description
System Time	HH:MM:SS	Set the System Time. To select a field, press <Tab>, <Shift + Tab>, or <Enter>. Then type in a new value. If you replace the battery, the default time is 00:00. (This is a 24-hour clock.)
System Date	MM/DD/YYYY	Set the System Date. To select a field, press <Tab>, <Shift + Tab>, or <Enter>. Then type in a new value. If you replace the battery, the default date is Jan 1990.
Legacy Diskette A:	Disabled 360 KB, 5 ¼" 1.2 MB, 5 ¼" 720 KB, 3 ½" 1.44/1.25 MB, 3 ½" 2.88 MB, 3 ½"	Select the diskette type for drive A: (The 1.25 MB, 3.5-inch refers to a 1024 byte/sector Japanese media format. To support the 1.25 MB, 3.5-inch requires a 3.5-inch 3-mode diskette drive.)
Legacy Diskette B:	Disabled 360 KB, 5 ¼" 1.2 MB, 5 ¼" 720 KB, 3 ½" 1.44/1.25 MB, 3 ½" 2.88 MB, 3 ½"	Select the diskette type for drive B: (The size 1.25 MB, 3.5-inch refers to a 1024 byte/sector Japanese media format. To support the 1.25 MB, 3.5-inch requires a 3.5-inch 3-mode diskette drive.)
Primary Master	CD-ROM	Press <Enter> for options.
Autotype Fixed Disk:	Press <Enter>	Pressing <Enter> attempts to detect the drive type for drives that comply with ANSI specifications.
Type:	User Auto 1-39 CD-ROM ATAPI Removable	User—lets you enter the parameters of the hard disk drive installed at this connection. Auto—autotypes the hard disk drive installed here. 1-39—lets you select the predetermined hard disk drive installed here. CD-ROM—a CD-ROM is installed here. ATAPI Removable—removable disk drive installed here.
Multi-sector Transfers:	Disabled	
LBA Mode Control	Disabled	
32-bit I/O:	Disabled Enabled	Enabled allows 32-bit IDE data transfers.
Transfer Mode	Standard	
Ultra DMA Mode:	Disabled	
Primary Slave	None	Press <Enter> for options.
Autotype Fixed Disk:	Press <Enter>	Pressing <Enter> attempts to detect the drive type for drives that comply with ANSI specifications.

continued

Main Menu (continued)

Feature	Option	Description
Type:	User Auto 1-39 CD-ROM ATAPI Removable	User—lets you enter the parameters of the hard disk drive installed at this connection. Auto—autotypes the hard disk drive installed here. 1-39—lets you select the predetermined hard disk drive installed here. CD-ROM—a CD-ROM is installed here. ATAPI Removable—removable disk drive installed here.
32-bit I/O:	Disabled Enabled	Enabled allows 32-bit IDE data transfers.
Ultra DMA Mode:	Disabled	
Secondary Master	None	Press <Enter> for options.
Autotype Fixed Disk:	Press <Enter>	Pressing <Enter> attempts to detect the drive type for drives that comply with ANSI specifications.
Type:	User Auto 1-39 CD-ROM ATAPI Removable	User—lets you enter the parameters of the hard disk drive installed at this connection. Auto—autotypes the hard disk drive installed here. 1-39—lets you select the predetermined hard disk drive installed here. CD-ROM—a CD-ROM is installed here. ATAPI Removable—removable disk drive installed here.
32-bit I/O:	Disabled Enabled	Enabled allows 32-bit IDE data transfers.
Ultra DMA Mode:	Disabled	
Secondary Slave	None	Press <Enter> for options.
Autotype Fixed Disk:	Press <Enter>	Pressing <Enter> attempts to detect the drive type for drives that comply with ANSI specifications.
Type:	User Auto 1-39 CD-ROM ATAPI Removable	User—lets you enter the parameters of the hard disk drive installed at this connection. Auto—autotypes the hard disk drive installed here. 1-39—lets you select the predetermined hard disk drive installed here. CD-ROM—a CD-ROM is installed here. ATAPI Removable—removable disk drive installed here.
32-bit I/O:	Disabled Enabled	Enabled allows 32-bit IDE data transfers.
Ultra DMA Mode:	Disabled	
Processor Information	Press <Enter>	Displays information about all processors. You cannot modify any items in this menu. Consult your system administrator if an item requires changing.
Processor 1		Stepping ID 2.
Processor 1		L2 cache size [512 KB].
Processor 2		Stepping ID, absent or disabled.

continued

Main Menu (continued)

Feature	Option	Description
Processor 3		Stepping ID, absent or disabled.
Processor 4		Stepping ID, absent or disabled.
Keyboard Features		Press <Enter> for options.
Numlock:	Auto On Off	Select power-on state for numlock.
Key Click:	Disabled Enabled	Enabled produces the key click.
Keyboard auto-repeat rate:	30/sec 26.7/sec 21.8/sec 18.5/sec 13.3/sec 10/sec 6/sec 2/sec	Select key repeat rate.
Keyboard auto-repeat delay:	1/4 sec 1/2 sec 3/4 sec 1 sec	Select delay before key repeat.
Language	English (US) Français Deutsch Italiano Español	Select the display language for the BIOS.

Advanced Menu**Setup Warning**

Setting items on this menu to incorrect values may cause your system to malfunction.

Feature	Option	Description
Plug & Play O/S:	No Yes	Select Yes if you are using a Plug and Play capable operating system. Select No if you need the BIOS to configure nonboot devices.
Reset Configuration Data:	No Yes	Select Yes if you want to clear the system configuration data.
Enable ACPI	No Yes	Select Yes if you want to enable the advanced configuration and power interface (ACPI) BIOS.
Use Multiprocessor Specification	1.1 1.4	Configure the Multiprocessor Specification revision level. Some OSs require 1.1 for compatibility.
Large Disk Access Mode	CHS LBA	Select the drive access method for IDE drives. Most OSs use logical block addressing (LBA). However, some operating systems may use the cylinder head sector (CHS). See your OS documentation for further help.

continued

Advanced Menu (continued)

Feature	Option	Description
Pause Before Boot	Disabled Enabled	Pause five seconds before booting the OS.
PCI Configurations		Additional Setup menus to configure PCI devices.
PCI Device, Embedded SCSI A		Setup items for configuring the specific PCI device.
Option ROM Scan:	Enabled Disabled	Initialize device expansion ROM.
Enable Master:	Enabled Disabled	Enable selected device as a PCI bus master.
Latency Timer:	Default 0020h 0040h 0060h 0080h 00A0h 00C0h 00E0h	Allot minimum guaranteed time slice for bus master in units of PCI bus clocks.
PCI Devices		
Option ROM Scan:	Enabled Disabled	Initialize device expansion ROM.
Enable Master:	Enabled Disabled	Enable selected device as a PCI bus master.
Latency Timer:	Default 0020h 0040h 0060h 0080h 00A0h 00C0h 00E0h	Allot minimum guaranteed time slice for bus master in units of PCI bus clocks.
I/O Device Configuration		
Serial Port A	Disabled Enabled Auto	Configure serial port A using these options: <ul style="list-style-type: none"> • Disabled—no configuration. • Enabled—user configuration. • Auto—BIOS or OS chooses the configuration. • OS Controlled—displayed when controlled by the OS.
Base I/O Address	3F8 2F8 3E8 2E8	Set the base I/O address for serial port A.
Interrupt	IRQ3 IRQ4	Set the interrupt for serial port A.

continued

Advanced Menu (continued)

Feature	Option	Description
Serial Port B	Disabled Enabled Auto	Configure serial port B using these options: <ul style="list-style-type: none"> • Disabled—no configuration. • Enabled—user configuration. • Auto—BIOS or OS chooses the configuration. • OS Controlled—displayed when controlled by the OS.
Base I/O Address	3F8 2F8 3E8 2E8	Set the base I/O address for serial port B.
Interrupt	IRQ3 IRQ4	Set the interrupt for serial port B.
Parallel Port	Disabled Enabled Auto	Configure the parallel port using these options: <ul style="list-style-type: none"> • Disabled—no configuration. • Enabled—user configuration. • Auto—BIOS or OS chooses the configuration. • OS Controlled—displayed when controlled by the OS.
Mode	Output only Bidirectional EPP ECP	Set the mode for the parallel port.
Interrupt	IRQ5 IRQ7	Set the interrupt for the parallel port.
Diskette Controller	Disabled Enabled Auto	Configure the diskette controller using these options: <ul style="list-style-type: none"> • Disabled—no configuration. • Enabled—user configuration. • Auto—BIOS or OS chooses the configuration. • OS Controlled—displayed when controlled by the OS.
Base I/O Address	Primary Secondary	Set the base I/O address for the diskette controller.
Advanced Chip Set Control		
Address Bit Permuting	Disabled Enabled	Enabled automatically sets two-way or four-way permuting based on the memory configuration. Enabled requires: <ul style="list-style-type: none"> • number of rows to be a power of two. • all rows to be the same size. • all populated rows to be adjacent and start at row 0.
Card to Card Interleave	Disabled Enabled	Enabled requires a symmetric RAM configuration between two memory modules.

continued

Advanced Menu (continued)

Feature	Option	Description
Base RAM Step	1 MB 1 KB Every location	Tests base memory once per MB or once per KB or every location.
Extended RAM Step	1 MB 1 KB Every location	Tests extended memory once per MB or once per KB or every location.
L2 Cache	Disabled Enabled	Enabled causes the secondary cache to be sized and enabled. Disabled causes the L2 cache to be disabled for core clock frequency bus ratios equal to 2.
ISA Expansion Aliasing	Disabled Enabled	Enabled causes every I/O access with an address in the range of x100h-x3FFh, x500h-x7FFh, x900h-xBFFh, and xD00h-xFFFh to be internally aliased to the range 0100h-03FFh before performing any other address range checking.
Memory Scrubbing	Disabled Enabled	Enabled lets the BIOS automatically detect and correct single-bit memory errors.
Restreaming Buffer	Disabled Enabled	When enabled, the data returned and buffered for a delayed inbound read may be reaccessed following a disconnect.
Read Prefetch for PXB0A	16 32 64	Configures the number of "Dwords" that will be prefetched on memory read multiple commands.
Read Prefetch for PXB0B	16 32 64	Configures the number of "Dwords" that will be prefetched on memory read multiple commands.
Read Prefetch for PXB1A	16 32 64	Configures the number of "Dwords" that will be prefetched on memory read multiple commands.
Multiboot Support	Disabled Enabled	Only enable when the total number of bootable devices is less than eight.
Special VGA Devnode	Disabled Enabled	Enable this node only when nonPCI compliant VGA cards need to be debugged. Enabling will impact I/O resources for a large configuration.

Security Menu

Feature	Option	Description
User Password Is	Clear	When you enter your user password, this field automatically changes to set.
Administrator Password Is	Clear	When you enter your administrator password, this field automatically changes to set.
Set User Password	Enter	The user password controls access to the system at boot. To enter a password, press <Enter> and follow the screen prompts.
Set Administrator Password	Enter	The administrator password controls access to the setup utility. To enter a password, press <Enter> and follow the screen prompts.
Password on Boot	Disabled Enabled	Requires password entry before boot. The system remains in the secure mode until you enter the password. Password on Boot takes precedence over Secure Mode Boot.
Diskette Access	User Administrator	Controls access to diskette drives.
Secure Mode Timer	Disabled 1 min 2 min 5 min 10 min 20 min 1 hr 2 hr	Select the time-out period of keyboard or mouse inactivity required before the secure mode activates. (A password must be entered for the secure mode to work.)
Secure Mode Hot Key	[]	Select a hot key, and then press <Ctrl+Alt+(your hot key)> to place the system in the secure mode. The key should not conflict with any application. Available choices are A-Z and 0-9. Press to remove the hot key.
Secure Mode Boot	Disabled Enabled	Enabled lets the system boots in the secure mode. Requires a password to unlock the system.
Video Blanking	Disabled Enabled	Enabled blanks video when the secure mode activates. Requires a password to unlock the system.
Diskette Write Protect	Disabled Enabled	Enabled write protects the diskette drive when the Secure Mode activates. Requires a password to restore the diskette writes.
Front Panel Lockout	Disabled Enabled	Enabled disables the front panel controls when the Secure Mode activates. Requires a password to unlock the system.

Server Menu

Feature	Option	Description
System Management		An additional setup menu for changing server management features.
Firmware SMIs	Disabled Enabled	Disabled turns off all firmware SMI sources.
System Event Logging	Disabled Enabled	Enabled logs critical system events.
Clear Event Log	Disabled Enabled	Enabled cleans the system event log.
Assert NMI on AERR	Disabled Enabled	Enabled generates an NMI. Enabling the Firmware SMIs option is required to assert an NMI.
Assert NMI on BERR	Disabled Enabled	Enabled generates an NMI. Enabling the Firmware SMIs option is required to assert an NMI.
Assert NMI on PERR	Disabled Enabled	Enabled generates an NMI. Enabling the SERR option is required to activate this option.
Assert NMI on SERR	Disabled Enabled	Enabled generates an NMI.
Enable Host Bus Error	Disabled Enabled	Enables host single- and multi-bit errors.
Server Management Information		Displays system serial number, part number, and server management controller revisions. All items on this menu cannot be modified in user mode. If any items require changes, please consult your system administrator.
Board Part Number		Information only.
Board Serial Number		Information only.
System Part Number		Information only.
System Serial Number		Information only.
Chassis Part Number		Information only.
Chassis Serial Number		Information only.
BMC Revision		Information only.
FPC Revision		Information only.
Primary HSBP Revision		Information only.
Secondary HSBP Revision		Information only.
Console Redirection		Additional setup menus to configure the console.
COM Port Address	Disabled 3F8 2F8 3E8	Select the port address. Make sure these values are identical to those of serial ports A and B in the peripheral configuration setup menu.
IRQ #	None	

continued

Server Menu (continued)

Feature	Option	Description
Baud Rate	9600 19.2 K 38.4 K 115.2 K	Select the baud rate.
Flow Control	No Flow Control CTS/RTS XON/XOFF CTS/RTS + CD	Select the flow control. <ul style="list-style-type: none"> • CTS/RTS = Hardware • XON/XOFF = Software • CTS/RTS + CD = Hardware + carrier detect for modem use.
Processor Retest	No Yes	Yes causes the BIOS to clear historical processor status and retest all processors on the next boot.
EMP Password Switch	Disabled Enabled	Enable or disable the EMP password.
EMP ESC Sequence		The front panel controller firmware updates this field.
EMP Hangup Line String		The front panel controller firmware updates this field.
Modem Init String		This string accepts up to 16 characters. The upper four characters will go to the next field which will pop up as soon as the 16th character is filled. Trying to fill the 17th character in the same field will have a wraparound problem.
EMP Access Mode	Preboot Only Always Active Disabled	Preboot Only—EMP enabled during power down or POST. Always Active—EMP always enabled. Disabled—EMP disabled.
EMP Restricted Mode Access	Disabled Enabled	When enabled, power down, front panel NMI, and reset control via EMP are disabled. Restricted mode can be selected with preboot or always active.
EMP Direct Connect/Modem Mode	Direct Connect Modem Mode	You can connect directly to the port or use a modem.

Boot Menu

Feature	Option	Description
Diskette Check:	Disabled Enabled	Enabled verifies the diskette type on boot. Disabled speeds up the boot process.
Boot Device Priority		Select the search order for the types of boot devices.
	<ol style="list-style-type: none"> 1. Diskette Drive 2. Removable Devices 3. Hard Drive 4. ATAPI CD-ROM Drive 	Use the up and down arrow keys to select a device. Press <+> to move it up the list, and press <-> to move it down the list. Press <Esc> to exit this menu.
Hard Drive		The system attempts to boot to the OS from the first hard drive in this list. If it does not find an OS, the system tries the next drive listed until it finds an OS. Use the up and down arrow keys to select a device. Press <+> to move it up the list, and press <-> to move it down the list. Press <Esc> to exit this menu.
Removable Devices		The OS assigns drive letters to these devices in the order displayed. Change the sequence and the drive lettering of a device by selecting it with the up and down arrow keys. Press <+> to move it up the list, and press <-> to move it down the list. Press <Esc> to exit this menu.
Maximum Number of I20 Drives	1 4	Selects the maximum number of I20 drives that will be assigned a DOS drive letter.
Message Timeout Multiplier	1 2 4 8 10 50 100 1000	All timeout values will be multiplied by this number.
Pause During Post	Disabled Enabled	Select enabled when you need to start the IRTOS manually. When you hear three beeps, POST has stopped. Press any key to continue.

Exit Menu Selections

The following menu options are available on the Server menu. Select an option by using the up or down arrow keys. Then press <Enter> to execute the option, and follow the prompts.

Option	Description
Exit Saving Changes	Exit Setup and save your changes to CMOS.
Exit Discarding Changes	Exit Setup without saving data to CMOS.
Load Setup Defaults	Load default values for all Setup items.
Load Custom Defaults	Load settings from custom defaults.
Save Custom Defaults	Save changes to custom defaults. Normally PhoenixBios reads setup settings from CMOS. However, if CMOS fails, it uses custom defaults—if you have set them. If not, it uses factory defaults.
Discard Changes	Load previous values from CMOS for all Setup items.
Save Changes	Save Setup data to CMOS.

5 System Setup Utility: When to Run

The System Setup Utility (SSU) is on the Server System Configuration Software CD shipped with the server. The SSU provides a graphical user interface (GUI) over an extensible framework for server configuration. For the AC450NX systems, the SSU framework supports the following functions and capabilities:

- assigns resources to baseboard devices and add-in cards prior to loading the operating system (OS)
- allows you to specify boot device order and system security options
- permits viewing and clearing of the system's critical event log
- Permits viewing of the system FRU and SDRs
- allows troubleshooting of the server when the OS is not operational
- provides a system level view of the server's I/O devices

When to Run the System Setup Utility

The SSU is a DOS-based utility that supports extended system configuration operations for onboard resources and add-in boards. The utility also allows you to view the system event log (SEL) and to set system boot and security options. Use the SSU when you need to:

- add and remove boards affecting the assignment of resources (ports, memory, IRQs, DMA)
- modify the server's boot device order or security settings
- change the server configuration settings
- save and restore the server configuration
- view or clear the SEL
- view FRU information
- view the SDR table

If you install or remove an ISA add-in board, you must run the SSU to reconfigure the server. Running the SSU is optional for a PCI and ISA Plug and Play add-in boards.

The SSU is PCI-aware, and it complies with the ISA Plug and Play specifications. The SSU works with any compliant configuration (.CFG) file supplied by the peripheral device manufacturer.

The I/O baseboard comes with a .CFG file. The .CFG file describes the characteristics of the board and the system resources that it requires. The configuration registers on PCI and ISA Plug and Play add-in boards contain the same type of information that is in a .CFG file. Some ISA boards also come with a .CFG file.

The SSU uses the information provided by .CFG files, configuration registers, flash memory, and the information that you enter, to specify a system configuration. The SSU writes the configuration information to flash memory.

The SSU stores configuration values in flash memory. These values take effect when you boot the server. POST checks the values against the actual hardware configuration; if they do not agree, POST generates an error message. You must then run the SSU to specify the correct configuration before the server boots.

The SSU always includes a checksum with the configuration data so that the BIOS can detect any potential data corruption before the actual hardware configuration takes place.

What You Need to Do

The SSU may be run directly from the Server Configuration Software CD or from a set of DOS diskettes. If you choose to run the SSU from a set of diskettes, you must copy the SSU from the Server Configuration Software CD to diskettes and follow the instructions in the README.TXT of diskette one. See Chapter 2, “On-site Installation: Installing the Server,” to create a set of SSU diskettes. Only diskette one of the set must be DOS bootable.

⇒ NOTE

If your diskette drive is disabled, or improperly configured, you must use the flash-resident Setup utility to enable it so that you can use the SSU. If necessary, you can disable the drive after you exit the SSU. Information entered using the SSU overrides any entered using Setup.

Running the SSU

- **Running the SSU Locally**

Running the ssu.bat file provided on the SSU media starts the SSU. If the server boots directly from the SSU media, the ssu.bat file runs automatically. If it boots from a different media, the SSU can be started manually or by another application. When the SSU starts in the local execution mode (the default mode), the SSU accepts input from the keyboard and/or mouse. The SSU presents a VGA-based Graphical User Interface (GUI) on the primary monitor.

The SSU runs from writable, nonwritable, removable, and nonremovable media. If you run the SSU from nonwritable media, all your preference settings will be lost because you cannot save them.

The SSU supports the ROM-DOS V6.22 operating system. It can run on other ROM-DOS compatible operating systems but they are not supported. The SSU will not operate from a DOS-box running under an operating system such as Windows.

- **Running the SSU Remotely**

To run the SSU remotely, you must invoke the SSU.BAT file with the /t switch and redirect the text-mode output via BIOS console redirection. The /t switch puts the display in text mode and allows the console to be viewed and controlled via BIOS console redirection.

First, configure the server for BIOS console redirection. Then configure the modem to auto-answer and to “modem reaction to DTR set to return to command state.” After configuring the server, it should be booted to a DOS prompt either locally or remotely through the EMP. Once the server boots, the remote user can use any ANSI terminal emulation program to connect to the configured COM port and invoke SSU /t. This process requires a bootable DOS partition, and all files required for the SSU to run must be on the server.

Starting the SSU

The SSU consists of a collection of task-oriented modules plugged into a common framework called the Application Framework (AF). The AF provides a launching point for individual tasks and a location for setting customization information.

1. Turn on your video monitor and your system.
2. There are two ways to start the SSU.
 - a. **From a set of SSU diskettes created from the CD:** Insert SSU diskette 1 in drive A, and press the push-button reset switch or <Ctrl+Alt+Del> to reboot your server from the diskette. Follow the screen prompts.
 - b. **From the Server Configuration Software CD:** Insert the CD into your CD-ROM drive, and press the reset switch on the front panel or <Ctrl+Alt+Del> to reboot the server.
 - When prompted, press <F2> to enter BIOS Setup.
 - From the Boot Menu, select the Boot Device Priority option, and then select the CD-ROM drive as your primary boot device.
 - Press <F10> to save the new settings.
 - Press <Enter> to exit BIOS Setup and boot from the CD.
 - From the CD menu, select Run Utilities and press <Enter>.
 - Select Run System Setup Utility, and press <Enter>. Follow the screen prompts.
 If you boot from the CD, skip to step 4.
3. The mouse driver loads if it is available; press <Enter> to continue.
4. When the main window of the SSU appears, you can customize the user interface before continuing.

Customizing the SSU

The SSU lets you customize the user interface according to your preferences. The AF sets these preferences and saves them in the AF.INI file so that they take effect the next time you start the SSU. There are four user-customizable settings.

⇒ NOTE

If you run the SSU from nonwritable media like a CD, these preferences will be lost when you exit the SSU.

- **Color**—this button lets you change the default colors associated with different items on the screen with predefined color combinations. The color changes are instantaneous.
- **Mode**—this button lets you set the desired expertise level.
 - novice
 - intermediate
 - expert

The expertise level determines which tasks are visible in the Available Tasks section and what actions each task performs. For a new mode setting to take effect, the user must exit the SSU and restart it.

- **Language**—this button lets you change the strings in the SSU to strings of the appropriate language. For a new language setting to take effect, you must exit the SSU and restart it.
- **Other**—this button lets you change other miscellaneous options in the SSU. The changes are instantaneous.

To change the interface default values:

Use the mouse to click on the proper button in the Preferences section of the SSU Main window.

or

Use the tab and arrow keys to highlight the desired button, and press the spacebar or <Enter>.

or

Access the menu bar with the mouse or hot keys (Alt + underlined letter).

Launching a Task

It is possible to have many tasks open at the same time, although some tasks may require complete control to avoid possible conflicts. The tasks achieve complete control by keeping the task as the center of operation until you close the task window.

To launch a task:

1. In the SSU Main window, double-click on the task name under Available Tasks to display the main window for the selected task.

or

Highlight the task name, and click on OK.

or

Use the tab and arrow keys to highlight the task name, and press the <spacebar> or <Enter>.




Figure 5-1. System Setup Utility Main Window

Resource Configuration Add-in (RCA) Window

The RCA provides three major functions:

- Creates representations of devices that cannot be discovered by the system (ISA cards)
- Modifies the contents of the system by adding and removing devices
- Modifies the resources used by devices

You can use the RCA window to define an ISA card or add an ISA card by clicking on the appropriate button. Removing an ISA card requires that the card be highlighted in the Devices section of the screen before clicking on the button.

⇒ NOTE

You can only add as many ISA cards as you have available ISA slots in the server.

1. From the SSU main window, launch the RCA by selecting the Resources task under the RCA heading in the task box.
2. When the RCA window appears, it displays messages similar to the following:

```
Baseboard: System Board
PCI Card: Bus 00 dev 00 -- Host Processor Bridge
PCI Card: Bus 00 dev 0D -- SCSI Controller
PCI Card: Bus 00 dev 0F -- Ethernet Controller
PCI Card: Bus 00 dev 12 -- Multifunction Controller
PCI Card: Bus 00 dev 14 -- VGA Controller
```
3. To configure a device, select its name in the Devices section of the RCA window, and press the spacebar or <Enter>, or double-click on the name.
4. It is possible to close the RCA window and return to the AF by clicking on the Back to AF button. Any changes made will be kept in memory for use by the RCA when it is rerun.
5. Save all the changes made by clicking on the Save button. Saving writes your current configuration to nonvolatile storage where it will be available to the system after every reboot.
6. Closing the window by clicking on the system menu—the dash in the upper-left corner—discards all changes.




Figure 5-2. RCA Window

Defining an ISA Card

An ISA card usually comes with a vendor-created .CFG file that specifies the resources the card requires to function properly. If the .CFG file is unavailable, you must manually create it or define the card through the SSU. Defining an ISA card consists of specifying the name of the card and the resources it consumes. This allows the RCA to consider the ISA card resource requirements when the RCA tries to resolve conflicts. The system BIOS also uses the information to configure the hardware when the system boots.

1. To add or remove ISA card resources, click on the appropriate resource buttons, select the desired value, and click on Add or Remove.
2. After you complete the necessary information, click on Save.
3. To edit a card, click on Load to retrieve the card information. After making changes, click on Save.
4. To create a card, click on New.
5. To remove a current definition of a card, click on Delete.




Figure 5-3. Define ISA Window

Adding and Removing ISA Cards

Adding and removing cards through the RCA provides a way for the RCA to run its conflict detection algorithms on the resources requested by the cards. This alerts you to any possible problems with that particular card in the current configuration.

- **To add an ISA card:**
 1. Click on Add ISA Card in the RCA window.
 2. Specify the directory for the .CFG file.
 3. Select the file and click on Ok.
- **To remove an ISA card:**
 1. Select a valid ISA card in the Devices section of the RCA window.
 2. Click on Remove ISA Card.

Modifying Resources

Modifying the resources of a device may be necessary to accommodate certain operating systems, applications, and drivers. It may also be necessary to modify resources to resolve a conflict.

- **To modify the resources associated with a device:**
 1. Highlight the device in the Devices section of the RCA window.
 2. Press the spacebar or <Enter>, or double-click on the entry.
This displays the functions of the selected device along with possible choices and the resources associated with those choices.
- **To make a modification:**
 1. Highlight the function in the Configuration window.
 2. Press the spacebar or <Enter>, or double-click on the entry (this updates the Choice and resource lists).
 3. Press the tab key to get to the Choice list, and press <Enter>.
 4. Use the arrow keys to select a proper choice, and press <Enter> again.
 5. If the choice allows multiple possible values for a particular resource, use the hot key to select a resource, and press the spacebar or double-click on the resource.
 6. Select the desired resource, and click on Ok.




Figure 5-4. Configuration Window

System Resource Usage

Clicking on the Resource Use button in the Configuration window displays the System Resource Usage window. This window shows what resources each device is consuming. This information is useful for choosing resources if a conflict occurs. Devices can be organized according to the resources you want to examine using the options in the Resource section of the screen. The resource information can also be written to a plain text file through this window.




Figure 5-5. System Resource Usage Window

Multiboot Add-in

The Multiboot Add-in (MBA) provides an interface for selecting Initial Program Load (IPL) devices. Using the MBA, you can identify all IPL devices in the system and prioritize their boot order. On power-up, the BIOS sequentially attempts to boot from each device.

To change the boot device priority:

1. Click on the device to select it.
2. Click on the Move Up button to move the device up.
3. Click on Move Down button to move the device down.
4. Click on the Save button to save the boot order in the system nonvolatile storage.




Figure 5-6. Multiboot Main Window

Security Add-in

The Security Add-in (PWA) provides security and password support options. Within the PWA, you can either set or modify the User and Administrator passwords or update any of the various security options available.

To Set the User Password

1. Click on the user password button.
2. Enter the password in the first field.
3. Verify the password by entering it again in the second field.

To Change or Clear the User Password

1. Click on the User password button.
2. Enter the old password in the first field.
3. Enter the new password in the second field or leave it blank to clear the password.
4. Verify the password by entering it again in the second field or leave it blank to clear the password.

To Set the Administrator Password

1. Click on the Administrator password button.
2. Enter the password in the first field.
3. Verify the password by entering it again in the second field.

To Change or Clear the Administrator Password

1. Click on the Administrator password button.
2. Enter the old password in the first field.
3. Enter the new password in the second field or leave it blank to clear the password.
4. Verify the password by entering it again in the second field or leave it blank to clear the password.

Security Options

Under this window, you can set the other security options:

- **Hot Key**—set a key sequence that, when pressed, will drop the server into secure mode.
- **Lock-Out Timer**—set an interval that, if no activity takes place during it, will drop the server into secure mode.
- **Secure Boot Mode**—force the server to boot directly into secure mode.
- **Video Blanking**—turn off the video when the server is in secure mode.
- **Floppy Write**—control access to the diskette drive while the server is in secure mode.
- **Front Panel Lockout**—control the power and reset buttons while the server is in secure mode.




Figure 5-7. Password Main Window

System Event Log Manager Add-in

Clicking on the SEL Manger add-in task brings up the SEL Manager window. It lets you examine SEL records:

- via the Baseboard Management Controller (BMC) in hex or verbose mode
- by sensor type or event type in hex or verbose mode
- from a previously stored binary file in hex or verbose mode

The SEL Manager window also lets you:

- save the SEL records to a file in either text or binary form
- clear the SEL entries from the nonvolatile storage area

SEL Manager Menus	Click on	to
File	Load SEL	view data from a previously saved SEL file
	Save SEL	save the currently loaded SEL data to a file
	Clear SEL	clear the SEL data from the BMC
	Exit	quit the SEL Viewer
View	SEL Info	display information about the SEL (these fields are display only)
	All Events	display the current SEL data from the BMC
	By Sensor	bring up a pop-up menu that allows you to load only the data from a certain sensor type
	By Event	bring up a pop-up menu that allows you to load only the data from a certain event type
	View Realtime	
Settings	Display HEX	toggle between the Hex/interpreted mode of displaying the SEL records
	Display Verbose	
	Output Binary	determine whether SEL data will be saved to the file (as under File - Save) in binary format or verbose format
	Output Text	
Help	About	display the SEL Viewer version information

The screenshot shows the 'System Setup Utility' window with the 'SEL Manager' tab selected. The window has a menu bar with 'File', 'View', 'Settings', and 'Help'. Below the menu bar is a table with two columns: 'Time Stamp' and 'Event Description'. The table contains 15 rows of event data. The first 14 rows have a 'Pre-Init Timestamp' and describe 'Lower Critical - going low Trigger Reading' events with various hex values. The 15th row has a timestamp of '04/15/98 - 13:18:41' and describes an 'Upper Non-critical - going high Trigger Reading' event. The window has a scrollbar on the right and a status bar at the bottom.

Time Stamp	Event Description
Pre-Init Timestamp	Lower Critical - going low Trigger Reading = 0x0001 Tri
Pre-Init Timestamp	Lower Critical - going low Trigger Reading = 0x0000 Tri
Pre-Init Timestamp	Lower Critical - going low Trigger Reading = 0x0007 Tri
Pre-Init Timestamp	Lower Critical - going low Trigger Reading = 0x0000 Tri
Pre-Init Timestamp	Lower Critical - going low Trigger Reading = 0x0001 Tri
Pre-Init Timestamp	Front Panel NMI OEM Or Unspecified (0x1D)
Pre-Init Timestamp	Lower Critical - going low Trigger Reading = 0x0000 Tri
Pre-Init Timestamp	Lower Critical - going low Trigger Reading = 0x0013 Tri
Pre-Init Timestamp	Lower Critical - going low Trigger Reading = 0x0000 Tri
04/15/98 - 13:18:41	Upper Non-critical - going high Trigger Reading = 0x00B
Pre-Init Timestamp	Lower Critical - going low Trigger Reading = 0x0001 Tri
Pre-Init Timestamp	Lower Critical - going low Trigger Reading = 0x0000 Tri

Figure 5-8. System Event Log Main Window

Sensor Data Record (SDR) Manager Add-In

In this window, you can:

- Examine all SDR records through the BMC (in either Hex or Verbose mode)
- Examine SDR records by Record type (in either Hex or Verbose mode)
- Examine SDR records from a previously stored binary file (in either Hex or Verbose mode)
- Save the SDR records to a file (in either text or binary form)

The SDR Manager can display SDR records in either raw form (hexadecimal) or in an interpreted, easy-to-understand textual form (verbose).

The SDR Manager's main window provides access to features of the add-in through menus. Each option included on the main menu supports an accelerator key. Accelerator keys are indicated by an underlined letter in the text listing the option.

Menu	Click On	To
File	Open FRU Save SDR Exit	Opens FRU data from a previously saved file Saves SDR data to a file in binary raw or verbose text format Quits the SDR Manager
View	SDR Info All Records By Record	Displays SDR information as returned by the GetSDRInfo interface of the BMC Displays all records in the SDR repository Displays all records in the SDR repository, sorted by record type
Settings	Display HEX Display Verbose Output Text Output Binary	Displays SDR records in Hex format Displays SDR records in verbose format Saves SDR data in verbose format Saves SDR data in binary format
Help	About	Displays SDR Manager version information




Figure 5-9. SDR Manager Main Window

Field Replaceable Unit (FRU) Manager

In this window you can:

- Examine all FRU Inventory areas on the server (in either Hex or Verbose mode)
- Examine individual FRU Inventory areas (in either Hex or Verbose mode)
- Examine FRU Inventory areas from a previously stored binary file (in either Hex or Verbose mode)
- Save the FRU Inventory areas to a file (in either text or binary form)

The FRU Manager can display the FRU Inventory areas in either raw form (hexadecimal) or in an interpreted, easy-to-understand textual form (verbose). The FRU manager's main window provides access to features of the add-in through menus. Each option included on the main menu supports an accelerator key. Accelerator keys are indicated by an underlined letter in the text listing the option.

Menu	Click On	To
File	Open FRU Save FRU Exit	Opens FRU data from a previously saved file Saves FRU data to a file in binary raw or verbose text format Quits the FRU Manager
View	FRU Info All FRU Areas By Device Type	Displays FRU information of the selected device Displays FRU areas of all devices Displays FRU areas sorted by device type
Settings	Display HEX Display Verbose Output Text Output Binary	Displays FRU areas in Hex format Displays FRU areas in verbose format Saves FRU data in verbose format Saves FRU data in binary format
Help	About	Displays FRU Manager version information




Figure 5-10. FRU Manager Main Window

Exiting the SSU

Exiting the SSU causes all windows to close.

1. Exit the SSU by opening the menu bar item File in the SSU Main window. See “System Setup Utility Main Window” on page 61.
2. Click on Exit.
or
Highlight Exit, and press <Enter>.

6 SCSI Configuration Utility

The SCSI configuration utility allows you to configure/view the settings of the host adapters and devices in the server. For information about the SCSI Configuration Utility refer to the *PCI SCSI Device Manager System Users Guide*.

7 Emergency Management Port Console: How to Use

The Emergency Management Port (EMP) Console provides an interface to the Emergency Management Port (EMP). This interface allows remote server management via a modem or direct connection.

The server control operations available with EMP Console are:

- Connecting to remote servers
- Powering the server on or off
- Resetting the server

The EMP Console uses three management plug-ins to monitor the server:

- SEL Viewer (*not available on AC450NX servers*)
- SDR Viewer (*not available on AC450NX servers*)
- FRU Viewer

The EMP Console also has a Phonebook plug-in that can be used to create and maintain a list of servers and their phone numbers.

How EMP Console Works

The EMP shares use of the COM 2 port with the system on the server. When the EMP has control of the port, the port operates in command mode. When the system has control, the port operates in console redirect mode. When connecting to a server, the EMP Console checks to determine the mode of the COM 2 port. The following discussion covers how EMP Console functions in each mode:

- *Command mode* is the default COM 2 state. In this state, EMP Console communicates with the server's firmware, allowing the client to remotely reset or power the server up or down. The client can also view the server's System Event Log (SEL), Field Replaceable Unit (FRU) information, or Sensor Data Record (SDR) table.
- In *console redirect mode*, EMP Console serves as a PC ANSI terminal window for BIOS console redirection. Commands typed in this terminal window are transmitted through BIOS to the server's console, and text displayed on the server console is displayed on the EMP Console's terminal window. In this mode, you can remotely view boot messages, access BIOS setup, and run DOS text mode applications through the EMP Console's terminal window.




Figure 7-1. EMP Console in Command State




Figure 7-2. EMP Console in Redirect State

Figure 7-2 shows the EMP Console window in redirect mode with the terminal window. The text that appears on the server monitor displays in the Redirect window.

Availability of the various EMP Console features are determined by two factors: the BIOS EMP access mode and whether the server's COM 2 port is configured for console redirection. The three EMP access modes are: disabled, pre-boot, and always active.

Table 7-1. EMP Console Access Modes (Server configured for console redirection)

Mode	Server is powered off	During POST	After OS boots
Disabled	Redirect window appears, but is blank	Redirect window	Redirect window
Pre-boot	EMP commands available	Redirect window*	Redirect window
Always Active	EMP commands available	Redirect window*	EMP commands available

* The operation mode can be modified by selections in the Reset and Power on/off dialogs. These are server control dialogs available in EMP Console.

Table 7-2. EMP Console Access Modes (Server not configured for console redirection)

Mode	Server is powered off	During POST	After OS boots
Disabled	Redirect window appears, but is blank	Redirect window appears, but is blank	Redirect window appears, but is blank
Pre-boot	EMP commands available	EMP commands available	Redirect window appears, but is blank
Always Active	EMP commands available	EMP commands available	EMP commands available

Requirements

This section outlines the requirements and configurations necessary for using EMP Console.

Operating Systems:

- Windows 95
 - 16 MB of RAM, 32 MB recommended
 - 20 MB disk space
- Windows NT†
 - Windows NT 4.0
 - 24 MB of RAM, 32 MB recommended
 - 20 MB disk space

Client Configuration: EMP Console supports all COM ports on the client system, along with any Windows NT/95 compatible modem.

Server Configuration: EMP Console requires the server's COM 2 port to be connected to an external modem or directly connected to a serial cable.

Direct Connect Configuration: A null modem serial cable is needed. Connect one end of the cable to the COM 2 port of server and the other to a port on the client machine.

Modem Configuration: On the client, EMP Console uses the Windows Application Program Interface (API) to determine if a modem is connected and available. The EMP Console does not configure the modem; it should be preconfigured through Windows.

For modem support, the server must use a Hayes compatible modem that supports a baud rate of 19.2k. The modem must be on the NT Hardware Compatibility List provided by Microsoft. The server modem must be set in auto-answer mode for EMP Console to be able to connect to it.

Setting Up the Server for the EMP

To use the EMP, you must configure the server's BIOS with specific settings. These settings are found in the BIOS Server menu and the Console Redirection submenu. The BIOS settings section, found earlier in this document, shows all the available options. This section focuses on the settings that must be configured in order to use the EMP.

Server Menu

All EMP related settings occur in the Server main menu. Change only the items below; all other default settings should remain the same.

EMP Password Switch & EMP Password: Anytime an attempt to initiate a connection is made, a prompt for the user password appears. If no EMP password is setup, then anyone can access the EMP by clicking OK.

In the EMP Password area of the Server menu, the EMP Password Switch option must be set to enable. Then type in a password of up to eight alphanumeric characters. If a beep is heard, the password was accepted.

EMP Access Modes: Choose either Disabled, Pre-boot, or Always Active, depending on the type of EMP access needed. The tables above show what is available with a given setting.

EMP Restricted Mode Access: Set Restricted Mode to either enabled or disabled as needed. If in enabled mode, this means that EMP Console's server control options, Power off and Reset, are unavailable, except power on. In disabled mode, these same server control options are available.

EMP Direct Connect/Modem Mode: Select Direct Connect if a null modem serial cable directly connects the server's COM 2 port to the EMP Console client machine. If they are connected via a modem, select Modem Mode.

Console Redirection Submenu

The settings in the Console Redirection Submenu of the Server menu must be set exactly as noted to be able to use the EMP.

COM Port Address: Select 2F8. This is the COM 2 port that must be used by the EMP. The IRQ# setting is automatically populated with the correct number based on the COM Port Address choice.

Baud Rate: Select 19.2k.

Flow Control: Select CTS/RTS + CD.

Main EMP Console Window

The main EMP Console window provides a graphical user interface (GUI) to access server control operations and to launch the management plug-ins. At the top of the window is the menu and tool bar. These provide the options to initiate plug-ins and other support features. A status bar at the bottom displays connection information such as server name, line status, and mode.

Toolbar

The tool bar buttons of the EMP Console main window combine server control and management plug-in commands available from both the Connect and Action menus as follows:

	Displays the Connect dialog to allow connection to a selected server.
	Disconnects from the currently connected server.
	Displays the Power On/Off dialog.
	Displays the Reset dialog.
	Launches the SEL Viewer. <i>(not available on AC450NX servers)</i>
	Launches the SDR Viewer. <i>(not available on AC450NX servers)</i>
	Launches the FRU Viewer.
	Displays the Phonebook Dialog.
	Displays the online help.

Status Bar

The status bar is displayed at the bottom of the main window. It contains the following status information:

- **SERVER NAME:** the name of the connected server when connecting via modem.
- **LINE:** the type of line connection. This is either direct or modem.
- **MODE:** either Redirect of EMP, depending on whether the EMP has control of the COM 2 port.
- **LINE STATUS:** gives status information about the server connection. For example, if a server is connected, the status bar says "Connected." Otherwise, the line is blank.

EMP Console Main Menu

- **File**
 - **Exit** - Exits EMP Console
- **Connect**
 - **Disconnect** - disconnects the server connection.
 - **[Re]Connect** - displays the connect dialog.
 - A list of the five most recent modem connections. Click on one of these server names to initiate a connection.
- **Action**
 - **Power On/Off** - displays the Power on/off dialog.
 - **Reset** - displays the Reset dialog.
 - **SEL Viewer** - displays the SEL Viewer. *(not available on AC450NX servers)*
 - **SDR Viewer** - displays the SDR Viewer. *(not available on AC450NX servers)*
 - **FRU Viewer** - displays the FRU Viewer.
 - **Phonebook** - displays the Phonebook dialog.
- **Help**
 - **Help Topics** - help topics for EMP Console.
 - **Help About** - provides version information.

Server Control Operations

Three server control operations are available from the menu or toolbar in EMP Console: remote server connection, powering the server on and off, and resetting the server. The server console mode can also be switched between EMP active and BIOS redirect modes through post-power-up and reset options.

Connect

When [Re]Connect is selected from the Connect menu, the Connect dialog in Figure 7-3 is displayed. This dialog allows you to connect to a server. If the client machine is already connected to a server, initiating connection generates a warning message. The message indicates that the existing connection will be terminated if you continue trying to initiate the new connection. You are prompted to enter the EMP password whenever a connection is attempted.




Figure 7-3. Connect Dialog

Options available in the dialog are:

- **Line Selection** - you can specify whether to use a direct connection or dial-up modem connection to the server.
 - **Dial-up** - connects to a selected server with a modem.
 - **Direct connect (Serial Line)** - connects to the selected server directly using a null modem serial cable.
- **Server** - a server name can be selected from the dropdown list of available servers. A server must be selected when the line selection is Dial-up.
- **Serial Line** - These options are enabled when the line selection is set to Direct connect (Serial Line).
 - **Baud Rate** - must be 19200 for EMP to connect properly.
 - **COM Port No.** - set the COM Port number to the port which the null modem serial cable is connected to.
- **Connect** - initiates the connection to the connected server. When this button is clicked, you are prompted for the EMP password.

- **Config** - displays the Phonebook dialog.
- **Cancel** - exits the Connect dialog without taking any action.
- **Help** - displays the help information for this dialog.

Power On/Off

Selecting Power On/Off from the Action menu displays the Power on/off dialog. This dialog provides commands to remotely power on or power off the server.




Figure 7-4. Power On/Off Dialog

Options available in the dialog are:

- **Power ON** - powers on the server.
- **Power OFF** - powers off the server. This option is not allowed if the server is configured in RESTRICTED mode for EMP operations.
- **Post-power-up option** - sets the mode selection of the server to EMP active or BIOS redirection. The setting is available after the next power-up. The default selection is EMP active.
- **Cancel** - exits the Connect dialog without taking any action.
- **Help** - displays the help information for this dialog.

Reset

Selecting Reset from the Action menu displays the Reset dialog. This dialog provides the ability to remotely reset the server with post-reset options.




Figure 7-5. Reset Dialog

Options available in the dialog are:

- **System Reset** - resets the server with the selected post-reset options. This operation is not allowed if the server is configured in RESTRICTED mode for EMP operations.
- **Post-reset option** - sets the post-reset option that will be in effect after reset. The options are EMP active or BIOS redirection. The default selection is EMP active.
- **Cancel** - exits the Connect dialog without taking any action.
- **Help** - displays the help information for this dialog.

Phonebook

EMP Console provides a support plug-in known as Phonebook. It stores names and numbers of servers in a list that can be updated by adding, modifying or deleting entries. Phonebook can be opened from the main menu and toolbar, or launched from the Connect dialog by clicking the Config button.




Figure 7-6. Phonebook Dialog

Options available in the dialog are:

- **Server** - a dropdown list of server names stored in Phonebook. If the New radio button is selected in the Operation area, this area is cleared.
- **Phone No.** - the number of the selected server. If the New radio button is selected in the Operation area, this area is cleared.
- **Operation**
 - **New** - lets you add a new entry in the Phonebook. Selecting this option clears the Server and Phone No. fields. You must click Save for the entry to be added to the Phonebook.
 - **Modify** - lets you edit an existing entry. You must select an existing entry from the Server dropdown list box and modify the existing phone number before selecting this option. Click Save in order to update the entry in the phonebook.
 - **Delete** - lets you delete an entry from the Phonebook. You must first select an existing server from the Server dropdown list box before selecting this option. You must click Save for the entry to be deleted.
- **Save** - saves a new or modified Phonebook entry, or deletes an entry if the Delete radio button is selected.
- **Connect** - displays the Connect dialog with the server from the Phonebook's Server dropdown list box already populating the Connect dialog's Server field.
- **Cancel** - exits the Connect dialog without taking any action.
- **Help** - displays the help information for this dialog.

FRU Viewer

The FRU Viewer allows you to view the server's FRU (Field Replaceable Unit) data from the server's Front Panel FRU information area. The options available in the FRU Viewer are:

- View all FRU records
- View FRU summary info
- Set FRU display mode to either Hex or verbose mode
- Close the FRU Viewer
- Exit EMP Console

FRU Viewer Menu Options

The following menu options are found on the FRU Viewer menu bar:

- **File**
 - **Close** - closes the FRU Viewer.
 - **Exit** - exits EMP Console.
- **View**
 - **Display all Records** - displays all FRU data, which consists of chassis, board, and product information.
 - **FRU Info** - displays the FRU summary information as returned by the server.
- **Settings** - lets you change operating parameters for the FRU Viewer. This menu displays the following options:
 - **Display HEX/Verbose** - toggles between HEX mode and interpreted mode of displaying FRU records.
- **Window** - gives options for displaying currently open windows.
- **Help**
 - **Help Topics** - help topics for EMP Console.
 - **Help About** - provides version information.

8 FRU and SDR Load Utility: When to Run

The Field Replacement Unit (FRU) and Sensor Data Record (SDR) Load Utility is a DOS based program used to update the server management subsystem's product level FRU, SDR, and the Desktop Management Interface (DMI) nonvolatile storage components (EEPROMs). The load utility:

- discovers the product configuration based on instructions in a master configuration file
- displays the FRU information (it may have values the user can change)
- updates the nonvolatile storage device (EEPROM) associated with the Baseboard Management Controller (BMC) that holds the SDR and FRU area
- updates the DMI area located in the BIOS nonvolatile storage device
- generically handles FRU devices that may not be associated with the BMC

When to Run the FRUSDR Load Utility

The FRUSDR Load Utility can be used to:

- Read the system FRU and SDR information.
- Load the FRU information using the configuration file.
- Update the sensor data records after adding or removing processors in your server. It programs the sensors that need to be monitored for server management.
- Enter the Asset Tag after upgrade/replacement of the PHP I/O baseboard.

The server must be rebooted to properly initialize the sensors after programming the Sensor Data Records. To do this, turn the server off and disconnect the AC power cords from the server power supplies. Wait approximately 30 seconds, reconnect the power cords, and turn the server on.

What You Need to Do

The FRUSDR Load Utility may be run directly from the Configuration Software CD or from diskettes you create from the CD. Before you can run the FRUSDR Load Utility from a diskette, you must copy the utility from the Server Configuration Software CD to a DOS-bootable diskette. See Chapter 2, "On-site Installation: Installing the Server," to create an FRUSDR Load Utility diskette.

⇒ NOTE

If your diskette drive is disabled, or improperly configured, you must use BIOS Setup to enable it. If necessary, you can disable the drive after you are done with the FRUSDR utility.

How You Use the FRUSDR Load Utility

This utility is compatible with ROM-DOS Ver. 6.22, MS-DOS Ver. 6.22, and later versions. The utility accepts CFG, SDR and FRU load files. The executable file for the utility is frusdr.exe. The utility requires the following supporting files:

- one or more .fru files describing the system's field replaceable units
- a .cfg file describing the system configuration
- a .sdr file describing the sensors in the system

Command Line Format

The basic command line format is:

```
frusdr [-?] [-h] [-d {dmi, fru, sdr}] [-cfg filename.cfg] -p -v
```

Command	Description
frusdr	Is the name of the utility.
-? or -h	Displays usage information.
-d {dmi, fru, sdr}	Only displays requested area.
-cfg filename.cfg	Uses custom CFG file.
-p	Pause between blocks of data.
-v	Verbose, display any additional details.

Parsing the Command Line

The FRUSDR Load Utility allows only one command line function at a time. A command line function may consist of two parameters; for example, -cfg filename.cfg. Any invalid parameters result in displaying an error message and exiting the program. You can use either a slash (/) or a minus sign (-) to specify command line options. The -p and -v options may be used in conjunction with any of the other options.

Displaying Usage Information

When the utility is run with the -? or -h command line flags, the following message is displayed when the verbose flag -v is added to the help command:

```
FRU & SDR Load Utility Version 2.0
```

```
Usage:  frusdr                Is the name of the utility.
        -? Or -h              Displays usage information.
        -d {dmi,fru,sdr}     Only displays requested area.
        -cfg filename.cfg    Uses custom CFG file.
        -p                    Pause between blocks of data.
        -v                    Verbose, display any additional details.
```

Copyright (c) 1998, Intel Corporation, All Rights Reserved

This utility must be run from a system executing DOS. Running in a Window's DOS box is insufficient and will provide incorrect results. Programming the BMC FRU area clears the SDR table, therefore the SDR table must be reprogrammed. Upon completing the programming of the FRU and SDR areas, the server should be rebooted.

Note: DOS users may alternatively use a '/' instead of the '-'.

The following information is display if -v option is included in the command line.

The /D FRU command may be followed with up to 16 device addresses. These device addresses are used to view up to 16 different FRU areas, instead of the default of displaying the BMC FRU. The arguments following the "-d FRU" are in the same order and value as the NVS_TYPE, NVS_LUN, DEV_BUS and DEV_ADDRESS which are found in the FRU file header in each FRU file. The LUN address is optional. If the LUN address is used, it must start with an 'L'.

Usage: FRUSDR -d fru (device) [lun] (bus) (addr) (addr2) (etc)

Example: FRUSDR /D FRU IMBDEVICE L00 00 C0 C2

The configuration file may be used to load multiple FRU and SDR files.

In the configuration file, you may define which FRU and SDR areas are to be programmed. Additionally, you may request information from the user or ask the user to choose which areas to program.

To read this area	Enter this command line
I/O Baseboard FRU	frusdr -d fru IMBDEVICE FF 20
Front Panel FRU	frusdr -d fru IMBDEVICE 00 22
CPU baseboard FRU	frusdr -d fru DS1624S 01 98
Top Mem Mod FRU	frusdr -d fru DS1624S 01 9A
Bottom Mem Mod FRU	frusdr -d fru DS1624S 01 9E
Interconnect Backplane FRU	frusdr -d fru AT24C02 01 A2
I/O Riser FRU	frusdr -d fru AT24C02 01 AE
Power Distribution Backplane FUR	frusdr -d fru IMBDEVICE L02 00 22
SCSI Hot Swap Backplane FRU	frusdr -d fru IMBDEVICE 00 C0
Term card in Slot 1	frusdr -d fru AT24C02 03 A0
Term card in Slot 2	frusdr -d fru AT24C02 03 A4
Term card in Slot 3	frusdr -d fru AT24C02 03 A8
Term card in Slot 4	frusdr -d fru AT24C02 03 AC

Displaying a Given Area

When the utility is run with the `-d DMI`, `-d FRU`, or `-d SDR` command line flag, the indicated area is displayed. Each area represents a sensor; one sensor for each instrumented device in the server. If the given display function fails because of an inability to parse the data present or a hardware failure, the utility displays an error message and exits.

Displaying DMI Area

Each DMI area displayed is headed with the DMI area designated name. In each area, each field has a field name header followed by the field in ASCII or as a number.

Example:

To display the DMI area, type `frusdr -d dmi -v -p` and press <Enter>. A message similar to the following appears:

```

Displaying DMI Area...

System Information (Type 1, 8 bytes)
Manufacturer      = Intel
Product          = AC450NX Server System
Version          = ASDK128M1P2MBPP
Serial Number    = Z00418630

Board Information (Type 2, 8 bytes)
Manufacturer      = Intel Corp.
Product          = AC450NX Server System
Version          = ASDK128M1P2MBPP
Serial Number    = 0123456789

Chassis Information (Type 3, 9 bytes)
Manufacturer      = Intel
Type              = Main Server Chassis
Version          = ASDK128M1P2MBPP
Serial Number    = Z00418630
Asset Tag#       =

```

Displaying FRU Area

The FRU area is displayed in ASCII format when the field is ASCII or as a number when the field is a number. Each FRU area displayed is headed with the FRU area designated name. Each field has a field name header followed by the field in ASCII or as a number. The Board, Chassis, and Product FRU areas end with an END OF FIELDS CODE that indicates there is no more data in this area. The Internal Use area is displayed in hex format, 16 bytes per line.

Example:

To display the FRU area, type `frusdr -d fru` and press <Enter>. A message similar to the following appears:

```
Common Header Area (Version 1, Length 8)
Header Area Version    = 01h
Internal Area Offset   = 01h
Chassis Area Offset    = 0Ah
Board Area Offset      = 0Eh
Product Area Offset    = 16h
PAD                    = 00h
PAD                    = 00h
CHECKSUM               = D0h

Internal Information Area (Version 0, Length 72)
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00

Chassis Information Area (Version 1, Length 32)
Chassis Type          = 11h
Part Number (ASCII)   = ASDK128M1P2MBPP
Serial Number (ASCII) = Z00418630
END OF FIELDS CODE

Board Information Area (Version 1, Length 64)
Unicode Country Base   = 00h
Manufacturing Time (mins) = 733803
Manufacturer Name (ASCII) = Intel
Product Name (ASCII)   = AC450NX Server System
Serial Number (ASCII)   = 0123456789
Part Number (ASCII)    = 664653-001
END OF FIELDS CODE
```

```

Product Information Area (Version 1, Length 80)
Unicode Country Base      = 00h
Manufacturer Name (ASCII) = Intel
Product Name (ASCII)     = AC450NX Server System
Part Number (ASCII)      = ASDK128M1P2MBPP
Version (ASCII)          =
Serial Number (ASCII)    = 0123456789
Asset Tag (ASCII)        =
END OF FIELDS CODE
    
```

Displaying SDR Area

The SDR nonvolatile storage area is displayed in the following hex format. The data is separated by a Sensor Record Number X header, where X is the number of that sensor record in the SDR area. The next line after the header is the sensor record data in hex format delineated by spaces. Each line holds up to 16 bytes. The data on each line is followed by the same data in ASCII format; nonprintable characters are substituted by a period (.).

Example:

To display the SDR area, type `frusdr -d sdr` and press <Enter>. A message similar to the following appears:

```

Reading SDR Record #1
0E 00 10 01 37 20 00 0F 05 00 10 F1 F8 02 01 85      ....7.....
02 00 00 00 04 00 00 C4 02 00 08 30 C2 07 91 95      .....0....
8E FF 00 1B 1B 00 99 95 00 8A 8E 02 02 00 01 CC      .....
53 43 53 49 2D 42 2D 54 65 72 6D 33                  SCSI-B-Term3

Reading SDR Record #2
0E 40 10 01 30 20 00 13 05 00 10 F1 F8 04 01 05      .@..0 .....
00 00 00 20 29 00 00 1E 02 00 00 00 00 00 00 ... ).....
00 FF 00 03 03 00 00 00 00 42 49 02 02 00 01 C5      .....BI.....
46 41 4E 2D 32                                       FAN-2
    
```

Using Specified CFG File

The utility can be run with the command line parameter of `-cfg filename.cfg`. The filename can be any DOS accepted, eight-character filename string. The utility loads the specified CFG file and uses the entries in the configuration file to probe the hardware and to select the proper SDRs to load into nonvolatile storage.

Displaying Utility Title and Version

The utility displays its title:

```
FRU & SDR Load Utility, Version xx.xx
```

Configuration File

The configuration file is in ASCII text. The utility executes commands formed by the strings present in the configuration file. These commands cause the utility to perform various tasks needed to ultimately load the proper SDRs into the nonvolatile storage of the BMC and possibly generic FRU devices. Because some of the commands are interactive, you are required to make a choice.

Prompting for Product Level FRU Information

Through the use of a configuration file, the utility may prompt the user for FRU information.

Filtering Sensor Data Record From the SDR File

The MASTER.SDR file has all the possible SDRs for the system. These records may need to be filtered based on the current product configuration. The configuration file directs the filtering of the SDRs.

Updating FRU Nonvolatile Storage Area

After the configuration is determined, the utility updates the FRU nonvolatile storage area. First it verifies the Common Header area and checksum from the specified FRU file. The Internal Use Area is read out of the specified .FRU file and is programmed into the nonvolatile storage. The Chassis Area is read out of the specified .FRU file. Last it reads the Product Area out of the specified FRU file, then the area is programmed into the FRU nonvolatile storage. All areas are also written to the FRU.TMP file.

Updating DMI Nonvolatile Storage Area

After programming the BMC FRU area, the utility then programs the following Chassis, Board, and Product FRU information to the DMI fields.

Example:

Loading DMI System Area

```
Manufacturer Name : Intel
Name : AC450NX Server System
Version Number : ASDK128M1P2MBPP
Serial Number : 0123456789
```

Loading DMI Board Area

```
Manufacturing Name : Intel
Name : AC450NX Server System
Serial Number : 0123456789
Version Number : 661880-303
```

Loading DMI Chassis Area

```
Chassis Part Number : 693792-003
Chassis Serial Number : Z00418630
Asset Tag :
```

If a failure occurs, the utility displays an error message and exits.

Updating the SDR Nonvolatile Storage Area

After the utility validates the header area of the supplied SDR file, it updates the SDR repository area. Before programming, the utility clears the SDR repository area. The utility filters all tagged SDRs depending on the product configuration set in the configuration file. Nontagged SDRs are automatically programmed. The utility also copies all written SDRs to the SDR.TMP file; it contains an image of what was loaded. The TMP file is also useful for debugging the server.

Cleaning Up and Exiting

If an update was successfully performed, the utility displays a single message and then exits.

If the utility fails, it immediately exits with an error message and exit code.

9 Hot-swappable Fans: Hot Swapping

This chapter tells how to hot-swap a fan.

When the yellow fan failure LED on the front panel turns on, you can determine which fan is defective by checking the yellow fan failure LEDs mounted next to each fan. When a fan fails, the LED will be on continuously. However, you *do not* need to shut the server down to hot-swap a failed fan.

Tools and Supplies You Need

- Phillips (cross-head) screwdriver (#2 bit)
- Antistatic wrist strap (recommended)
- Pen or pencil

Equipment Log

Use the equipment log form provided in Appendix B, “Equipment Log,” to record the model and serial numbers of the server, all installed options, and any other pertinent information about the server.

Hot-Swapping a Fan

The server contains six fans in a (5 + 1) redundant configuration for cooling system components. If a single fan fails, the yellow fan failure LED on the front panel turns on. A fan-fail LED mounted next to each fan identifies the failed fan. You can easily hot-swap the defective fan without turning the server power off.



CAUTION

Even though the server can continue operating with only five fans, the defective fan must be replaced in a reasonable amount of time.

Removing a Fan

See Figure 9-1.

1. Remove and save the screw that secures the fan array cover.
2. Slide the fan array cover to the server front to free the cover from the locking tabs and lift the cover.



NOTE

The fan array cover can be removed by first removing the top cover. See Chapter 12, “Server Covers: Removing/Reinstalling.”


3. Look at the yellow fan failure LEDs to determine which fan is defective.



WARNING

The fan blade may still be rotating. To avoid injury wait until it stops rotating before grabbing the fan with your free hand.

4. Use the grasp holes and remove the defective fan.
5. Set it aside.



OM07304

Figure 9-1. Removing/Hot-swapping a Fan

- A. Grasp holes
- B. Fan

Replacing a Fan

See Figure 9-1.

1. Remove the new fan from the protective packaging.
2. Record the model and serial numbers of the fan in your equipment log.

⇒ **NOTE**

Fans are keyed and can only be inserted one way. Be sure that the fan connector will mate with the front panel baseboard connector when aligning the fan in the fan cavity.

3. Align the fan with the fan cavity.
4. Lower the fan into the cavity.
5. Replace the fan array cover and secure it with the screw removed earlier.

10 Hot-swappable SCSI Hard Disk Drives: Installing/Hot Swapping

Hot-docking Bays

Two 3.5-inch hot-docking bays provide space for 3.5-inch wide by 1-inch high single connector attachment (SCA) SCSI hard disk drives. You can install up to 2 industry-standard wide/fast-20 SCSI III SCA-type hard disk drives in these bays.

The power supply fans provide cooling for the hot swap drives. A system with two power supplies is capable of cooling most drives that would be installed into the system, however drives which dissipate a large amount of power may require three power supplies to be installed into the system to insure proper cooling. Refer to the product specifications to determine if the particular drive to be installed needs the additional cooling provided by a third power supply.

Carriers for 3.5-inch wide 1-inch or 1.6-inch height drives allow easy hot-swapping of drives in and out of these bays without shutting down the server.

By installing a Redundant Array of Inexpensive Disks (RAID) controller board on the PHP I/O baseboard, RAID software, and SCSI hard disk drives in the hot-docking bays, you can easily set up RAID applications.

Tools and Supplies You Need

- Phillips (cross-head) screwdriver (#2 bit)
- Antistatic wrist strap (recommended)
- Pen or pencil

Equipment Log

Use the equipment log form provided in Appendix B, “Equipment Log,” to record the model and serial numbers of the server, all installed options, and any other pertinent information about the server. You will need this information when running the SSU.

SCSI SCA Hard Disk Drives

The server supports a variety of single-ended and differential SCSI SCA-type hard disk drives. As shipped from the supplier, the server may not contain any drives. Contact your sales representative or dealer for a list of approved drives that can be installed in the server.

Mounting a SCSI SCA Hard Disk Drive in a Carrier


See Figures 10-1 and 10-2.

1. Remove the 3.5-inch hard disk drive from the protective wrapper, and place it on an antistatic surface.
2. Record the model and serial numbers of the drive in your equipment log.
3. Orient the drive carrier so that the handle is toward your left and the metal EMI/ESD fingers are toward your right.
4. Orient the drive so that the board-side faces toward the finger-side of the carrier and the SCA connector faces away from you.
5. Being careful not to damage the metal fingers of the carrier, place it on the drive.
6. Place the drive and carrier assembly on an antistatic surface of a table or a workbench so that the drive handle and fingers overlap the edge of the table or the workbench.
7. Using four screws of the appropriate size and length (not supplied), attach the carrier to the drive.



CAUTION


Some specific hard disk drive designs require electrical isolation of the drive from the chassis or other ground paths. These drives are usually clearly labeled with this requirement on the drive. Full-height, 1.6-inch drives with this requirement must have an electrical isolator such as durable mylar tape placed between the EMI/ESD grounding fingers and the top cover of the drive. Failure to isolate this type of drive from the ground path will result in unpredictable operation of the drive, including severely impacted performance and data corruption.



OM07153

Figure 10-1. Hard Disk Drive and Carrier

- A. EMI/ESD grounding clips and fingers
- B. SCSI connector
- C. SCSI hard disk drive
- D. Drive carrier handle



OM08268

Figure 10-2. Hard Disk Drive and Carrier Assembly

- A. Four screws

Installing a SCSI SCA Hard Disk Drive in a Hot-docking Bay


See Figure 10-3.

1. Orient the carrier and drive assembly in front of the hot-docking bay guide rails so that metal fingers of the perforated metal bracket attached to the carrier are facing up. Make sure that the carrier is placed correctly into the guide rails to avoid damage.
2. While grasping only the drive carrier handle, firmly push the assembly into the bay until the drive docks with the peripheral bay backplane connector.



CAUTION

Do not press on the perforated metal bracket of the carrier when you push the assembly into the bay. Otherwise you may damage the metal fingers of the bracket.



OM07336

Figure 10-3. Installing a Hard Disk Drive

- A. Drive carrier latch
 - B. Drive carrier handle
 - C. Hot-docking bay guide rails
3. If you installed a RAID controller board in your server, run the Disk Array Controller Configuration utility supplied with the board. See the manufacturer's documentation provided with the board.

Hot-swapping a SCSI SCA Hard Disk Drive

Status LEDs are arranged in sets of three below each of the 2 hot-docking bays. They monitor the status of each drive. When a yellow LED is on continuously, it is okay to hot-swap (remove and replace) a bad drive with a good one. You *do not* need to shut the server down to hot-swap a drive.

SCSI Drive Status LED Descriptions

SCSI drive, power on green LED	SCSI drive active green LED	SCSI drive faulty* yellow LED	Description and action if needed
● On	○ Off	○ Off	Drive is present with power.
● On	● Blinking	○ Off	Drive is present with power and is being accessed.
○ Off	○ Off	● On	Drive CAN be replaced. Steady yellow fault light indicates drive has a problem. Power to drive is off.
● On	○ Off	● Slow blinking	Drive SHOULD NOT be replaced at this time. A slowly blinking yellow fault light indicates that a drive that has just been replaced is in recovery mode (drive array being rebuilt). Power to drive is on.
○ Off	○ Off	○ Off	There is no drive installed in the bay.

* The hot-swap controller is responsible for turning the yellow drive fault LED on or off according to the states specified by commands received via SAF-TE and IMB.


See Figures 10-3 and 10-4.

1. Look at the yellow LEDs below the hot-docking bays to determine which drive is bad.
2. Push on the drive carrier latch of the bad drive, and while grasping the handle, pull the assembly toward you to disengage the drive from the backplane connector.
3. Carefully slide the assembly out of the bay, and place it on an antistatic surface.
4. Orient the new carrier and drive assembly in front of the hot-docking bay guide rails so that metal fingers of the perforated metal bracket attached to the carrier are facing up. Make sure you correctly place the carrier into the guide rails to avoid damage.
5. While grasping only the drive carrier handle, firmly push the assembly into the bay until the driver carrier latches.



CAUTION

Do not press on the perforated metal bracket of the carrier when you push the assembly into the bay. Otherwise you may damage the metal fingers of the bracket.



OM07345

Figure 10-4. Hot-swap SCSI Drive Indicators

- A. Green LED, drive power
- B. Green LED, drive activity
- C. Yellow LED, drive fault

11 Hot-swappable Power Supplies: Hot Swapping

This chapter tells how to hot-swap a server power supply.

When the yellow power supply failure LED on the front panel turns on, you can determine which power supply is defective by checking the three status LEDs on the back of each power supply. If a power supply fails, the yellow FAIL LED on the back of the power supply will be on continuously. You may hot-swap the power supply—remove and replace it—with a good one. If the server contains three power supplies, you *do not* need to shut the server down to hot-swap a failed power supply.

The LEDs on the power supply are:

- **Green PWR (Power) LED**—when blinking, AC is applied to the power supply and standby voltages are available. When on continuously, all power outputs are ready.
- **Yellow FAIL (Power Supply Failure) LED**—when on continuously, the power supply has failed and it may be replaced.
- **Yellow PRFL (Predictive Failure) LED**—when blinking, the power supply is about to fail in the near future due to the fan performing poorly. The LED latches into a blinking state once the predictive failure condition occurs.

Power Supply Status	Power Supply LEDs		
	PWR (power) (Green)	FAIL (power supply failure) (Yellow)	PRFL (predictive failure) (Yellow)
No AC power	Off	Off	Off
AC in/standby outputs on	Blinking	Off	Off
DC outputs on and okay	On	Off	Off
Power supply failure	Off	On	Off
Current limit	On	Blinking/None Latch	Off
Predictive failure	On	Off	Blinking/Latched

Tools and Supplies You Need

- Pen or pencil

Equipment Log

Use the equipment log form provided in Appendix B, “Equipment Log,” to record the model and serial numbers of the server, all installed options, and any other pertinent information about the server. You will need this information when running the SSU.

Hot Swapping a Power Supply

In a fully configured server, the power system contains three 750 watt auto-ranging power supplies; one of the power supplies is redundant. If a single power supply fails in the redundant power system, the yellow power supply failure LED on the front panel turns on. You can easily hot-swap the defective power supply without turning the server power off.

Power supplies are hot-swappable only in configurations with three power supplies.



WARNING

Because of chassis airflow disruption, the power supply bay should not be vacant for more than two minutes when server power is on. Exceeding the two-minute limit may cause damage to certain peripheral components.

Before replacing a power supply in a two-power supply configuration, you must turn off power to the server.

A filler panel is required in a two-power supply configuration. The filler panel must be installed within two minutes when moving from a three-power supply configuration to a two-power supply configuration.



NOTE

If the system contains less than two power supplies or AC is not present in at least two power supplies and midplane jumper JP1 is removed, the system will automatically shutdown.

In a three-power supply configuration a power supply can be swapped at any time.

Removing a Power Supply



CAUTION

If the chassis contains only two power supplies, turn off all peripheral devices connected to the server. Then turn off the server power with the push-button on/off switch on the front panel.

See Figures 11-1.

1. Look at the yellow FAIL LEDs on the power supplies to determine which one is defective.
2. Pull the power supply handle down to unlock it from the chassis.
3. Pull the power supply toward you to unplug it.
4. Remove the defective power supply, and set it aside.




Figure 11-1. Removing a Power Supply

- A. Pull down handle
- B. Remove power supply

Replacing a Power Supply

See Figure 11-1.

1. Remove the new power supply from the protective packaging.
2. Record the model and serial numbers of the power supply in your equipment log.
3. Slide the replacement power supply into the power supply cavity with the handle out.
4. After the power supply contacts the midplane, lift the power supply handle to lock it into place.

Part II: Service Technician's Guide

Safety Guidelines

12 Server Covers: Removing/Reinstalling

13 Server Components: Removing/Reinstalling

14 Removable Media Drives: Installing/Removing/Replacing

15 Midplane: Description/Voltages

16 Peripheral Bay Backplane: Description

17 PHP I/O Baseboard: Description/Setting Configuration Jumpers

18 CPU Baseboard: Description/Setting Configuration Jumpers

19 Memory Modules: Description/Adding Memory

20 Power System: Description/Calculating Power Usage

21 Back-up Battery: Replacing/Disposing

22 Solving Problems: Troubleshooting/Error Messages

23 Front Panel: Description/Voltages

24 Peripheral Bay Blindmate Board: Description

A Regulatory Specifications

B Equipment Log

C Warnings

Safety Guidelines

BEFORE YOU REMOVE SERVER COVERS, OBSERVE THESE GUIDELINES:

1. Turn off all peripheral devices connected to the server.
2. Turn off DC power in the server by pressing the push-button on/off power switch on the front panel of the server.
3. Disconnect AC power to the server by unplugging the alternating current (AC) power cord from the AC inlet filter or wall outlet.
4. Label and disconnect all peripheral cables attached to the I/O panel on the back of the server.
5. Provide some electrostatic discharge (ESD) protection by wearing an antistatic wrist strap attached to chassis ground of the server—any unpainted metal surface—when handling components.

Warnings and Cautions

These warnings and cautions apply whenever you remove the top and side covers of the server to access components inside it. Integration of the server should be done only by technically qualified personnel.

Server Precautions



WARNING

Server power on/off: The *push-button on/off power switch* on the front panel of the server does not turn off the AC power. To remove AC power from the server, you must unplug the AC power cord from the AC inlet filter.

Hazardous conditions, power supply and power distribution backplane: Hazardous voltage, current, and energy levels are present inside the power supply and the power distribution backplane. There are no user-serviceable parts inside them; servicing should be done only by technically qualified personnel.

Hazardous conditions, devices and cables: Hazardous electrical conditions may be present on power, telephone, and communication cables. Turn off the server and disconnect telecommunications systems, networks, modems, and each power cord attached to the server before opening it. Otherwise, personal injury or equipment damage can result.

Avoid injury: The minimum server configuration weighs 51.4 kg (113 lbs), and the maximum one weighs 60 kg (132 lbs). To avoid injury, we recommend that a lift be used to insert the server into the slide assemblies in the equipment rack.

**CAUTION**

Electrostatic discharge (ESD) and ESD protection: ESD can damage disk drives, add-in boards, and other components. This server can withstand normal levels of environmental ESD while you are hot-swapping hard disk drives and power supplies. However, we recommend doing all procedures in this manual only at an ESD workstation. If one is not available, you can provide some ESD protection by wearing an antistatic wrist strap attached to chassis ground of the server—any unpainted metal surface—when handling components.

Handling boards and modules: Boards and modules can be extremely sensitive to ESD and always require careful handling. After removing a board or module from a protective wrapper or from the server, place the board or module component-side up on a nonconductive, static-free surface. If you place the I/O baseboard on a conductive surface, the back-up battery leads may short out. If they do, this will result in a loss of CMOS data and will drain the battery. Do not slide a board or module over any surface.

Cooling and airflow: Operating the server with the top and side covers removed can damage the components inside it. For proper cooling and airflow, always replace the covers and air baffles before turning on the server.

Back-up battery: Danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the equipment manufacturer. Discard the used battery according to the manufacturer's instructions.

Equipment Rack Precautions

**WARNING**

Anchor the equipment rack: The equipment rack must be anchored to an unmovable support to prevent it from falling over when one or more servers are extended in front of it on slide assemblies. The anchors must be able to withstand a force of up to 113 kg (250 lbs). You must also consider the weight of any other device installed in the rack.

Main AC power disconnect: You are responsible for installing an AC power disconnect for the entire rack unit. This main disconnect must be readily accessible, and it must be labeled as controlling power to the entire unit, not just to the server(s).

Grounding the rack installation: To avoid the potential for an electrical shock hazard, you must include a third wire safety grounding conductor with the rack installation. If the server power cord is plugged into an AC outlet that is part of the rack, then you must provide proper grounding for the rack itself. If the server power cord is plugged into a wall AC outlet, the safety grounding conductor in the power cord provides proper grounding only for the server. You must provide additional, proper grounding for the rack and other devices installed in it.

Overcurrent protection: The server is designed for an AC line voltage source with up to 20 amperes of overcurrent protection. If the power system for the equipment rack is installed on a branch circuit with more than 20 amperes of protection, you must provide supplemental protection for the server. If more than one server is installed in the rack, the power source for each server must be from a separate branch circuit. The overall current rating of a server configured with three power supplies is under 12 amperes.



CAUTION

Temperature: The operating temperature of the server, when installed in an equipment rack, must not go below 5 °C (41 °F) or rise above 35 °C (95 °F). Extreme fluctuations in temperature can cause a variety of problems in your server.

Ventilation: The equipment rack must provide sufficient airflow to the front of the server to maintain proper cooling. It must also include ventilation sufficient to exhaust a maximum of 3,150 Btu's per hour for the server. The rack selected and the ventilation provided must be suitable to the environment in which the server will be used.

12 Server Covers: Removing/Reinstalling

This chapter tells how to remove and reinstall the server covers.

Warnings and Cautions

Only a *qualified service technician* is authorized to remove the server covers and to access any of the components inside the server. Before removing the covers, see “Safety Guidelines” on page 115.

Tools and Supplies You Need

- Phillips (cross-head) screwdriver (#1 bit and #2 bit)
- Small flat-bladed screwdriver
- Antistatic wrist strap (recommended)
- Pen or pencil

Equipment Log

Use the equipment log form provided in Appendix B, “Equipment Log,” to record the model and serial numbers of the server, all installed options, and any other pertinent information about the server. You will need this information when running the SSU.

Covers


See Figures 12-1 and Figure 12-2 The server comes with several removable covers:

- The plastic snap-on front bezel provides user friendly system controls and indicators.
- The plastic snap-on peripheral bay cover provides access to the peripheral bay. You must remove the front bezel before you can remove this cover.
- The top cover provides access to the CPU baseboard, I/O baseboard, and PCI bus regular slot cover. You must remove the top cover before you can remove the PCI bus regular slot cover.
- The PCI bus hot-plug cover provides access to the PCI bus hot-plug slots.
- The fan array cover provides access to the 6-fan array. It can be opened without removing the top cover.
- The memory module cover provides access to the two memory modules.



CAUTION

For proper cooling and airflow, do not operate the server with the covers removed. Always reinstall them before turning on the server.



OM07302

Figure 12-1. Server Covers

- A. Memory module cover
- B. Fan array cover
- C. Top cover
- D. PCI hot-plug cover

Removing the Peripheral Bay Cover


The peripheral bay cover is attached to the chassis with press-in rivets and spring clips. See Figure 12-2.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Grasp the peripheral bay cover handle and pull.
3. Place the bezel on a smooth surface so that it does not get scratched.

Reinstalling the Peripheral Bay Cover

See Figure 12-2.

1. Position the peripheral bay cover in position and press into place.



OM07356

Figure 12-2. Peripheral Bay Cover and Front Bezel

- A. Plastic snap-on Peripheral Bay Cover
- B. Plastic snap-on Front Bezel

Removing the Front Bezel

The plastic front bezel is attached to the chassis with press-in rivets and spring clips in the same manner as the peripheral bay cover.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the peripheral bay cover as described earlier.
3. Grasp the bezel hand and pull.
4. Place the bezel on a smooth surface so that it does not get scratched.

Reinstalling the Front Bezel

1. Install the peripheral bay cover as described earlier.
2. Position the front bezel in position and press into place.

Removing the Top Cover

See Figures 12-3 and 12-4.


1. Observe the precautions on page 115, “Safety Guidelines.”
2. Turn off all peripheral devices connected to the server.
3. Turn the server off with the push-button on/off power switch on the front panel.
4. Unplug the AC power cord from the power inlet receptacle, or from the power source outlet.
5. Label and disconnect all peripheral cables attached to the I/O panel on the back of the server.

6. Remove and save the screws that attach the top cover to the chassis.

⇒ **NOTE**

It is not necessary to remove the PCI bus hot-plug cover.


7. While facing the back of the server, pull hard on the front edge of the cover to disengage the tabs along the sides of the cover from the slots in the chassis slide.
8. Slide the cover backward about an inch, and lift it straight up. Set the cover aside.
9. Lift PCI bus regular expansion slot cover from chassis.



OM07303

Figure 12-3. Top Cover

C. Two screws



OM07305

Figure 12-4. PCI Regular Slot Cover

A. Two screws

Reinstalling the Top Cover


See Figures 12-3 and 12-4.

1. Reinstall the PCI bus regular expansion slot cover.
2. While facing the back of the server, position the top cover over the chassis so that the tabs along the edges of the cover align with the slots in the top edge of the chassis.
3. Gently lower the cover straight down on top of the server. Then place your hands on the outer surface of the cover, opposite each other, and push the cover forward to seat it.
4. Attach the cover to the chassis with the two screws, and tighten them firmly (6.0 inch-pounds).
5. Connect all external cables and power cords to the server.

Removing the PCI Bus Hot-Plug Cover

See Figure 12-5.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove and save the screws that attach the PCI bus hot-plug cover to the chassis.
3. While facing the back of the server, pull on the front edge of the cover to disengage the tabs along the front of the cover from the top cover.
4. Remove the cover and set it aside.



OM07357

Figure 12-5. PCI Bus Hot-Plug Cover

Reinstalling the PCI Bus Hot-Plug Cover

See Figure 12-5.

1. Ensure that add-in boards are firmly seated in their respective slots.
2. Position the cover over the top cover so that the tabs along its edges align with the slots in the top cover.
3. Lower the cover until it rests on the top cover.
4. Push the cover toward the server front to seat the tabs along the cover front with the top cover.
5. Attach the cover to the top cover with the two screws, and tighten them firmly (6.0 inch-pounds).

Removing the Fan Array Assembly Cover

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the front bezel as described earlier.
3. Remove the top cover as described earlier.
4. Remove and save the screw that secures the fan array assembly cover to the chassis.
5. Slide the cover forward to free it from the securing tab.
6. Remove the cover.


Reinstalling the Fan Array Assembly Cover

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Place cover in position over the fan array. Ensure that the tabs interlock with the fan array assembly.
3. Lower cover and slide it to the rear so that it engages locking tabs.
4. Secure the cover screw removed earlier.
5. Reinstall the top cover as described earlier.
6. Reinstall the front bezel as described earlier.

Removing the Memory Module Cover

See Figure 12-6.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the front bezel as described earlier.
3. Loosen the four captive screws securing the memory module cover and remove the cover.



OM07353

Figure 12-6. Memory Module Cover

Reinstalling the Memory Module Cover

See Figure 12-6.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Place the cover in position and tighten the four captive screws to secure the cover.
3. Reinstall the front bezel as described earlier.

13 Server Components: Removing/Reinstalling

This chapter tells how to remove and reinstall major server components. Because the CPU baseboard is mounted horizontally toward the front of the chassis and the PHP I/O baseboard is mounted horizontally towards the rear of the chassis, the procedures start with the covers and end up with the baseboards.

Warnings and Cautions

Only a *qualified service technician* is authorized to remove the server covers and to access any of the components inside the server. Before removing the covers, see “Safety Guidelines” on page 115.

Tools and Supplies You Need

- Phillips (cross-head) screwdriver (#1 bit and #2 bit)
- Small flat-bladed screwdriver
- Antistatic wrist strap (recommended)
- Pen or pencil

Equipment Log

Use the equipment log form provided in Appendix B, “Equipment Log,” to record the model and serial numbers of the server, all installed options, and any other pertinent information about the server. You will need this information when running the SSU.

Fan Array Housing

Removing the Fan Array Housing


See Figures 13-1 and 13-2.

1. Observe the precautions on page 115, "Safety Guidelines."
2. Remove the top cover, the fan array assembly cover, and the memory module cover as described in Chapter 12, "Server Covers: Removing/Reinstalling."
3. Use the grasp holes and remove all fan assemblies.
4. Remove and save the five screws that secure the housing to the chassis.
5. Remove the fan array housing.

Reinstalling the Fan Array Housing


See Figures 13-1 and 13-2.

1. Observe the precautions on page 115, "Safety Guidelines."
2. Reinstall the fan array housing ensuring that it engages with the support tabs.
3. Insert the screws that you removed earlier and tighten the screws firmly (8.0-inch pounds).
4. Reinstall each fan assembly. The fan assemblies are keyed and can only be installed if correctly oriented.
5. Reinstall the top cover, the fan array assembly cover, and the memory module cover as described in Chapter 12, "Server Covers: Removing/Reinstalling."



OM07304

Figure 13-1. Fan Removal



OM07308

Figure 13-2. Fan Array Housing

- A. Screws (five)
- B. Fan array housing

LCD Module

The LCD module displays server information.

Removing the LCD Module

See Figure 13-3.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the memory module cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Remove the two screws that secure the LCD module to the chassis.
4. Disconnect the LCD module data and power cables from the front panel board and set the LCD module aside.


Reinstalling the LCD Module

See Figure 13-3.

1. Connect the LCD module data and power cables to the front panel board.

⇒ NOTE

- Verify that both cables are below the sheet of insulating material above the front panel board.
2. Insert the screws that you removed earlier and tighten the screws.
 3. Reinstall the memory module cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”



OM07358

Figure 13-3. LCD Module

Memory Modules

CAUTION

To avoid damaging the memory module DIMM sockets, do not attempt to use the metal stiffener on the memory module as a handle.

Removing a Memory Module

See Figure 13-4.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the memory module cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Simultaneously rotate the eject/insert levers of the memory module outward about 90° to disengage the pin-and-socket connector of the module from the pin-and-socket connector of the midplane.
4. Being careful not to touch the components on the memory module, slide it out of the slot guides. Place the module DIMM-side up on a nonconductive, static-free surface, or store it in an antistatic protective wrapper.

Reinstalling a Memory Module


See Figure 13-4.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Being careful not to touch the components on the memory module, remove it from its protective wrapper. Place the module DIMM-side up on a nonconductive, static-free surface.
3. Record the serial number of the memory module in your equipment log.
4. Remove any installed DIMM from the removed memory module and reinstall them in the replacement memory module.

⇒ NOTE

The memory module installs DIMM-side down.

5. Grasp the memory module by the eject/insert levers, and carefully slide it into the slot guides until the levers engage with the flanges in front of the guides.
6. Simultaneously rotate the levers inward until they are flush with the edge of the module to seat the pin-and-socket connector of the module into the pin-and-socket connector of the midplane.
7. If you removed the LCD module, reinstall it as described earlier.
8. Reinstall the memory module cover as described in Chapter 12.



OM07361

Figure 13-4. Memory Module

Front Side Bus Terminator Module

The CPU baseboard provides four slot 2 connectors for processors packaged in S.E.C. cartridges. If any slot 2 connector is depopulated, a terminator module must be installed in the connector to properly terminate the signals on the front side bus (FSB). For example, if only two slots are populated with processors, you need FSB terminator modules in the two unpopulated processor slots. The terminator modules are housed in plastic covers.

Removing a Terminator Module


See Figure 13-5.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Loosen the holddown bracket captive screw and remove the holddown bracket.
4. Simultaneously rotate the eject/insert levers of the terminator module outward to eject the module out of the slot 2 connector on the CPU baseboard.
5. Slide the module out of the slot guides, and place it component-side down on a nonconductive, static-free surface.

Reinstalling a Terminator Module

See Figure 13-5.

1. Grasp the terminator module by the eject/insert levers, and carefully slide it into the slot guides until the levers engage with the flanges in the front sides of the guides.
2. Simultaneously rotate the levers inward until they are flush with the edge of the module to seat the module into the slot 2 connector on the CPU baseboard.
3. Insert the hook end of the holddown bar in the flange of the right slot guide.
4. Tighten the captive screw.
5. Reinstall the top cover as described in Chapter 12.



OM07306

Figure 13-5. Removing a Holddown

Processor

The CPU baseboard supports up to four processors packaged in S.E.C. cartridges.



CAUTION

The processors can be extremely sensitive to ESD and always require careful handling. After removing a processor from a protective wrapper or from the CPU baseboard, place it on a nonconductive, static-free surface. Do not slide the processor over any surface.

Removing a Processor

See Figures 13-5.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Loosen the holddown bracket captive screw and remove the holddown bracket.
4. Simultaneously rotate the eject/insert levers of the processor cartridge outward to eject the cartridge out of the slot 2 connector on the CPU baseboard.
5. Slide the cartridge out of the slot guides, and place it heat sink-side up on a nonconductive, static-free surface, or store it in an antistatic protective wrapper.



CAUTION

If a slot 2 connector is depopulated, a terminator module must be installed in the connector to properly terminate the signals on the FSB.

Installing a Processor

See Figures 13-5.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Remove the processor cartridge or terminator module as described earlier.
4. Being careful not to touch the gold edge connector on the processor cartridge, remove it from the protective wrapper. Place the cartridge heat sink-side up on a nonconductive, static-free surface.
5. Record the serial number of the cartridge in your equipment log.
6. Grasp the cartridge by the eject/insert levers, and carefully slide it into the slot guides until the levers engage with the flanges in the front sides of the guides.
7. Simultaneously rotate the levers inward until they are flush with the edge of the cartridge to seat the cartridge into the slot 2 connector on the CPU baseboard.
8. Insert the hook end of the holddown bar in the flange of the right slot guide.
9. Tighten the captive screw.
10. Reinstall the top cover as described in Chapter 12.

DC to DC Converter VRM

VRM in connector	Provides power for	Description
J1	Processor #1	Processor core power only
J2	Processor #1 and #2	L2 Cache power only
J3	Processor #2	Processor core power only
J4	Processor #3	Processor core power only
J5	Processor #3 and #4	L2 Cache power only
J6	Processor #4	Processor core power only

Removing a DC to DC Converter VRM


See Figure 13-6.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Using a small flat-bladed screwdriver, push the plastic ejector levers on each end of the connector away from the VRM to eject it out of the connector.
4. Place the VRM on a nonconductive, static-free surface, or store it in an antistatic protective wrapper.

Installing a DC to DC Converter VRM

See Figure 13-6.

1. Remove the DC to DC converter VRM from the antistatic package.
2. Carefully insert the VRM in the connector on the CPU baseboard. Make sure you do not bend the connector pins.
3. Push down firmly on each end of the VRM until the ejector levers of the connector snap into place, locking the VRM in the connector.
4. Reinstall the top cover as described in Chapter 12.



OM07318

Figure 13-6. DC to DC Converter VRM

- A. VRM socket
- B. DC to DC Converter VRM
- C. Ejector lever
- D. J1, VRM connector
- E. J3, VRM connector
- F. J2, VRM connector
- G. J5, VRM connector
- H. J6, VRM connector
- I. J4, VRM connector
- J. CPU Baseboard

CPU Tray

The CPU tray provides rigid mounting for the front panel board, the CPU baseboard, and the memory modules. It also facilitates mating with the midplane.

Removing the CPU Tray

See Figure 13-7.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top cover and memory module cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Remove all terminator and processor modules as described earlier.
4. Remove the LCD module as described earlier.
5. Remove the memory modules as described earlier.
6. Remove the fan array housing as described earlier.
7. Remove six screws that secure the tray to the chassis.
8. Simultaneously pull the eject/insert levers down to eject the tray out of the midplane.
9. Slide the tray from the chassis.

Reinstalling the CPU Tray


See Figure 13-7 and 13-8.

1. Carefully position the tray on the guide rails and slide the tray into the chassis.



CAUTION


- Be careful not to pinch the cables coming from the peripheral bay when reinstalling the tray.
2. Simultaneously lift the eject/insert levers to mate the tray grand connector with the midplane grand connector. Ensure that the lower tray guide engages with the tray support attached to the peripheral bay. Be sure CPU support rail engages rear support.
 3. Reinstall the six screws that secure the tray to the chassis.
 4. Reinstall all terminator and processor modules as described earlier.
 5. Reinstall the fan array housing as described earlier.
 6. Reinstall the memory modules as described earlier.
 7. Reinstall the LCD module as described earlier.
 8. Reinstall the top cover and memory module cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”



OM07327

Figure 13-7. CPU Tray

- A. Rear support
- B. Eject/Insert levers
- C. Screws (six)
- D. Midplane
- E. Grand connector
- F. Front panel board



OM07328

Figure 13-8. CPU Tray Support Rail

Front Panel Board

The front panel board contains the server controls and indicators. It is mounted on snap-on and threaded standoffs on the CPU Tray (see Figure 13-7).

Removing the Front Panel Board

See Figure 13-9.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the CPU tray as described earlier.
3. Remove the insulating material from the front panel board.
4. Remove the nine screws, and remove the board.

**CAUTION**

When the front panel board is free of the CPU board connector, its switches are surrounded by sheet metal. Be careful not to damage these switches when lifting the front panel board.

5. Push/pull the front panel board horizontally to free it from the CPU baseboard connector and lift the board from the chassis.
6. Place the board on a nonconductive, static-free surface, or store it in an antistatic protective wrapper.


Reinstalling the Front Panel Board

See Figure 13-9.

**CAUTION**

When positioning the front panel board for reinstallation be sure its switches are in the sheet metal holes before mating its connector with the CPU baseboard. If the switches are not in the holes they may be damaged.

1. Position the front panel board over threaded standoffs on the chassis.
2. Push the board horizontally to mate the connector with the CPU baseboard connector.
3. Insert the screws loosely into the threaded standoffs.
4. Make sure the board is properly positioned, and tighten all screws firmly (8.0 inch-pounds).
5. Reinstall the CPU tray as described earlier.
6. Reinstall the LCD module as described earlier.
7. Reinstall the insulating material removed earlier from the front panel board.
8. Reinstall the fan array housing as described earlier.
9. Reinstall the top cover as described in Chapter 12.



OM07322

Figure 13-9. Front Panel Board

- A. CPU baseboard connector
- B. LCD data connector
- C. LCD power connector

CPU Baseboard

Removing the CPU Baseboard


See Figure 13-10.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the CPU tray as described earlier.
3. Remove the front panel board as described earlier.
4. Remove the terminator modules as described earlier.
5. Remove the processors as described earlier.
6. Remove the screws in the base of the processor retention module.
7. Remove the module—it comes out as one unit—and set it aside.
8. Remove the DC to DC converters as described earlier.
9. Lift the baseboard to unsnap it from the snap-on standoffs.
10. Place the baseboard on a nonconductive, static-free surface, or store it in an antistatic protective wrapper.

Reinstalling the CPU Baseboard

See Figure 13-10.

1. Remove CPU baseboard from the antistatic protective wrapper if you placed it in one.
2. Position the baseboard over the snap-on and threaded standoffs on the CPU tray.
3. Press the baseboard onto the snap-on standoffs, and insert the screws loosely into the threaded standoffs.
4. Position the processor retention module over the CPU baseboard and loosely insert the retaining screws into the threaded standoffs.
5. Make sure the baseboard is properly seated, and then tighten all screws to 8.0 inch-pounds.
6. Reinstall the processors and any terminator modules as described earlier.
7. Reinstall DC to DC converters as described earlier.
8. Reinstall the front panel board as described earlier.
9. Reinstall the CPU tray as described earlier.



- ⊕ = A
- ⊕ = B

OM07321

Figure 13-10. CPU Baseboard

- A. Standoff (six)
- B. Screw (twelve)

Add-in Boards

The PHP I/O baseboard provides 10 PCI bus master slots and one ISA bus master slot. They accept any add-in PCI and ISA boards or any add-in board that is compatible with an IBM PC AT[†] or PC XT[†] system (except for an 8-bit drop card that fits only in an 8-bit PC XT connector). One PCI slot shares a common chassis I/O expansion slot with the ISA slot; you can use the slot for either PCI or the ISA, but not both.



CAUTION

Some accessory/option card outputs may exceed Class 2 or limited power source limits and must use appropriate interconnecting cabling in accordance with the National Electric Code during installation.

Do not overload the PHP I/O baseboard by installing add-in boards that draw excessive current. For expansion slot current limitations, see Chapter 20, “Power System: Description/Calculating Power Usage.”

Add-in boards can be extremely sensitive to ESD and always require careful handling. After removing the board from the protective wrapper or from the baseboard, place it component-side up on a nonconductive, static-free surface. Do not slide the board over any surface.

⇒ NOTE

If you are installing or removing an ISA add-in board, you must run the SSU to reconfigure the server. Running the SSU is optional for a PCI add-in board.

Installing an Add-in Board


See Figures 13-11, 13-12, and 13-13.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top and PCI bus regular slot covers as described in Chapter 12, “Server Covers: Removing/Reinstalling.”

⇒ NOTE

The 64-bit PCI hot swap expansion slots also have a power enabling switch actuator. This actuator must be installed (unless override is set in the BIOS setup or an expansion board is installed). The actuator is held in place by the expansion slot cover screw.


3. Select the appropriate 16-bit ISA, 32-bit PCI, or 64-bit PCI expansion slot. Remove and save the expansion slot cover and, if installed, the power enabling switch actuator.



OM07319

Figure 13-11. PHP I/O Baseboard Expansion Slots


- A. 16-bit ISA slot
- B. 32-bit PCI slots
- C. 64-bit hot swap PCI slots



OM07337

Figure 13-12. Expansion Slot Cover

5. Being careful not to touch the components or gold edge connectors on the add-in board, remove it from the protective wrapper, and place it component-side up on a nonconductive, antistatic surface.
6. Record the serial number of the board in your equipment log.
7. Set any jumpers or switches according to the board manufacturer's instructions.
8. Grasp the board by the top edge or upper corners, and firmly press it into an expansion slot on the PHP I/O baseboard (Figures 13-13). The tapered foot of the board retaining bracket must fit into the mating slot in the expansion slot frame.
9. Secure the add-in board to the expansion slot frame using the expansion slot cover retaining screw.
10. Reinstall the top and PCI bus regular slot covers as described in Chapter 12.
11. If you installed an ISA add-in board, run the SSU to reconfigure the server. Running the SSU is optional for a PCI add-in board. For information about running this utility, see Chapter 5, "System Setup Utility: When to Run."



OM07331

Figure 13-13. Installing an Add-in Board

- A. 16-bit ISA slot (ISA board component-side up)
- B. 32-bit PCI slot (PCI board, component-side down)
- C. 64-bit hot swap PCI slot (PCI board, component-side down)

Removing an Add-in Board



CAUTION

Expansion slot covers must be installed on all vacant slots to maintain the electromagnetic emission characteristics of the server and to ensure proper cooling of the server components.

See Figures 13-11, 13-12, and 13-13.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top and PCI bus regular slot covers as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Disconnect any cables attached to the board you are removing.
4. Remove and retain the screw securing the add-in board to the expansion slot frame.
5. Grasp the board by the top edge or upper corners, and carefully pull it toward you until the edge connector of the board pulls free from the connector on the PHP I/O baseboard. Make sure that you do not scrape the board against other components.
6. Store the board in an antistatic protective wrapper.
7. Install an expansion slot cover (Figure 13-12) over the vacant slot. The tapered foot of the cover must fit into the mating slot in the bottom of the expansion slot frame.
8. If this is a 64-bit hot swap slot, install the power enabling switch actuator over the vacant slot. The spring at the end of the actuator rests on the power enabling switch.
9. Secure the expansion slot cover and the actuator to the expansion slot frame using the expansion slot cover retaining screw.
10. Reinstall the top and PCI bus regular slot covers as described in Chapter 12.
11. If you removed an ISA add-in board, run the SSU to configure the system. For information about running this utility, see Chapter 5, “System Setup Utility: When to Run.”

I/O Riser Card

Removing the I/O Riser Card


See Figure 13-14.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top and PCI bus regular slot covers as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Disconnect the Intelligent Chassis Management Bus (ICMB) signal cable from J1 on the I/O riser card.
4. Remove and save the screw.
5. Holding the card by the top edge or upper corners, carefully pull it toward you until the edge connector of the card pulls free from its connector J2A1 on the PHP I/O baseboard. Make sure that you do not scrape the card against other components.
6. Place the card on a nonconductive, static-free surface, or store it in an antistatic protective wrapper.

Reinstalling the I/O Riser Card

See Figure 13-14.

1. Remove the I/O riser card from the antistatic protective wrapper if you placed it in one.
2. Holding the card by the top edge or upper corners, carefully insert the edge connector of the card into connector J2A1 on the PHP I/O baseboard. Press the card firmly into the connector.
3. Insert the screw you removed earlier in the threaded hole in the chassis. Tighten the screw firmly (8.0 inch-pounds).
4. Connect the ICMB signal cable to J1 on the riser card.
5. Reinstall the top and side covers as described in Chapter 12.



OM07323

Figure 13-14. I/O Riser Card

- A. J1B1, I/O connector
- B. Screw
- C. ICMB signal cable

I/O Tray

The I/O Tray provides rigid mounting for the PHP I/O baseboard and facilitates mating with the midplane.

Removing the I/O Tray


See Figure 13-15.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top and PCI bus regular slot covers as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Label and disconnect all internal cables connected to the add-in boards installed in the expansion slots.
4. Remove the add-in boards as described earlier. This step is not required unless replacing the PHP I/O baseboard.
5. Label and disconnect all internal cables connected to the PHP I/O baseboard.
6. Remove the three screws securing the tray to the chassis.
10. Simultaneously rotate the eject/insert levers to eject the tray out of the midplane.
7. Lift the tray from the chassis.

Reinstalling the I/O Tray

See Figure 13-15.

1. Position the tray over the chassis and lower it on to its supports.
2. Simultaneously rotate the eject/insert levers into the locked position. This action also mates the PHP I/O baseboard connector with the midplane connector.
3. Reinstall the three securing screws.
4. Connect all internal cables to the PHP I/O baseboard.
5. Reinstall all add-in boards, if removed, as described earlier.
6. Connect all internal cables connected to the add-in boards installed in the expansion slots.
7. Reinstall the top and PCI bus regular slot covers as described in Chapter 12, “Server Covers: Removing/Reinstalling.”



OM07310

Figure 13-15. I/O Tray

- A. Screws (three)
- B. Eject/insert levers
- C. I/O Tray

Intelligent Chassis Management Bus (ICMB) Board

Removing the ICMB Board


See Figure 13-16.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top and PCI bus regular slot covers as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Disconnect the ICMB signal cable from connector J1 on the I/O riser card.
4. Remove and save the screw that attach the ICMB board to the I/O Tray.
5. Push on the tab of the snap-on standoff and pull the board toward you to remove it from the snap-on standoff.
6. Place the board on a nonconductive, static-free surface, or store it in an antistatic protective wrapper.

Reinstalling the ICMB Board

See Figure 13-16.

1. Remove the ICMB board from the antistatic protective wrapper if you placed it in one.
2. Position the board over the snap-on and threaded standoffs on the I/O Tray.
3. Press the board onto the snap-on standoff, and insert the screw loosely into the threaded standoffs.
4. Make sure the board is properly aligned, and tighten the screw firmly (8.0 inch-pounds).
5. Connect the signal cable to connector J1 on the I/O riser card.
6. Reinstall the top and PCI bus regular slot covers as described in Chapter 12.



OM07354

Figure 13-16. ICMB Board

PHP I/O Baseboard



CAUTION

The PHP I/O baseboard can be extremely sensitive to ESD and always requires careful handling. After removing the baseboard from the server, place it component-side up on a nonconductive, static-free surface to prevent shorting out the battery leads. If you place the baseboard on a conductive surface, the back-up battery leads may short out. If they do, this will result in a loss of CMOS data and will drain the battery. Do not slide the baseboard over any surface.

Removing the PHP I/O Baseboard

See Figure 13-17.


1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top and PCI bus regular slot covers as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Remove the I/O Tray as described earlier.
4. Remove the I/O riser card as described earlier.
5. Remove the ICMB board as described earlier.
6. Remove all PCI hot plug expansion slot power switch activators and covers.
7. Remove the add-in boards as described earlier.
8. Remove the plastic divider and base.
9. Remove and save the screws that attach the PHP I/O baseboard to the tray.
10. Pull the board toward you to unsnap it from the snap-on standoffs.
11. Place the board on a nonconductive, static-free surface, or store it in an antistatic protective wrapper.

Reinstalling the PHP I/O Baseboard

See Figure 13-17.

1. Remove the PHP I/O baseboard from the antistatic protective wrapper if you placed it in one.
2. Position the baseboard over the snap-on and threaded standoffs on the center bulkhead of the chassis.
3. Press the baseboard onto the snap-on standoffs and install the plastic divider and base.
4. Insert the screws loosely into the threaded standoffs.
5. Make sure the baseboard is properly seated, and tighten all screws firmly (8.0 inch-pounds).
6. Reinstall the I/O board as described earlier.
7. Reinstall the I/O riser card.
8. Reinstall the ICMB board as described earlier.
9. Connect all internal cables to the PHP I/O baseboard.
10. Reinstall the add-in boards in their original expansion slots as described earlier.
11. Connect all internal cables that go to the add-in boards installed in the expansion slots.

12. Reinstall all PCI hot plug expansion slot power switch activators and covers in their original positions.
13. Reinstall the top and PCI bus regular slot covers as described in Chapter 12.
14. Connect all peripheral device cables that go to the I/O panel on the rear of the system.
15. Run the SSU, and use the saved configuration file to restore all options to the same settings. For information about running this utility, see Chapter 5, “System Setup Utility: When to Run.”



OM07317

Figure 13-17. PHP I/O Baseboard

- A. Snap-on standoffs (two)
- B. Screws (thirteen)

MidPlane

Removing the Midplane

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top and PCI bus regular slot covers as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Remove the CPU tray as described earlier.
4. Remove the I/O Tray as described earlier.
5. Remove three screws holding the upper midplane support bracket and remove the bracket.
6. Remove four screws holding the midplane support bracket to the chassis and remove the bracket.
7. Remove and save the screws that attach the midplane to its support bracket and remove the midplane.
8. Place the midplane on a nonconductive, static-free surface, or store it in an antistatic protective wrapper.

Reinstalling the Midplane

1. Remove the midplane from the antistatic protective wrapper if you placed it in one.
2. Position the midplane on its support bracket and insert the screws loosely into the threaded standoffs.
3. Make sure the midplane is properly positioned, and tighten all screws firmly (8.0 inch-pounds).
4. Reinstall the midplane and its support bracket in the chassis.
5. Reinstall the upper midplane support bracket.
6. Reinstall the I/O Tray as described earlier.
7. Reinstall the CPU baseboard tray as described earlier.
8. Remove the top and PCI bus regular slot covers as described in Chapter 12, “Server Covers: Removing/Reinstalling.”

AC Filter and Cable

Removing the AC Filter and Cable

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Remove the CPU tray as described earlier.
4. Remove the I/O Tray as described earlier.
5. Remove and save the screws that attaches the AC filter tray to the chassis.
6. Remove and save the screws that attaches the three AC plugs to the chassis.
7. Remove the three plug retaining brackets.
8. Remove the AC filter and cable.

Reinstalling the AC Filter and Cable

1. Remove the AC filter and cable from the antistatic protective wrapper if you placed it in one.
2. Lay the cable in position inside the chassis.
3. Reinstall the three plug retaining brackets and secure with screws.
4. Reinstall the AC filter tray.
5. Reinstall the I/O Tray as described earlier.
6. Reinstall the CPU baseboard tray as described earlier.
7. Reinstall the top cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”

Peripheral Bay

Removing the Peripheral Bay


See Figure 13-18

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top and memory module covers as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Remove and save the four screws that secure the peripheral bay to the chassis.
4. Grab the CPU baseboard tray support and pull the peripheral bay from the chassis.

Reinstalling the Peripheral Bay

See Figure 13-18

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Place the peripheral bay into position and push into place using the CPU baseboard tray support.
3. Ensure that the CPU baseboard tray support engages with the CPU baseboard tray.
4. Install the four securing screws removed earlier.
5. Reinstall the top and memory module covers as described in Chapter 12, “Server Covers: Removing/Reinstalling.”



OM07350

Figure 13-18. Peripheral Bay

Peripheral Bay Backplane

Removing the Peripheral Bay Backplane


See Figure 13-19.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Remove Peripheral Bay as described earlier.
4. Tag and disconnect power and signal cable to the diskette drive and CD-ROM drive.
5. Remove and save eight securing screws and remove backplane from peripheral bay.
6. Place the board on a nonconductive, static-free surface, or store it in an antistatic protective wrapper.

Reinstalling the Peripheral Bay Backplane

See Figure 13-19.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the board from the antistatic protective wrapper if you placed it in one.
3. Position and align the board over the two alignment pins.
4. Reinstall the eight securing screws removed earlier.
5. Reinstall the peripheral bay as described earlier.



OM07355

Figure 13-19. Peripheral Bay Backplane

- A. Snap-on standoffs (two)
- B. Screws (eight)


Peripheral Bay Blindmate Board

Removing the Peripheral Bay Blindmate Board

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Remove the fan array housing as described earlier.
4. Remove the CPU tray as described earlier.
5. Remove the peripheral bay as described earlier.
6. Tag and disconnect all cables to the board.
7. Remove and save the screws that attached the board to the chassis and remove the board.
8. Place the board on a nonconductive, static-free surface, or store it in an antistatic protective wrapper.

Reinstalling the Peripheral Bay Blindmate Board

1. Remove the board from the antistatic protective wrapper if you placed it in one.
2. Attach the board to chassis.
3. Connect all cables.
4. Reinstall the peripheral bay as described earlier.
5. Reinstall the CPU tray as described earlier.
6. Reinstall the fan array housing as described earlier.
7. Reinstall the top cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”



OM07342

Figure 13-20. Peripheral Bay Blind Mate Board

A. Screw (four)

14 Removable Media Drives: Installing/Removing/Replacing

This chapter tells how to remove and reinstall removable media drives.

Warnings and Cautions

Only a *qualified service technician* is authorized to remove the server covers and to access any of the components inside the server. Before removing the covers, see “Safety Guidelines” on page 115.

Tools and Supplies You Need

- Phillips (cross-head) screwdriver (#1 bit and #2 bit)
- Small flat-bladed screwdriver
- Antistatic wrist strap (recommended)
- Pen or pencil

Equipment Log

Use the equipment log form provided in Appendix B, “Equipment Log,” to record the model and serial numbers of the server, all installed options, and any other pertinent information about the server. You will need this information when running the SSU.

Diskette Drive

The 3.5-inch diskette drive in the 3.5-inch user-accessible drive bay supports 720 KB, 1.25 MB, 1.44 MB, and 2.88 MB media. Contact your sales representative or dealer for a list of approved add-in devices.

Removing the Diskette Drive


See Figure 14-1.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the peripheral bay as described in Chapter 13, “Server Components: Removing/Reinstalling.”
3. Disconnect the power and signal cables from the 3.5-inch diskette drive.
4. Remove and save the screws that secure the drive to the 3.5-inch drive bay to the peripheral bay.
5. Pull the diskette drive and tray from the peripheral bay.
6. Remove and save the screws that secure the drive to its support tray and place it component-side up on a nonconductive, static-free surface, or store it in an antistatic protective wrapper.

Replacing the Diskette Drive

See Figure 14-1.

1. Remove the 3.5-inch diskette drive from the protective packaging, and place it component-side up on a nonconductive, static-free surface.
2. Record the model and serial numbers of the drive in your equipment log.
3. Set any jumpers or switches according to the drive manufacturer's instructions.
4. Install diskette drive in its support tray using the screws removed earlier.
5. Slide the drive into the 3.5-inch diskette drive bay until it stops.
6. Connect the power and signal cables.
7. Secure the drive to the bay with the screw you removed earlier.
8. Reinstall the peripheral bay as described in Chapter 13, “Server Components: Removing/Reinstalling”.
9. Run the SSU to specify that the diskette drive is installed in the server. For information about running this utility, see Chapter 5, “System Setup Utility: When to Run.”



OM07360

Figure 14-1. Diskette Drive

A. Screw (one)


CD-ROM Drive

The server comes with an CD-ROM drive installed in the peripheral bay. Contact your sales representative or dealer for a list of approved add-in devices.

Removing the CD-ROM Drive

See Figures 14-2, and 14-3.


1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the peripheral bay as described in Chapter 13, “Server Components: Removing/Reinstalling.”
3. Disconnect the power and the signal cables from the CD-ROM drive.
4. Squeeze the tabs on the plastic snap-in slide rails toward the drive to release it. Pull the drive out of the bay until you can access its power and signal cables.
5. Remove and save the four screws and the two snap-in slide rails from the drive.



OM07359

Figure 14-2. CD-ROM Drive

- A. CD-ROM Drive
- B. Plastic snap-in slide rail
- C. Tab
- D. Power cable
- E. Signal cable



OM06742

Figure 14-3. Snap-in Plastic Slide Rails

- A. CD-ROM drive
- B. Tab
- C. Screw
- D. Slide rail

Replacing the CD-ROM Drive

See Figures 14-2, and 14-3.

1. Remove the CD-ROM drive from the protective packaging, and place it on an antistatic surface.
2. Record the model and serial numbers of the drive in your equipment log.
3. Set any jumpers and switches on the drive according to the manufacturer's instructions.
4. Using two screws of the appropriate size and length (not supplied), attach each plastic slide rail to the drive.
5. Orient the drive so that the slide rails engage in the bay guide rails and push the drive into the bay until the slide rails lock in place.
6. Connect the power signal cables to the drive.
7. Reinstall the peripheral bay as described in Chapter 13, "Server Components: Removing/Reinstalling"
8. This step is optional. Run the SSU or Setup to specify that the CD-ROM drive is the boot device. For information about running these utilities, see Chapter 5, "System Setup Utility: When to Run," and Chapter 4, "Setup Utility: When to Run."

15 Midplane: Description/Voltages

This chapter describes the midplane.

Warnings and Cautions

Only a *qualified service technician* is authorized to remove the server covers and to access any of the components inside the server. Before removing the covers, see “Safety Guidelines” on page 115.

Midplane Features

The midplane distributes the power load—CPU and PHP I/O baseboards, memory modules, peripheral bays, and hot-swap hard disk backplane—among two or three 750 watt autoranging power supplies. It also provides a bus interface for the CPU and PHP I/O baseboards, memory modules, and the hot-swap hard disk backplane. The midplane provides the following voltages and maximum currents:

Voltage	Maximum Current
+12 V	56 A
+5 V	68 A
+3.3 V	61 A
5 V standby	1 A
-12 V	1 A
+24 V Bias	100 mA

I²C Bus

The private I²C bus monitors failures and voltage margining in the server. The 5 V standby voltage provides power for the bus, and it is available even when the server power is off.


Detection Signals

Signal Name	Description
Present	When the presence detect line is low, the power supply is present.
AC OK	When the power-good signal on the midplane goes high, it signifies that all power supply voltages are available and stable.
Predictive Failure	The predictive failure signal from the power supply alerts the front panel controller (FPC) in case the supply is likely to fail because of a poorly performing fan—running at a slower RPM than normal. When the signal goes high, the FPC warns the user about the upcoming failure but it does not shut down the power supply.
Fault	When the fault signal from the power supply goes low, it indicates that the power supply has failed. To clear the fault, you must remove and reapply AC power to the power supply.
Power On	When the power-on signal on the midplane goes high, the power supplies power up if there is no 240 VA shutdown condition.

5 V Quick Discharge

The quick discharge circuit speeds up discharging the 5 V bus after power is turned off. The circuit starts discharging the bus as the voltage drops to around 1 V.

Midplane Connectors



OM07339

Figure 15-1. Midplane

- A. Grand connector
- B. Memory module connector (J6)
- C. Peripheral power connector (J11)
- D. Memory module connector (J7)

Grand Connector

Pins on this connector extend through the midplane and connect with both the CPU baseboard and the PHP I/O baseboard.

F16 and Front Panel Connector, J3

Pins	Signals				
	A	B	C	D	E
1	COM2_TO_FP_EN	GROUND	GROUND	COM2_TO_SIO_EN	PIC_CLK
2	IO_TCK	XIMB_SOUT_EN	SIN_TTL_COM2	STPCLK_L	GROUND
3	IO_TDO	GROUND	IO_TMS	IO_TRST_L	PICD(1)
4	BMC_SPI_BUS(1)	IO_TDI	PWRGDB	PICD(0)	GROUND
5	BMC_SPI_BUS(6)	GROUND	A20M_L	INIT_L	unused
6	BMC_SPI_BUS(0)	CPU_SPI_RESET_L	PROC_RESET_L	GROUND	GROUND
7	I2C_BMC_SCL	GROUND	GROUND	BMC_SPI_BUS(2)	BMC_SPI_BUS(4)
8	I2C_BMC_SDA	BMC_SPI_BUS(3)	BMC_SPI_BUS(5)	GROUND	GROUND
9	NMI_5V	GROUND	SMI_L	X0IB_L	CIB_INT(0)
10	GROUND	IGNNE_L	I2C_GLOBAL_SDA	IO_PWRGD	GROUND
11	X0D_L(0)	GROUND	GROUND	I2C_GLOBAL_SCL	INTR
12	X0D_L(1)	X0XRTS_L	X0HRTS_L	GROUND	GROUND
13	X0D_L(3)	GROUND	GROUND	DSEL0_L	FERR_L
14	X0D_L(4)	X0D_L(2)	X0BE_L(0)	GROUND	GROUND
15	GROUND	GROUND	GROUND	DCMPLTA_L	X0BLK_L
16	X0D_L(6)	X0D_L(5)	X0PAR_L	GROUND	GROUND
17	X0D_L(8)	GROUND	GROUND	SIN_TTL_XIMB	X0RST_L
18	X0D_L(9)	X0D_L(7)	X0ADS_L	GROUND	GROUND
19	GROUND	GROUND	X0D_L(11)	SOUT_TTL_COM2	SOUT_TTL_XIMB
20	X0D_L(12)	X0D_L(10)	X0BE_L(1)	GROUND	DCD_TTL_FP
21	X0D_L(14)	GROUND	X0XSTBN_L	X0XSTBP_L	GROUND
22	X0D_L(15)	X0D_L(13)	GROUND	GROUND	WDEVT_L
23	GROUND	GROUND	DOFF0_L	X0HSTBP_L	GROUND
24	X0CLK	GROUND	GROUND	X0HSTBN_L	DCMPLTB_L
25	GROUND	DVALIDA_L	DSR_TTL_FP	ISP_MODE	ISP_EN_L
26	CTS_TTL_FP	DOFF1_L	GROUND	ISP_SCLK	GROUND
27	RI_TTL_FP	GROUND	ISP_FPC_SDO	ISP_FPC_EN_L	-12V
28	ISP_SDO	RTS_TTL_FP	GROUND	-12V	GROUND
29	INTRUSION_L	GROUND	DTR_TTL_FP	DVALIDB_L	CPU_SLP_L
30	ISP_SDI	FAN_FAILED_L	SPEAKER_DATA	GROUND	GROUND
31	VCC_STDBY	GROUND	GROUND	FP_TO_PII4_PWRBTN	SECURE_MODE_BMC
32	I2C_FPC_SCL	VCC_STDBY	HARD_RESET	DSEL1_L	GROUND
33	I2C_FPC_SDA	GROUND	GROUND	X1IB_L	PWR_GOOD
34	GROUND	DS2P_I2C_SDA	DS2P_I2C_SCL	PS_PWR_ON	GROUND

continued

F16 and Front Panel Connector, J3 (continued)

Pins	Signals				
	A	B	C	D	E
35	X1D_L(0)	GROUND	GROUND	FP_NMI_SWT_L	PWR_CNTRL_SFC_L
36	X1D_L(1)	X1XRTS_L	X1HRTS_L	GROUND	GROUND
37	X1D_L(3)	GROUND	GROUND	PWR_CNTRL_RTC_L	I2C_CEL_CONNECT_FPC
38	X1D_L(4)	X1D_L(2)	X1BE_L(0)	GROUND	GROUND
39	GROUND	GROUND	GROUND	I2C_CEL_CONNECT_BMC	X1BLK_L
40	X1D_L(6)	X1D_L(5)	X1PAR_L	GROUND	GROUND
41	X1D_L(8)	GROUND	GROUND	I2C_BACKUP_SCL	X1RST_L
42	X1D_L(9)	X1D_L(7)	X1ADS_L	GROUND	GROUND
43	GROUND	GROUND	X1D_L(11)	I2C_BACKUP_SDA	MIOC_INTREQ_L
44	X1D_L(12)	X1D_L(10)	X1BE_L(1)	GROUND	GROUND
45	X1D_L(14)	GROUND	X1XSTBN_L	X1XSTBP_L	GROUND
46	X1D_L(15)	X1D_L(13)	GROUND	GROUND	GROUND
47	GROUND	GROUND	5V_SENSE	X1HSTBP_L	GROUND
48	X1CLK	5V_RET_SENSE	GROUND	X1HSTBN_L	GROUND

Grand Connector to Mem A, J4 and Mem B, J1

Pins	Signals				
	A	B	C	D	E
1	MD#(35)	GND	MD#(34)	GND	MD#(33)
2	GND	MD#(32)	GND	MD#(31)	+1.5V
3	MD#(30)	GND	DSTBN1#	GND	MD#(29)
4	GND	MD#(28)	GND	MD#(27)	GND
5	MD#(26)	GND	DSTBP1#	GND	MD#(25)
6	GND	MD#(24)	GND	MD#(23)	+1.5V
7	MD#(22)	GND	MD#(21)	GND	MD#(20)
8	GND	GND	GND	MD#(19)	GND
9	MUXCLK0	GND	MD#(17)	GND	MD#(18)
10	GND	GND	GND	<i>Was DSEL#</i>	GND
11	MRESET#	GND	<i>Was DOFF0_L</i>	GND	<i>Was DOFF1_L</i>
12	GND	MD#(16)	GND	MD#(15)	+1.5V
13	MD#(14)	GND	MD#(13)	GND	MD#(12)
14	GND	MD#(11)	GND	MD#(10)	GND
15	MD#(9)	GND	DSTBP0#	GND	MD#(8)
16	GND	MD#(7)	GND	MD#(6)	+1.5V
17	MD#(5)	GND	DSTBN0#	GND	MD#(4)
18	GND	MD#(3)	GND	GND	GND
19	MD#(2)	GND	MD#(1)	GND	SPARECLK0
20	GND	MD#(0)	GND	GND	GND
21	TCK	GND	TDI	GND	TMS
22	GND	TRST#	GND	MA#(13)	GND
23	MA#(12)	GND	MA#(11)	GND	MA#(10)
24	GND	MA#(9)	GND	MA#(8)	+1.5V
25	MA#(7)	GND	MA#(6)	GND	MA#(5)
26	GND	MA#(4)	GND	GND	GND
27	MA#(3)	GND	MA#(2)	GND	RCGCLK
28	GND	MA#(1)	GND	GND	GND
29	MA#(0)	GND	CSTB#	GND	ROW#
30	GND	CMND1#	GND	BANK0#	+1.5V
31	BANK1#	GND	BANK2#	GND	CMND0#
32	GND	CARD#	GND	GND	GND
33	PHIT#	GND	RCMPLT#	GND	SPARECLK1
34	GND	RHIT#	GND	GND	GND
35	Unused	GND	Unused	GND	Unused
36	GND	MD#(71)	GND	MD#(70)	GND
37	MD#(69)	GND	MD#(68)	GND	MD#(67)
38	GND	MD#(66)	GND	MD#(65)	+1.5V
39	MD#(64)	GND	DSTBN3#	GND	MD#(63)

continued

Grand Connector to Mem A, J4 and Mem B, J1 (continued)

Pins	Signals				
	A	B	C	D	E
40	GND	MD#(62)	GND	MD#(61)	GND
41	MD#(60)	GND	DSTBP3#	GND	MD#(59)
42	GND	GND	GND	MD#(58)	GND
43	MUXCLK1	GND	MD#(56)	GND	MD#(57)
44	GND	GND	GND	MD#(55)	GND
45	MD#(54)	GND	Unused	GND	<i>Was DCMLPT#</i>
46	GND	<i>Was DVALID#</i>	GND	<i>Was WDEVT#</i>	+1.5V
47	MD#(53)	GND	MD#(52)	GND	MD#(51)
48	GND	MD#(50)	GND	MD#(49)	GND
49	MD#(48)	GND	DSTBP2#	GND	MD#(47)
50	GND	MD#(46)	GND	MD#(45)	+1.5V
51	MD#(44)	GND	DSTBN2#	GND	MD#(43)
52	GND	MD#(42)	GND	MD#(41)	GND
53	MD#(40)	GND	MD#(39)	GND	MD#(38)
54	GND	MD#(37)	GND	MD#(36)	+1.5V

Grand Connector Power Module 1 Connector J2

Pins	Signals				
	A	B	C	D	E
P1X1	GND	GND	12V	12V	3.3V
P1X2	GND	GND	12V	12V	3.3V
P1X3	GND	GND	12V	12V	3.3V
P2X1	GND	GND	12V	12V	3.3V
P2X2	GND	GND	12V	12V	3.3V
P2X3	GND	GND	12V	12V	3.3V
P1X1	GND	GND	12V	5V	3.3V
P1X2	GND	GND	12V	5V	3.3V
P1X3	GND	GND	12V	5V	3.3V
P2X1	GND	GND	12V	5V	3.3V
P2X2	GND	GND	12V	5V	3.3V
P2X3	GND	GND	12V	5V	3.3V
P1X1	GND	GND	12V	5V	3.3V
P1X2	GND	GND	12V	5V	3.3V
P1X3	GND	GND	12V	5V	3.3V
P2X1	GND	GND	12V	5V	3.3V
P2X2	GND	GND	12V	5V	3.3V
P2X3	GND	GND	12V	5V	3.3V

Grand Connector Power Module 2 Connector J5

Pins	Signals				
	A	B	C	D	E
P1X1	GND	GND	12V	5V	3.3V
P1X2	GND	GND	12V	5V	3.3V
P1X3	GND	GND	12V	5V	3.3V
P2X1	GND	GND	12V	5V	3.3V
P2X2	GND	GND	12V	5V	3.3V
P2X3	GND	GND	12V	5V	3.3V
P1X1	GND	GND	12V	5V	5V
P1X2	GND	GND	12V	5V	5V
P1X3	GND	GND	12V	5V	5V
P2X1	GND	GND	12V	5V	5V
P2X2	GND	GND	12V	5V	5V
P2X3	GND	GND	12V	5V	5V
P1X1	GND	GND	12V	5V	5V
P1X2	GND	GND	12V	5V	5V
P1X3	GND	GND	12V	5V	5V
P2X1	GND	GND	12V	5V	5V
P2X2	GND	GND	12V	5V	5V
P2X3	GND	GND	12V	5V	5V

Memory Board 1 & 2 Interface Connector J6 & J7

Pins	Signals				
	A	B	C	D	E
1	GND	MD#(36)	GND	MD#(37)	+3.3V
2	GDCMPLT#	+3.3V	DSTBN2#	GND	MD#(38)
3	GND	MD#(39)	GND	MD#(40)	+3.3V
4	MD#(41)	+3.3V	DSTBP2#	GND	MD#(42)
5	GND	MD#(43)	GND	MD#(44)	+3.3V
6	MD#(45)	+3.3V	MD#(46)	GND	MD#(47)
7	GND	MD#(48)	GND	MD#(49)	+3.3V
8	MD#(50)	+3.3V	MD#(51)	GND	MD#(52)
9	GND	MD#(53)	GND	WDEVT#	+3.3V
10	DCMPLT#	+3.3V	MD#(54)	GND	DVALID#
11	GND	GND	+1.5V	MD#(55)	+3.3V
12	MUXCLK1	GND	MD#(56)	GND	MD#(57)
13	GND	GND	+1.5V	MD#(58)	+3.3V
14	MD#(59)	+3.3V	DSTBP3#	GND	MD#(60)
15	GND	MD#(61)	GND	MD#(62)	+3.3V
16	MD#(63)	+3.3V	DSTBN3#	GND	MD#(64)
17	GND	MD#(65)	GND	MD#(66)	+3.3V
18	+1.5V	+3.3V	MD#(67)	GND	MD#(68)
19	GND	MD#(69)	GND	MD#(70)	+3.3V
20	MD#(71)	+3.3V	+3.3V	GND	+3.3V
21	GND		GND		+3.3V
22	+3.3V	+3.3V	CARD_NUM	GND	I2C_BMC_SCL
23	GND	GND	+1.5V	PWRGD	+3.3V
24	SPARECLK1	GND	PHIT#	GND	I2C_BMC_SDA
25	GND	GND	+1.5V	RHIT#	+3.3V
26	+1.5V	+3.3V	RCMPLT#	GND	+3.3V
27	GND	CARD#	GND	GRCMPLT#	+3.3V
28	CMND0#	+3.3V	BANK0#	GND	BANK1#
29	GND	BANK2#	GND	CMND1#	+3.3V
30	+1.5V	+3.3V	ROW#	GND	CSTB#
31	GND	GND	+1.5V	MA#(0)	+3.3V
32	RCGCLK	GND	MA#(1)	GND	MA#(2)
33	GND	GND	+1.5V	MA#(3)	+3.3V
34	MA#(4)	+3.3V	MA#(5)	GND	MA#(6)
35	GND	MA#(7)	GND	MA#(8)	+3.3V
36	MA#(9)	+3.3V	MA#(10)	GND	MA#(11)
37	GND	MA#(12)	GND	MA#(13)	+3.3V

continued

Memory Board 1 & 2 Interface Connector J6 & J7 (continued)

Pins	Signals				
	A	B	C	D	E
38	+1.5V	+3.3V	TMS	GND	+3.3V
39	GND	GND	+1.5V	TRST#	+3.3V
40	SPARECLK0	GND	TDI	GND	TDO
41	GND	GND	+1.5V	TCK	+3.3V
42	MD#(0)	+3.3V	MD#(1)	GND	MD#(2)
43	GND	MD#(3)	GND	MD#(4)	+3.3V
44	MD#(5)	+3.3V	DSTBN0#	GND	MD#(6)
45	GND	MD#(7)	GND	MD#(8)	+3.3V
46	MD#(9)	+3.3V	DSTBP0#	GND	MD#(10)
47	GND	MD#(11)	GND	MD#(12)	+3.3V
48	MD#(13)	+3.3V	MD#(14)	GND	MD#(15)
49	GND	DOFF1#	GND	DOFF0#	+3.3V
50	MD#(16)	+3.3V	DSEL#	GND	MRESET#
51	GND	GND	+1.5V	MD#(17)	+3.3V
52	MUXCLK0	GND	MD#(18)	GND	MD#(19)
53	GND	GND	+1.5V	MD#(20)	+3.3V
54	MD#(21)	+3.3V	MD#(22)	GND	MD#(23)
55	GND	MD#(24)	GND	MD#(25)	+3.3V
56	MD#(26)	+3.3V	DSTBP1#	GND	MD#(27)
57	GND	MD#(28)	GND	MD#(29)	+3.3V
58	GDCMPLT#	+3.3V	DSTBN1#	GND	MD#(30)
59	GND	MD#(31)	GND	MD#(32)	+3.3V
60	MD#(33)	+3.3V	MD#(34)	GND	MD#(35)

Power Supply Connectors J8, J9, & J10

Pin	Signal (Description)	Pin	Signal (Description)	Pin	Signal (Description)
1	VCC12	19	VCC12	37	VCC12
2	VCC12	20	VCC12	38	GND
3	GND	21	GND	38	GND
4	GND	22	PRED_FAIL_PSI	40	M12V (-12V)
5	VBIAS (+24V)	23	PSx_SCL (I ² C SCL)	41	PSx_SDA (I ² C SDA)
6	12V_SENSE (12V Rem.Sense)	24	PGOOD (AC OK)	42	PSx_FAULT
7	VCC5STBY	25	P5V_LS (5V Load Share)	43	P3_3V_LS (3.3V Load Share)
8	GND_SENSE (Gnd Rem. Sense)	26	P12V_LS (12V Load Share)	44	PWR_ON_SUPPLIES
9	spare	27	PSxRS3 (+3.3V Rem. Sense)	45	PSxRS5
10	spare	28	spare	46	PSx_PRESENT
11	GND	29	GND	47	GND
12	GND	30	GND	48	GND
13	VCC3	31	GND	49	GND
14	VCC3	32	GND	50	GND
15	VCC3	33	GND	51	GND
16	VCC3	34	VCC5	52	VCC5
17	VCC3	35	VCC5	53	VCC5
18	VCC3	36	VCC5	54	VCC5

Peripheral Power Connector J11

Pin #	Signal:	Pin #	Signal:
1	VCC12	11	VCC12
2	GND	12	GND
3	VCC12	13	VCC12
4	VCC5	14	VCC5
5	GND	15	GND
6	VCC5	16	VCC5
7	GND	17	GND
8	I2C_GLOBAL_SCL	18	I2C_GLOBAL_SDA
9	GND	19	GND
10	PWR_GOOD	20	RESET_IIC_L

16 Peripheral Bay Backplane: Description

This chapter describes the peripheral bay backplane and lists its SCSI ID.

Warnings and Cautions

Only a *qualified service technician* is authorized to remove the server covers and to access any of the components inside the server. Before removing the covers, see “Safety Guidelines” on page 115.

Peripheral Bay Backplane

The WideUltra disk backplane supports hot-swapping of SCA-type SCSI drives, manages the enclosure (chassis), and monitors server functions conforming to the *SCSI-Accessed Fault-Tolerant Enclosures* (SAF-TE) specification. The disk backplane provides:

- an independent SCSI channel
- two SCA-2 connectors for SCA-type SCSI hard disk drives
- active terminators that terminate the backplane end of the SCSI bus (SCSI-3 compliant)
- power control for each drive that automatically powers down a slot when a drive failure is detected and reported or a drive is removed (when a new drive is inserted, the power control waits a few moments and then applies power to the new drive)
- three light-emitting diodes (LEDs) for each drive
 - power LEDs indicate the drives are receiving power
 - activity LEDs indicate the drives are being accessed
 - drive fault LEDs indicate the failure status of each drive (during server initialization, they flash for one second)
- intrachassis I²C bus
- I²C bus temperature sensor for each microcontroller
- interchassis I²C bus support, per SAF-TE specification
- serial EEPROM for nonvolatile information storage

The SCA-2 connectors on the disk backplane provide control signals and power for up to two wide/fast 3.5-inch SCA-type SCSI hard disk drives. The backplane receives control signals from a Symbios 53C896 host adapter on the PHP I/O baseboard.

The fault indicator LEDs on the front panel indicate failure status for each drive in the hot-docking bays. These indicators get their signals through a cable connected to the front panel connector on the disk backplane.

The temperature sensor on the disk backplane provides temperature information to other devices in the server through enclosure service messages.


The disk backplane power control provides powering down of a drive when a failure is detected and reported to the SCSI bus through enclosure service messages. When a new drive is inserted in an SCA connector, the power control waits a short time for the drive to become fully seated and

then applies power to the drive. Power control also lets you insert and store a spare drive in an SCA connector. When a drive fails, the spare drive can be put into service.

SCSI ID Configurations

The SCSI chip on the peripheral bay backplane uses the SAF-TE protocol to communicate with the I/O baseboard and uses SCSI ID 6.

Peripheral Bay Backplane Connectors



OM07352

Figure 16-1. Peripheral Bay Backplane

- A. SCSI Hot-Swap connector
- B. SCSI Hot-Swap connector
- C. Power connector
- D. Diskette connector
- E. IDE connector
- F. Power connector
- G. Blindmate connector
- H. SCSI connector

17 PHP I/O Baseboard: Description/Setting Configuration Jumpers

This chapter describes the PHP I/O baseboard and tells how to configure the jumpers.

Warnings and Cautions

Only a *qualified service technician* is authorized to remove the server covers and to access any of the components inside the server. Before removing the covers, see “Safety Guidelines” on page 115.

PHP Input/Output (I/O) Baseboard Features

The PHP I/O baseboard provides the primary I/O interface of the server. The baseboard also interfaces with the CPU baseboard through the Midplane. The PHP I/O baseboard provides:

- three functionally independent PCI buses
 - 32-bit primary PCI bus
 - 32-bit secondary PCI bus
 - 64-bit PCI bus
- integrated Symbios 53C896 Dual Channel LVDS controller
- integrated IDE controller that supports one IDE bus
- onboard video, serial, parallel, and universal serial bus (USB) ports
- user-accessible expansion slots
 - five 32-bit regular PCI bus slots
 - four 64-bit hot-plug PCI bus slots
 - one shared 16-bit ISA/32-bit PCI bus slot
- I²C server management interface

32-bit PCI Expansion Slots

Six 32-bit PCI bus master slots (two primary and four secondary) on the PHP I/O baseboard provide expansion enhancement. One 32-bit primary slot shares a common chassis expansion slot with the ISA slot; you can use the shared slot for either PCI or ISA but not both. The PCI bus operates at 33 MHz and provides:

- 32-bit memory addressing
- +3.3 V and +5 V environments
- burst transfers of up to 133 MB/sec
- 8-, 16-, or 32-bit data transfers
- plug and play configuration
- hierarchical bus to maximize connectivity

⇒ NOTE

Add-in video boards must be installed in the 32-bit primary PCI slots.

64-bit PCI Hot-plug Expansion Slots

Four 64-bit PCI hot-plug bus master slots on the PHP I/O baseboard provide maximum performance at the wider bus width.

⇒ NOTE

Both 32-bit and 64-bit PCI boards may be installed in the 64-bit slots. However, the 32-bit boards will not take advantage of the extra bandwidth provided by the 64-bit bus.

Add-in video boards must be installed in the 32-bit primary PCI slots.

ISA Expansion Slot

The ISA bus master slot on the PHP I/O baseboard provides for legacy expansion. The ISA slot shares a common chassis I/O expansion slot with a 32-bit PCI slot; you can use the shared slot for either ISA or PCI but not both. The ISA bus operates at up to 8.33 MHz and provides

- 24-bit memory addressing
- type A transfers at 5.33 MB per second
- type B transfers at 8 MB per second
- 8- or 16-bit data transfers
- interrupt sharing

PCI Video Controller

The onboard Cirrus Logic GD5446 PCI VisualMedia accelerator is a 64-bit DRAM-based SVGA controller with hardware-accelerated BitBLT transfers of data, video playback, and video capture to the frame buffer. The frame buffer is addressable through a 16-Mbyte window consisting of three, 4-Mbyte byte-swapping apertures, and a special video aperture. The SVGA controller also features a 64-bit GUI BitBLT engine with double-buffered, memory-mapped control registers. The control registers are relocatable anywhere in the 64-Kbyte space; this allows multiple devices in a single server.

The SVGA controller is fully compatible with these video standards: CGA, EGA, Hercules graphics, MDA, and VGA. The server comes with 2 MB of onboard video DRAM allowing the controller to support 132-column text modes and high resolution graphics with 1280 x 1024 x 16 colors. Depending on the environment, the controller displays up to 16.7 M colors in some video resolutions.

The SVGA controller supports analog VGA monitors (single and multiple frequency, interlaced and noninterlaced) with a maximum vertical retrace interlaced frequency of 87 Hz.

Video Modes

The CL-GD5446 provides all the standard IBM VGA modes. The following tables show all the supported video modes.

Standard VGA Modes

Modes in Hex	Colors (number/palette size)	Char. x Row	Char. Cell	Resolution	Display Mode	Pixel Freq. (MHz)	Horiz. Freq. (KHz)	Vert. Freq. (Hz)
0, 1	16/256K	40 x 25	9 x 16	360 X 400	Text	14	31.5	70
2, 3	16/256K	80 x 25	9 x 16	720 X 400	Text	28	31.5	70
4, 5	4/256K	40 x 25	8 x 8	320 X 200	Graphics	12.5	31.5	70
6	2/256K	80 x 25	8 x 8	640 X 200	Graphics	25	31.5	70
7	Mono	80 x 25	9 x 16	720 X 400	Text	28	31.5	70
D	16/256K	40 x 25	8 x 8	320 X 200	Graphics	12.5	31.5	70
E	16/256K	80 x 25	8 x 14	640 X 200	Graphics	25	31.5	70
F	Mono	80 x 25	8 x 14	640 X 350	Graphics	25	31.5	70
10	16/256K	80 x 25	8 x 14	640 X 350	Graphics	25	31.5	70
11	2/256K	80 x 30	8 x 16	640 X 480	Graphics	25	31.5	60
11*	2/256K	80 x 30	8 x 16	640 X 480	Graphics	31.5	37.9	72
11*	2/256K	80 x 30	8 x 16	640 X 480	Graphics	31.5	37.5	75
12	16/256K	80 x 30	8 x 16	640 X 480	Graphics	25	31.5	60
12*	16/256K	80 x 30	8 x 16	640 X 480	Graphics	31.5	37.9	72
12*	16/256K	80 x 30	8 x 16	640 X 480	Graphics	31.5	37.5	75
12*	16/256K	80 x 30	8 x 16	640 X 480	Graphics	35.8	43.3	85
13	256/256K	40 x 25	8 x 8	320 X 200	Graphics	12.5	31.5	70

Extended VGA Modes

Mode(s) in Hex	Colors (number/ palette size)	Char. x Row	Char. Cell	Resolution	Pixel Freq. (MHz)	Horiz. Freq. (KHz)	Vert. Freq. (Hz)
58, 6A	16/256K	100 x 37		800 X 600	36	35.2	56
58, 6A	16/256K	100 x 37		800 X 600	40	37.8	60
58, 6A	16/256K	100 x 37		800 X 600	50	48.1	72
58, 6A	16/256K	100 x 37		800 X 600	49.5	46.9	75
5C	256/256K	100 x 37		800 X 600	36	35.2	56
5C	256/256K	100 x 37		800 X 600	40	37.9	60
5C	256/256K	100 x 37		800 X 600	50	48.1	72
5C	256/256K	100 x 37		800 X 600	49.5	46.9	75
5C	256/256K	100 x 37		800 X 600	56.25	53.7	85
5D*	16/256K	128 x 48		1024 X 768	44.9	35.5	43
5D	16/256K	128 x 48		1024 X 768	65	48.3	60
5D	16/256K	128 x 48		1024 X 768	75	56	70
5D*	16/256K	128 x 48		1024 X 768	77	58	72
5D	16/256K	128 x 48		1024 X 768	78.5	60	75
5E	256/256K	80 x 25		640 x 400	25	31.5	70
5F	256/256K	80 x 30		640 X 480	25	31.5	60
5F	256/256K	80 x 30		640 X 480	31.5	37.9	72
5F	256/256K	80 x 30		640 X 480	31.5	37.5	75
5F	256/256K	80 x 30		640 X 480	36	43.3	85
60*	256/256K	128 x 48		1024 X 768	44.9	35.5	43
60	256/256K	128 x 48		1024 X 768	65	48.3	60
60	256/256K	128 x 48		1024 X 768	75	56	70
60	256/256K	128 x 48		1024 X 768	77	58	72
60	256/256K	128 x 48		1024 X 768	78.7	60	75
60	256/256K	128 x 48		1024 X 768	94.5	68.3	85
64	64K	-	-	640 X 480	25	31.5	60
64	64K	-	-	640 X 480	31.5	37.9	72
64	64K	-	-	640 X 480	31.5	37.5	75
64	64K	-	-	640 X 480	36	43.3	85
65	64K	-	-	800 X 600	36	35.2	56
65	64K	-	-	800 X 600	40	37.8	60
65	64K	-	-	800 X 600	50	48.1	72
65	64K	-	-	800 X 600	49.5	46.9	75
65	64K	-	-	800 X 600	56.25	53.7	85
66	32K [‡]	-	-	640 X 480	25	31.5	60
66	32K [‡]	-	-	640 X 480	31.5	37.9	72

* Interlaced Mode. ‡ 32K Direct-Color/256-Color Mixed Mode.

continued

Extended VGA Modes (continued)

Mode(s) in Hex	Colors (number/ palette size)	Char. x Row	Char. Cell	Resolution	Pixel Freq. (MHz)	Horiz. Freq. (KHz)	Vert. Freq. (Hz)
66	32K [‡]	-	-	640 X 480	31.5	37.5	75
66	32K [‡]	-	-	640 X 480	36	43.3	85
67	32K [‡]	-	-	800 X 600	36	35.2	56
67	32K [‡]	-	-	800 X 600	40	37.8	60
67	32K [‡]	-	-	800 X 600	50	48.1	72
67	32K [‡]	-	-	800 X 600	49.5	46.9	75
67	32K [‡]	-	-	800 X 600	56.25	53.7	85
68	32K [‡]	-	-	1024 x 768	44.9	35.5	43
68	32K [‡]	-	-	1024 x 768	65	48.3	60
68	32K [‡]	-	-	1024 x 768	75	56	70
68	32K [‡]	-	-	1024 x 768	78.7	60	75
68	32K [‡]	-	-	1024 x 768	94.5	68.3	85
69*	32K [‡]	-	-	1280 x 1024	75	48	43
69*	32K [‡]	-	-	1280 x 1024	108	65	60
6C*	16/256K	160 x 64	8 x 16	1280 X 1024	75	48	43
6D*	256/256K	160 x 64	8 x 16	1280 X 1024	75	48	43
6D	256/256K	160 x 64	8 x 16	1280 X 1024	108	65	60
6D	256/256K	160 x 64	8 x 16	1280 X 1024	126	76	71.2
6D	256/256K	160 x 64	8 x 16	1280 X 1024	135	80	75
71	16M	-	-	640 X 480	25	31.5	60
71	16M	-	-	640 X 480	31.5	37.9	72
71	16M	-	-	640 X 480	31.5	37.5	75
71	16M	-	-	640 X 480	36	43.3	85
74*	64K [‡]	-	-	1024 X 768	44.9	35.5	43
74	64K	-	-	1024 X 768	65	48.3	60
74	64K	-	-	1024 X 768	75	56	70
74	64K	-	-	1024 X 768	78.7	60	75
74	64K	-	-	1024 X 768	94.5	68.3	85
75*	64K [‡]	-	-	1280 X 1024	75	48	43
78	16M	-	-	800 x 600	36	35.2	56
78	16M	-	-	800 x 600	40	37.8	60
78	16M	-	-	800 x 600	50	48.1	72
78	16M	-	-	800 x 600	49.5	46.9	75
78	16M	-	-	800 x 600	56.25	53.7	85
79	16M	-	-	800 x 600	44.9	35.5	43
79	16M	-	-	1024 x 768	65	48.3	60

* Interlaced Mode. ‡ 32K Direct-Color/256-Color Mixed Mode.

continued

Extended VGA Modes (continued)

Mode(s) in Hex	Colors (number/ palette size)	Char. x Row	Char. Cell	Resolution	Pixel Freq. (MHz)	Horiz. Freq. (KHz)	Vert. Freq. (Hz)
79	16M	-	-	1024 x 768	75	56	70
79	16M	-	-	1024 x 768	78.7	60	75
79	16M	-	-	1024 x 768	94.5	68.3	85
7C	256/256K	144 x 54	8 x 16	1152 x 864	94.5	63.9	70
7C	256/256K	144 x 54	8 x 16	1152 x 864	108	67.5	75
7D	64K	-	-	1152 x 864	94.5	63.9	70
7D	64K	-	-	1152 x 864	94.5	67.5	75

* Interlaced Mode. ‡ 32K Direct-Color/256-Color Mixed Mode.

Symbios 53C896 SCSI Controller

A Symbios 53C896 LVDS SCSI controller provides embedded SCSI on the primary 32-bit PCI bus. The configuration registers define PCI-related parameters for the 53C896 device. The 53C896 supports all mandatory registers in the PCI configuration space header, including the vendor ID, device ID, class code, revision ID, header type, and command and status fields.

The 53C896 supports two LVDS channels. One channel controls slow devices such as CD-ROMs, and DVDs; the other channel provides a high speed connection to the internal LVDS drives or an external disk array.

IDE Controller

The PIIX4 multifunction device on the PHP I/O baseboard acts as a PCI-based Fast IDE controller that supports:

- PIO and IDE DMA/bus master operations
- Mode 4 timings
- transfer rates up to 33 MB/sec
- buffering for PCI/IDE burst transfers
- master/slave IDE mode

Server Management (SM)

During normal operation, SM receives information about the status of the server. SM also monitors the power supply voltages and operating temperature of the server. If SM determines that the server is not operating within specified limits, it attempts to notify a supervisor or an administrator about the condition of the server. The microcontrollers on the front panel board, disk backplane, and PHP I/O baseboard implement the server management features.

Front Panel Controller (FPC)

Where located: on the front panel board

What it manages:

- server power control consolidation from several sources
 - push-button power signal from the front panel connector
 - real-time clock (RTC)
 - server monitor module (SMM), if installed
 - commands from the Intelligent Platform Management Bus (IPMB)
- power and reset switch interfaces
- fault LEDs
- chassis, midplane and power supplies Field Replacement Unit (FRU) inventory interface
- server hard reset generation
- server power fault indication
- Intelligent Chassis Management Bus (ICMB) bridge device
- EMP connection
- LCD interface

Board Management Controller (BMC)

Where located: on the PHP I/O baseboard

What it provides:

- temperature and voltage monitoring of the I/O and CPU baseboards
- threshold comparison functions
- SMI (systems management interrupt) generation
- watchdog timer and certain GPIO (general purpose input/output) functions
- fault-resilient booting
- processor presence, Voltage ID (VID), IERR, and thermal trip monitoring
- server event log, event time stamping, sensor data record information, and DIMM ID information interface
- current event status and sensor readings when polled by System Management Software

Hot-swap Controller (HSC)

Where located: on the disk backplane


What it does:

- implements the SAF-TE command set
- controls the fault lights and drive power-on
- provides a path for management information via SCSI
- retrieves drive fault status, backplane temperature, and fan failure information via the IPMB
- queries the status of the front panel controller for power supply information
- controls drive power-on and power-down, facilitating hot-swapping

I/O Riser Card

The I/O riser card contains all the legacy I/O connections such as video, keyboard, mouse, etc. The card plugs into the legacy connector on the PHP I/O baseboard and provides the following external connectors:

- PS/2-compatible keyboard (interchangeable with the mouse)
- PS/2-compatible mouse (interchangeable with the keyboard)
- parallel port
- two serial ports
- VGA video port
- ICMB connector interface




OM08099

Figure 17-1. I/O Riser Card

- A. I/O riser card
- B. USB (connectors mounted on PHP I/O baseboard)
- C. Parallel port
- D. Video port
- E. Serial port 2
- F. Serial port 1
- G. Keyboard port
- H. Mouse port
- I. ICMB connector

PHP I/O Baseboard Configuration Jumpers

You can use the configuration jumpers on the PHP I/O baseboard to recover a BIOS, clear a CMOS password, or clear all CMOS settings. Figure 17-2 shows the jumper positions for the default system configuration. The reserved pins may not be populated in shipping configurations. Table 17-1 shows the minimum default configurations in bold face type.



OM08476

Figure 17-2. J2C1 Configuration Jumper Block

Table 17-1. Configuration Jumpers (J2C1)

Pins (default in bold)	Function
1(B-C)	Disable programming onboard programmable devices
1(A-B)	Allow programming of onboard programmable devices
2(B-C)	Normal boot
2(A-B)	Boot Recovery BIOS
3(B-C)	Reserved
3(A-B)	Reserved
4(B-C)	Allow BIOS flash update
4(A-B)	Disable BIOS flash update
5(B-C)	Do not clear CMOS
5(A-B)	Clear CMOS
6(B-C)	Do not clear password
6(A-B)	Clear password
7(B-C)	Do not override PHP switches
7(A-B)	Override PHP switches
8(B-C)	Disable I/O SPI chain
8(A-B)	Allow I/O SPI chain

Restoring CMOS to Default Values

The jumper on J2C1 pins 5(B-C) preserves the settings stored in CMOS nonvolatile memory (NVRAM) during server reset. Moving the jumper to pins 5(A-B) clears CMOS and sets it and the real-time clock (RTC) to the Setup default values during server reset.

To clear CMOS and restore the Setup default values:

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Turn off the server, and unplug the AC power cords from the power supplies or wall outlets.
3. Remove the top and right side covers. See Chapter 12, “Server Covers: Removing/Reinstalling.”
4. Move the jumper on J2C1 from pins 5(B-C) to pins 5(A-B).
5. Reinstall the covers, and plug in the power cords.
6. Turn on the server, and wait for POST to complete. This automatically restores CMOS and RTC to Setup default values. See Chapter 3, “Power-on Self Test: Description/Running.”
7. Turn off the server, unplug the power cords, and remove the top and right side covers.
8. Move the jumper from J2C1 pins 5(A-B) to pins 5(B-C).
9. Reinstall the covers, and plug in the power cords.
10. Run the SSU to configure your server. See Chapter 5, “System Setup Utility: When to Run.”

Clearing the Password

The jumper on J2C1 pins 6(B-C) protects the CMOS password during server reset. Moving the jumper to pins 6(A-B) clears the password during server reset.

To clear the CMOS password:

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Turn off the server, and unplug the AC power cords from the power supplies or wall outlets.
3. Remove the top and right side covers. See Chapter 12, “Server Covers: Removing/Reinstalling.”
4. Move the jumper from J2C1 pins 6(B-C) to pins 6(A-B).
5. Reinstall the covers, and plug in the power cords.
6. Turn on the server, and wait for POST to complete. This automatically clears the password. See Chapter 3, “Power-on Self Test: Description/Running.”
7. Turn off the server, unplug the power cords, and remove the top and right side covers.
8. Move the jumper from J2C1 pins 6(A-B) to pins 6(B-C).
9. Reinstall the covers, and plug in the power cords.
10. Run the SSU to configure your server. See Chapter 5, “System Setup Utility: When to Run.”

Updating the BIOS

The jumper on J2C1 pins 4(B-C) applies +12 V power to the VPP pin on the flash memory device. This allows you to update the BIOS in flash memory with the Flash Update Utility. Moving the jumper to pins 4(A-B) protects the contents of flash memory.

⇒ NOTE

For a copy of the latest system BIOS release to create a Flash update utility diskette, contact your dealer or sales representative.

Before you can update the system BIOS from the Flash Update Utility diskette, you must make the diskette MS-DOS bootable. You must have either MS-DOS version 5.00 or 6.00 (or greater) installed on C:\DOS. To prevent accidentally installing a BIOS for a different type of system, the update utility insures that the BIOS matches the target system.

⇒ NOTE

Please review the update utility instructions and the release notes distributed with the update utility and BIOS code before attempting to update the BIOS.

The BIOS update utility allows you to update the

- BIOS in flash memory
- user and logo area of the BIOS
- language section of the BIOS

Recording the Current BIOS Settings

Before updating the BIOS, record your current BIOS settings. You will need them to configure your server at the end of the update procedure.

1. Turn on your video monitor and your server. Each time you turn on or reboot your server POST begins and, after a few seconds, displays this message:
Press <F2> to enter Setup
2. After pressing F2, a few seconds may pass before entering Setup while POST completes tests and initialization functions. When Setup is entered, write down the current settings.

Creating the BIOS Update Diskette

The BIOS update file is a compressed self-extracting archive that contains the files you need to update the BIOS.

1. Copy the BIOS update file to a temporary directory on your hard disk.
2. From the C:\ prompt, change to the temporary directory.
3. To extract the file, type the name of the BIOS update file; for example, type `10006BI1.EXE` and press <Enter>. The extracted files include
 - LICENSE.TXT—software license agreement
 - README.TXT—instructions for the BIOS update
 - BIOINSTR.TXT—instructions for creating a bootable diskette
 - BIOS.EXE—BIOS update software
4. Insert the bootable diskette into drive A.
5. Change to the temporary directory that holds the BIOS.EXE file.
6. Type `BIOS A:` and press <Enter> to extract the BIOS.EXE file to the diskette.

⇒ NOTE

If the extracted files do not include the BIOS.EXE file, you must extract the BIOS update file directly to the bootable diskette in drive A.

Example: type `10006BI1 A:` and press <Enter>.

Running the BIOS Update Utility

Remember to write down the current BIOS settings before running the BIOS update utility.

1. Observe the precautions on page 111, “Safety Guidelines.”
2. Insert the update diskette into drive A, and turn on the monitor and server. When the server boots from the diskette, follow the screen prompts.

If you choose option 1, the server will automatically reboot after the update process completes so that the changes will take effect. Remove the diskette when the server starts to boot.

If you choose option 2, you must reboot the server by pressing reset or <Enter> after the update process completes for the changes to take effect. Remove the diskette when the server starts to boot.
3. As the server boots, check the BIOS identifier—version number—to make sure the update was successful.

4. When the following message appears, press <F2>.

Press <F2> to enter SETUP
5. After entering Setup, press <F9> to load Setup defaults; then press <Enter> to confirm.
6. Set the Setup options to the settings you wrote down before updating the BIOS.
7. Press <F10> to exit and save the settings; then press <Enter> to confirm and to reboot the server.
8. To protect the contents of flash memory, turn off the server, unplug the power cords from the power supplies or wall outlets, and remove the top and right side covers. See Chapter 12, “Server Covers: Removing/Reinstalling.”
9. Move the jumper from J2C1B pins 4(B-C) to pins 4(A-B) to write-protect the flash memory device.
10. Reinstall the covers, plug in the power cords, and turn on the server.

⇒ NOTE

If the system BIOS becomes corrupted during the update process—for example, a power outage occurs—follow the “Recovering the BIOS” procedure on page 197.

Recovering the BIOS

Moving the boot option jumper on J2C1 from pins 2(B-C) to pins 2(A-B) enables the BIOS flash memory boot recovery mode. The BIOS can be corrupted—for example, when the update procedure is aborted due to a power outage. However, flash memory contains a protected area that cannot be corrupted. Code in this area is used to boot the server from drive A when the BIOS has been corrupted. After booting, the Flash Update Utility (IFLASH) is used to automatically recover the BIOS from the BIOS recovery files on the diskette.

To recover the BIOS:

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Turn off the server, and unplug the AC power cords from the power supplies or wall outlets.
3. Remove the top and right side covers. See Chapter 12, “Server Covers: Removing/Reinstalling.”
4. Move the jumper from J2C1 pins 2(B-C) to pins 2(A-B) to allow the server to boot from the recovery BIOS.
5. Reinstall the top and side covers, plug in the power cords, and insert the Flash Update Utility diskette in drive A.

6. Turn on the monitor and server. After the server boots, the speaker emits a single beep and the recovery process starts—it takes about three minutes. When the recovery process completes, the speaker emits two beeps.

While in the recovery mode, there is no screen display on the monitor. The keyboard is disabled as the server automatically recovers the BIOS. The following beep codes describe the recovery status.

Beep Code	Message
1	Recovery process starting.
2	Successful completion, no errors.
4	The server could not boot from the diskette; it may not be bootable.
Continuous series of low beeps	The wrong BIOS recovery files are being used and/or the flash memory jumper is in the wrong position.

7. After successful completion of restoring the recovery BIOS, remove the diskette, turn off the server and monitor, unplug the power cords, and remove the top and right side covers.
8. Move the jumper from J2C1 pins 2(A-B) to pins 2(B-C)—the normal boot mode.
9. Reinstall the covers, and plug in the power cords.
10. After running the special recovery mode, run the SSU to specify a new password. See Chapter 5, “System Setup Utility: When to Run.”

Updating BMC, FPC, and HCS Firmware

For a copy of the latest BMC, FPC, and HSC firmware releases, contact your dealer or sales representative.

Before you can update the firmware from the firmware update diskettes, you must make them MS-DOS bootable. You must have MS-DOS version 6.00 (or greater) installed on C:\DOS.

⇒ NOTE

Please review the firmware release notes distributed with the firmware update package before attempting to update the firmware of any microcontroller.


Boot Sequence

The PHP I/O baseboard provides the server with a variety of methods for detecting and booting an operating system. The BIOS scans devices and user configurable option slots in a specific sequence. Knowing the precise sequence the BIOS detects, sets up, and boots, assists in defining the server configuration.

Location	Bus	IDSEL	Comment
J1E2	ISA	None	Floppy Drive
J3B1	ISA	None	Compatibility (Legacy) Boot Slot ¹
J1G2	IDE	None	Primary IDE
P1	Primary PCI	25	Expansion Slot ¹
J2G1	Primary PCI	26	On board SCSI
P2	Primary PCI	27	Expansion Slot ¹
U4G1	Primary PCI	28	On board Video
U3D1	Primary PCI	31	PIIX4 Component
P3	Secondary PCI	20	Expansion Slot
P4	Secondary PCI	21	Expansion Slot
P5	Secondary PCI	22	Expansion Slot
P6	Secondary PCI	23	Expansion Slot
U7E2	Secondary PCI	25	PID Component
P7	64 Bit PCI	20	Expansion Slot
P8	64 Bit PCI	21	Expansion Slot
P9	64 Bit PCI	22	Expansion Slot
P10	64 Bit PCI	23	Expansion Slot

1. Install user supplied video adapters only in slots P1 or P2.

PHP I/O Baseboard Layout



OM07313

Figure 17-3. PHP I/O Baseboard Layout

- A. J1G2, Primary IDE port
- B. J2G1, Primary SCSI port
- C. J1E2, Diskette drive port
- D. J2E2, Secondary SCSI port
- E. J1C1, I2C feature connector
- F. J2C1, jumper block
- G. J1A1, USB connector
- H. J2A1, I/O riser card connector
- I. J3B1, 16-bit ISA expansion slot
- J. P1-P6, 32-bit PCI expansion slots
- K. P7-P10 64-bit PCI expansion slots
- L. Expander bus power connectors
- M. Expander bus signal connector
- N. B3G1, Battery

PHP I/O Baseboard Connectors

Expander Bus Connector: Signal Section

Signal	Pin	Signal	Pin	Signal	Pin
COM2_TO_FP_EN	A1	GND	B1	GND	C1
IO_TCK	A2	XIMB_SOUT_EN	B2	SIN_TTL_COM2	C2
IO_TDO	A3	GND	B3	IO_TMS	C3
BMC_SPI_BUS(1)	A4	IO_TDI	B4	PWRGDB	C4
BMC_SPI_BUS(6)	A5	GND	B5	A20M_L	C5
BMC_SPI_BUS(0)	A6	CPU_SPI_RESET_L	B6	PROC_RESET_L	C6
I2C_BMC_SCL	A7	GND	B7	GND	C7
I2C_BMC_SDA	A8	BMC_SPI_BUS(3)	B8	BMC_SPI_BUS(5)	C8
NMI_5V	A9	GND	B9	SMI_L	C9
GND	A10	IGNNE_L	B10	I2C_GLOBAL_SDA	C10
X0D_L(0)	A11	GND	B11	GND	C11
X0D_L(1)	A12	X0XRTS_L	B12	X0HRTS_L	C12
X0D_L(3)	A13	GND	B13	GND	C13
X0D_L(4)	A14	X0D_L(2)	B14	X0BE_L(0)	C14
GND	A15	GND	B15	GND	C15
X0D_L(6)	A16	X0D_L(5)	B16	X0PAR_L	C16
X0D_L(8)	A17	GND	B17	GND	C17
X0D_L(9)	A18	X0D_L(7)	B18	X0ADS_L	C18
GND	A19	GND	B19	X0D_L(11)	C19
X0D_L(12)	A20	X0D_L(10)	B20	X0BE_L(1)	C20
X0D_L(14)	A21	GND	B21	X0XSTBN_L	C21
X0D_L(15)	A22	X0D_L(13)	B22	GND	C22
GND	A23	GND	B23	DOFF0_L	C23
X0CLK	A24	GND	B24	GND	C24
GND	A25	DVALIDA_L	B25	DSR_TTL_FP	C25
CTS_TTL_FP	A26	DOFF1_L	B26	GND	C26
RI_TTL_FP	A27	GND	B27	ISP_FPC_SDO	C27
ISP_SDO	A28	RTS_TTL_FP	B28	GND	C28
INTRUSION_L	A29	GND	B29	DTR_TTL_FP	C29
ISP_SDI	A30	FAN_FAILED	B30	SPEAKER_DATA	C30
VCC_STDBY	A31	GND	B31	GND	C31
I2C_FPC_SCL	A32	VCC_STDBY	B32	HARD_RESET	C32
I2C_FPC_SDA	A33	GND	B33	GND	C33
GND	A34	I2C_DS2P_SDA	B34	I2C_DS2P_SCL	C34
X1D_L(0)	A35	GND	B35	GND	C35

continued

Expander Bus Connector: Signal Section A, B, & C (continued)

Signal	Pin	Signal	Pin	Signal	Pin
X1D_L(1)	A36	X1XRTS_L	B36	X1HRTS_L	C36
X1D_L(3)	A37	GND	B37	GND	C37
X1D_L(4)	A38	X1D_L(2)	B38	X1BE_L(0)	C38
GND	A39	GND	B39	GND	C39
X1D_L(6)	A40	X1D_L(5)	B40	X1PAR_L	C40
X1D_L(8)	A41	GND	B41	GND	C41
X1D_L(9)	A42	X1D_L(7)	B42	X1ADS_L	C42
GND	A43	GND	B43	X1D_L(11)	C43
X1D_L(12)	A44	X1D_L(10)	B44	X1BE_L(1)	C44
X1D_L(14)	A45	GND	B45	X1XSTBN_L	C45
X1D_L(15)	A46	X1D_L(13)	B46	GND	C46
GND	A47	GND	B47	5V_SENSE	C47
X1CLK	A48	5V_RET_SENSE	B48	GND	C48

Expander Bus Connector: Signal Section D & E

Signal	Pin	Signal	Pin
COM2_SIO_EN_A_	D1	PIC_CLK	E1
STP_CLK_L	D2	GND	E2
IO_TRST_L	D3	PICD(1)	E3
PICD(0)	D4	GND	E4
INIT_L	D5	RESET_PWR_DIST_L	E5
GND	D6	GND	E6
BMC_SPI_BUS(2)	D7	BMC_SPI_BUS(4)	E7
GND	D8	GND	E8
X0IB_L	D9	CIB_INT0	E9
IO_PWRGD	D10	GND	E10
I2C_GLOBAL_SCL	D11	INTR	E11
GND	D12	GND	E12
DSEL0_L	D13	FERR_L	E13
GND	D14	GND	E14
DCMPLTA_L	D15	X0BLK_L	E15
GND	D16	GND	E16
SIN_TTL_XIMB	D17	X0RST_L	E17
GND	D18	GND	E18
SOUT_TTL_COM2	D19	SOUT_TTL_XIMB	E19
GND	D20	DCD_TTL_FP	E20
X0XSTBP_L	D21	GND	E21
GND	D22	WDEVT_L	E22

continued

Expander Bus Connector: Signal Section D & E (continued)

Signal	Pin	Signal	Pin
X0HSTBP_L	D23	GND	E23
X0HSTBN_L	D24	DCMPLTB_L	E24
ISP_MODE	D25	ISP_EN_L	E25
ISP_CLK	D26	GND	E26
ISP_FPC_EN_L	D27	(-12V)	E27
(-12V)	D28	GND	E28
DVALIDB_L	D29	CPU_SLP_L	E29
GND	D30	GND	E30
FP_T0_PII4_PWRBTN	D31	SECURE_MODE_BMC	E31
DSEL1_L	D32	GND	E32
X1IB_L	D33	PWR_GOOD	E33
PS_PWR_ON	D34	GND	E34
FP_NMI_SWT_L	D35	PWR_CNTR_SFC	E35
GND	D36	GND	E36
PWR_CNTR_RTC_L	D37	I2C_CEL_CONNECT_FPC	E37
GND	D38	GND	E38
I2C_CEL_CONNECT_BMC	D39	X1BLK_L	E39
GND	D40	GND	E40
I2C_BACKUP_SCL	D41	X1RST_L	E41
GND	D42	GND	E42
I2C_BACKUP_SDA	D43	MIOC_INTREQ_L	E43
GND	D44	GND	E44
X1XSTBP_L	D45	GND	E45
GND	D46	GND	E46
X1HSTBP_L	D47	GND	E47
X1HSTBN_L	D48	GND	E48

Expander Bus Connector: Power Section

Connectors J10H1C and J10H1D

Pin	Signal								
P1A1	GND	P1B1	GND	P1C1	+12V	P1D1	+5V	P1E1	+5V
P1A2	GND	P1B2	GND	P1C2	+12V	P1D2	+5V	P1E2	+5V
P1A3	GND	P1B3	GND	P1C3	+12V	P1D3	+5V	P1E3	+5V
P2A1	GND	P2B1	GND	P2C1	+12V	P2D1	+5V	P2E1	+5V
P2A2	GND	P2B2	GND	P2C2	+12V	P2D2	+5V	P2E2	+5V
P2A3	GND	P2B3	GND	P2C3	+12V	P2D3	+5V	P2E3	+5V

Connector J4H1D and J10H1B

Pin	Signal								
P1A1	GND	P1B1	GND	P1C1	+12V	P1D1	+5V	P1E1	+3.3V
P1A2	GND	P1B2	GND	P1C2	+12V	P1D2	+5V	P1E2	+3.3V
P1A3	GND	P1B3	GND	P1C3	+12V	P1D3	+5V	P1E3	+3.3V
P2A1	GND	P2B1	GND	P2C1	+12V	P2D1	+5V	P2E1	+3.3V
P2A2	GND	P2B2	GND	P2C2	+12V	P2D2	+5V	P2E2	+3.3V
P2A3	GND	P2B3	GND	P2C3	+12V	P2D3	+5V	P2E3	+3.3V

Connectors J4H1B

Pin	Signal								
P1A1	GND	P1B1	GND	P1C1	+12V	P1D1	+12V	P1E1	+3.3V
P1A2	GND	P1B2	GND	P1C2	+12V	P1D2	+12V	P1E2	+3.3V
P1A3	GND	P1B3	GND	P1C3	+12V	P1D3	+12V	P1E3	+3.3V
P2A1	GND	P2B1	GND	P2C1	+12V	P2D1	+12V	P2E1	+3.3V
P2A2	GND	P2B2	GND	P2C2	+12V	P2D2	+12V	P2E2	+3.3V
P2A3	GND	P2B3	GND	P2C3	+12V	P2D3	+12V	P2E3	+3.3V

Connector J4H1C

Pin	Signal								
P1A1	GND	P1B1	GND	P1C1	+12V	P1D1	+5V	P1E1	+3.3V
P1A2	GND	P1B2	GND	P1C2	+12V	P1D2	+5V	P1E2	+3.3V
P1A3	GND	P1B3	GND	P1C3	+12V	P1D3	+5V	P1E3	+3.3V
P2A1	GND	P2B1	GND	P2C1	+12V	P2D1	+5V	P2E1	+3.3V
P2A2	GND	P2B2	GND	P2C2	+12V	P2D2	+5V	P2E2	+3.3V
P2A3	GND	P2B3	GND	P2C3	+12V	P2D3	+5V	P2E3	+3.3V

32-bit PCI Connector

Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
A1	TRST_L	A32	AD16	B1	-12 V	B32	AD17
A2	+12 V	A33	+3.3 V	B2	TCK	B33	C/BE2_L
A3	TMS	A34	FRAME_L	B3	GND (Ground)	B34	GND
A4	TDI	A35	GND	B4	TDO	B35	IRDY_L
A5	+5 V	A36	TRDY_L	B5	+5 V	B36	+3.3 V
A6	INTA_L	A37	GND	B6	+5 V	B37	DEVSEL_L
A7	INTC_L	A38	STOP_L	B7	INTB_L	B38	GND
A8	+5 V	A39	+3.3 V	B8	INTD_L	B39	LOCK_L
A9	RESERVED	A40	SDONE	B9	PRSNT1_L	B40	PERR_L
A10	+5 V	A41	SB0_L	B10	RESERVED	B41	+3.3 V
A11	RESERVED	A42	GND	B11	PRSNT2_L	B42	SERR_L
A12	GND [†]	A43	PAR	B12	GND [†]	B43	+3.3 V
A13	GND ^{††}	A44	AD15	B13	GND [†]	B44	C/BE1_L
A14	RESERVED	A45	+3.3 V	B14	RESERVED	B45	AD14
A15	RESET_L	A46	AD13	B15	GND	B46	GND
A16	+5 V	A47	AD11	B16	CLK	B47	AD12
A17	GRANT_L	A48	GND	B17	GND	B48	AD10
A18	GND	A49	AD9	B18	REQ_L	B49	GND
A19	RESERVED	A50	KEY	B19	+5 V	B50	KEY
A20	AD30	A51	KEY	B20	AD31	B51	KEY
A21	+3.3 V	A52	C/BE0_L	B21	AD29	B52	AD8
A22	AD28	A53	+3.3 V	B22	GND	B53	AD7
A23	AD26	A54	AD6	B23	AD27	B54	+3.3 V
A24	GND	A55	AD4	B24	AD25	B55	AD5
A25	AD24	A56	GND	B25	+3.3 V	B56	AD3
A26	IDSEL	A57	AD2	B26	C/BE3_L	B57	GND
A27	+3.3 V	A58	AD0	B27	AD23	B58	AD1
A28	AD22	A59	+5 V	B28	GND	B59	+5 V
A29	AD20	A60	REQ64_L	B29	AD21	B60	ACK64_L
A30	GND	A61	+5 V	B30	AD19	B61	+5 V
A31	AD18	A62	+5 V	B31	+3.3 V	B62	+5 V

* The cross (†) symbol after the signal indicates that the slot serves +5 V compliant devices only.

64-bit PCI Connector

For pins A1–A62 and B1–B62, the 64-bit PCI connector is identical to the 32-bit PCI connector. The table below shows the additional extension pins for the 64-bit PCI connector.

Pin	Signal	Pin	Signal
A63	GND (Ground)	B63	RESERVED
A64	C/BE7_L	B64	GND
A65	C/BE5_L	B65	C/BE6_L
A66	+5 V	B66	C/BE4_L
A67	PAR64	B67	GND
A68	AD62	B68	AD63
A69	GND	B69	AD61
A70	AD60	B70	+5 V
A71	AD58	B71	AD59
A72	GND	B72	AD57
A73	AD56	B73	GND
A74	AD54	B74	AD55
A75	+5 V	B75	AD53
A76	AD52	B76	GND
A77	AD50	B77	AD51
A78	GND	B78	AD49
A79	AD48	B79	+5 V
A80	AD46	B80	AD47
A81	GND	B81	AD45
A82	AD44	B82	GND
A83	AD42	B83	AD43
A84	+5 V	B84	AD41
A85	AD40	B85	+5 V
A86	AD38	B86	AD39
A87	GND	B87	AD37
A88	AD36	B88	+5 V
A89	AD34	B89	AD35
A90	GND	B90	AD33
A91	AD32	B91	GND
A92	RESERVED	B92	RESERVED
A93	GND	B93	RESERVED
A94	RESERVED	B94	GND

ISA Connector

The ISA connector on the PHP I/O baseboard follows the standard pinout given in the ISA Specification.

Pin	Signal	Pin	Signal
B1	GND (Ground)	A1	IOCHK_L
B2	RESET	A2	SD7
B3	+5 V	A3	SD6
B4	IRQ9	A4	SD5
B5	-5 V	A5	SD4
B6	DRQ2	A6	SD3
B7	-12 V	A7	SD2
B8	SRDY_L	A8	SD1
B9	+12 V	A9	SD0
B10	GND	A10	IOCHRDY
B11	SMEMW_L	A11	AEN
B12	SMEMR_L	A12	SA19
B13	IOW_L	A13	SA18
B14	IOR_L	A14	SA17
B15	DACK3_L	A15	SA16
B16	DRQ3	A16	SA15
B17	DACK1_L	A17	SA14
B18	DRQ1	A18	SA13
B19	REFRESH_L	A19	SA12
B20	BCLK	A20	SA11
B21	IRQ7	A21	SA10
B22	IRQ6	A22	SA9
B23	IRQ5	A23	SA8
B24	IRQ4	A24	SA7
B25	IRQ3	A25	SA6
B26	DACK2_L	A26	SA5
B27	TC	A27	SA4
B28	BALE	A28	SA3
B29	+5 V	A29	SA2
B30	OSC 14 MHz	A30	SA1
B31	GND	A31	SA0
Key		Key	
D1	MEMCS16_L	C1	SBHE_L
D2	IOCS16_L	C2	LA23
D3	IRQ10	C3	LA22

continued

ISA Connector (continued)

Pin	Signal	Pin	Signal
D4	IRQ11	C4	LA21
D5	IRQ12	C5	LA20
D6	IRQ15	C6	LA19
D7	IRQ14D	C7	LA18
D8	DACK0_L	C8	LA17
D9	DRQ0	C9	MEMR_L
D10	DACK5_L	C10	MEMW_L
D11	DRQ5	C11	SD8
D12	DACK6_L	C12	SD9
D13	DRQ6	C13	SD10
D14	DACK7_L	C14	SD11
D15	DRQ7	C15	SD12
D16	+5 V	C16	SD13
D17	MASTER16_L	C17	SD14
D18	GND	C18	SD15

Diskette Drive Port

Pin	Name	Pin	Name
1	GND (Ground)	2	FD_DENSEL
3	GND	4	No Connection
5	Key	6	FD_DRATE0
7	GND	8	FD_INDEX_L
9	GND	10	FD_MTR0_L
11	GND	12	FD_DR1_L
13	GND	14	FD_DR0_L
15	GND	16	FD_MTR1_L
17	FD_MSEN1	18	FD_DIR_L
19	GND	20	FD_STEP_L
21	GND	22	FD_WDATA_L
23	GND	24	FD_WGATE_L
25	GND	26	FD_TRK0_L
27	FD_MSEN0	28	FD_WPROT_L
29	GND	30	FD_RDATA_L
31	GND	32	FD_HDSEL_L
33	GND	34	FD_DSKCHG_L

Wide/Fast 16-bit SCSI Port

Signal Name	Conn. Pin	Cable Pin	Cable Pin	Conn. Pin	Signal Name
GND (Ground)	1	1	2	35	DB12_L
GND	2	3	4	36	DB13_L
GND	3	5	6	37	DB14_L
GND	4	7	8	38	DB15_L
GND	5	9	10	39	DBP1_L
GND	6	11	12	40	DB0_L
GND	7	13	14	41	DB1_L
GND	8	15	16	42	DB2_L
GND	9	17	18	43	DB3_L
GND	10	19	20	44	DB4_L
GND	11	21	22	45	DB5_L
GND	12	23	24	46	DB6_L
GND	13	25	26	47	DB7_L
GND	14	27	28	48	DBP_L
GND	15	29	30	49	GND
GND	16	31	32	50	GND
TERMPWR	17	33	34	51	TERMPWR
TERMPWR	18	35	36	52	TERMPWR
RESERVED	19	37	38	53	RESERVED
GND	20	39	40	54	GND
GND	21	41	42	55	ATN_L
GND	22	43	44	56	GND
GND	23	45	46	57	BSY_L
GND	24	47	48	58	ACK_L
GND	25	49	50	59	RST_L
GND	26	51	52	60	MSG_L
GND	27	53	54	61	SEL_L
GND	28	55	56	62	C/D_L
GND	29	57	58	63	REQ_L
GND	30	59	60	64	I/O_L
GND	31	61	62	65	DB8_L
GND	32	63	64	66	DB9_L
GND	33	65	66	67	DB10_L
GND	34	67	68	68	DB11_L

IDE Port

Pin	Signal	Pin	Signal
1	RSTDRV	2	GND (Ground)
3	DD7	4	DD8
5	DD6	6	DD9
7	DD5	8	DD10
9	DD4	10	DD11
11	DD3	12	DD12
13	DD2	14	DD13
15	DD1	16	DD14
17	DD0	18	DD15
19	GND	20	KEY PIN
21	DRQ	22	GND
23	DIOW	24	GND
25	DIOR	26	GND
27	IORDY	28	CSEL
29	DACK	30	GND
31	IRQ	32	No connection
33	DA1	34	No connection
35	DA0	36	DA2
37	CS1P_L	38	DS3P_L
39	DHACT_L	40	GND

I²C Feature Connector

Pin	Name	Pin	Name
1	SMI#	2	I2CCLK
3	CONP	4	key
5	PWROFF#	6	I2CDATA
7	LPOK	8	KEYUNLK
9	NMI	10	HostAUX
11	RESET#	12	GND
13	GND	14	key
15	SECURE	16	GND
17	INTRUD#	18	NMI_L
19	INIT_L	20	GND
21	KB_DATA	22	MS_DATA
23	KB_CLK	24	MS_CLK
25	Key	26	RESET_BMC_L

I²C Connector

Pin	Signal
1	CLK
2	GND
3	DATA

Front Panel Connector

Pin	Signal	Pin	Signal
1	GND (Ground)	2	+5V
3	VCC_STDBY	4	GND
5	ISP_SCLK	6	FAN_FAILED_L
7	ISP_SDI	8	SPEAKER_DATA
9	ISP_FPC_EN_L	10	INTRUSION_L
11	ISP_MODE	12	RESERVED
13	ISP_FPC_SDO	14	GND
15	VCC_STDBY	16	BMC_TO_FPC_RST_CMD
17	GND	18	PROC_RESET_L
19	COM2_TO_FP_EN	20	SYS_RESET_STATE
21	COM2_TO_SIO_EN_A	22	RST_SFC_L
23	XIMB_SOUT_EN	24	SECURE_MODE_BMC
25	VCC_STDBY	26	HARD_RESET
27	RESERVED	28	FP_NMI_SWT_L
29	SIN_TTL_COM2	30	RESERVED
31	SIN_TTL_XIMB	32	GND
33	SOUT_TTL_COM2	34	PWR_CNTRL_SFC_L
35	SOUT_TTL_XIMB	36	PWR_CNTRL_RTC_L
37	RESERVED	38	PWR_GOOD
39	GND	40	PS_PWR_ON
41	DCD_TTL_FP	42	GND
43	DSR_TTL_FP	44	I2C_CEL_CONNECT_FPC
45	CTS_TTL_FP	46	I2C_CEL_CONNECT_BMC_A
47	RI_TTL_FP	48	I2C_FPC_SCL
49	GND	50	I2C_FPC_SDA
51	VCC_STDBY	52	GND
53	RTS_TTL_FP	54	RESERVED
55	DTR_TTL_FP	56	I2C_BACKUP_SCL
57	GND	58	I2C_BACKUP_SDA
59	(key position)	60	GND

Legacy Connector

The legacy connector on the PHP I/O baseboard provides the signals for the external legacy VGA, serial, parallel, mouse, and keyboard peripheral ports.

Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
A1	VCC_STDBY	A21	PP_STB_L	B1	+5V	B21	SP0_RTS_L
A2	KB_DATA	A22	PP_SLIN_L	B2	MS_DATA	B22	GND
A3	KB_CLK	A23	PP_INIT_L	B3	MS_CLK	B23	SP1_RTS_L
A4	+5V	A24	PP_ERR_L	B4	SIN_TTL_XIMB	B24	SP0_CTS_L
A5	SOUT_TTL_XIMB	A25	PP_AFD_L	B5	SIN_TTL_COM2	B25	SP1_CTS_L
A6	PP_SLCT	A26	I2C_BMC_SCL	B6	SP0_DCD_L	B26	RTL_TTL_FP_L
A7	PP_PE	A27	DSR_TTL_FP	B7	SP1_DCD_L	B27	DTR_TTL_FP_L
A8	PP_BUSY	A28	CTS_TTL_FP	B8	SP0_SIN	B28	DCD_TTL_FP_L
A9	PP_ACK_L	A29	RT_TTL_FP	B9	GND	B29	I2C_BMC_SDA
A10	GND	A30	COM2_TO_STD_EN	B10	SP1_SIN	B30	XIMB_SOUT_EN
A11	PP_DR7	A31	COM2_TO_FP_EN	B11	SP0_RI_L	B31	SOUT_TTL_COM2
A12	PP_DR6	A32	GND	B12	SP1_RI_L	B32	PWR_GOOD
A13	PP_DR5	A33	GND	B13	GND	B33	GND
A14	PP_DR4	A34	GND	B14	SP0_DTR_L	B34	GND
A15	GND	A35	V_BLUE	B15	SP1_DTR_L	B35	V_VSYNC
A16	PP_DR3	A36	GND	B16	SP0_SOUT	B36	GND
A17	PP_DR2	A37	V_GREEN	B17	SP1_SOUT	B37	V_HSYNC
A18	PP_DR1	A38	GND	B18	No connection	B38	GND
A19	PP_DR0	A39	V_RED	B19	SP0_DSR_L	B39	VR_DDCDAT
A20	GND	A40	GND	B20	SP1_DSR_L	B40	VR_DDCCLK

USB Port




OM06248

Pin	Signal	Description
A1	VCC	Overcurrent monitor line port 0
A2	DATAL0	Differential data line paired with DATAH0
A3	DATAH0	Differential data line paired with DATAL0
A4	GND	Ground potential
B1	VCC	Overcurrent monitor line port 1
B2	DATAL1	Differential data line paired with DATAH1
B3	DATAH1	Differential data line paired with DATAL1
B4	GND	Ground potential

Keyboard and Mouse Ports

These identical PS/2 compatible ports share a common housing. The top one is the mouse, and the bottom one is the keyboard.




OM00951A

Mouse		Keyboard	
Pin	Signal	Pin	Signal
1	MSEDAT (mouse data)	1	KEYDAT (keyboard data)
2	No connection	2	No connection
3	GND (Ground)	3	GND (Ground)
4	FUSED_VCC (+5 V)	4	FUSED_VCC (+5 V)
5	MSECLK (mouse clock)	5	KEYCLK (keyboard clock)
6	No connection	6	No connection

Serial Ports

These ports support external devices such as modems and scanners that require serial data transmission.




OM00932A

Pin	Signal
1	DCD (data carrier detect)
2	RXD (receive data)
3	TXD (transmit data)
4	DTR (data terminal ready)
5	GND (Ground)
6	DSR (data set ready)
7	RTS (request to send)
8	CTS (clear to send)
9	RIA (ring indicator)

Parallel Port

The IEEE 1284-compatible parallel port—used primarily for a printer—sends data in parallel format.



OM00933A

Pin	Signal	Pin	Signal
1	STROBE_L	14	AUFDXT_L (auto feed)
2	Data bit 0	15	ERROR_L
3	Data bit 1	16	INIT_L (initialize printer)
4	Data bit 2	17	SLCTIN_L (select input)
5	Data bit 3	18	GND (Ground)
6	Data bit 4	19	GND
7	Data bit 5	20	GND
8	Data bit 6	21	GND
9	Data bit 7	22	GND
10	ACK_L (acknowledge)	23	GND
11	BUSY	24	GND
12	PE (paper end)	25	GND
13	SLCT (select)		

ICMB Connectors


The ICMB device provides external access to the ICMB devices that are within the chassis. This makes it possible to externally access chassis management functions, alert logs, post-mortem data, etc. The device also provides a mechanism for chassis power control. The server provides two SEMCONN 6-pin connectors to allow daisy-chained cabling.



OM06193A

Pin	Signal
1	No connection
2	No connection
3	+ (positive)
4	- (negative)
5	No connection
6	No connection

VGA Video Port



OM00936A

Pin	Signal
1	Red (analog color signal R)
2	Green (analog color signal G)
3	Blue (analog color signal B)
4	No connection
5	GND (video ground, shield)
6–8	GND (video ground, shield)
9	No connection
10	GND (video ground)
11–12	No connection
13	HSYNC (horizontal sync)
14	VSYNC (vertical sync)
15	No connection

18 CPU Baseboard: Description/Setting Configuration Jumpers

This chapter describes the CPU baseboard and tells how to use the jumpers.

Warnings and Cautions

Only a *qualified service technician* is authorized to remove the server covers and to access any of the components inside the server. Before removing the covers, see “Safety Guidelines” on page 115.

CPU Baseboard Features

The CPU baseboard interfaces with the PHP I/O baseboard and memory modules through the midplane. The CPU baseboard provides

- four Slot 2 type connectors for processors packaged in Single Edge Contact (S.E.C.) cartridges
- an onboard DC-to-DC converter that supplies V_{TT} voltage for the CPU baseboard and memory modules
- four sockets for VRM8.3 converters that supply core voltage for the processors
- two sockets for VRM8.3 converters that supply L2 cache voltage for the processors
- I²C, serial peripheral interface (SPI), and in-system programming (ISP) server management interfaces

In a symmetric multiprocessor (SMP) environment, all processors are equal and have no preassigned tasks. Distributing the processing loads among processors increases server performance. This is particularly useful when application demand is low and the I/O request load is high. In an SMP environment, the processors share a common bus, the same interrupt structure, and access to common memory and I/O channels. The SMP implementation conforms to the Multiprocessor Specification Version 1.4.

The onboard PCI and memory controller (PMC) supports from 128 MB to 8 GB of ECC memory, either fast page mode (FPM) or extended data out (EDO) 3.3 V 50 or 60 ns DRAMs, mounted on JEDEC DIMMs.

Processors

The processor core and L2 cache components are mounted inside the S.E.C. cartridge. It plugs into one of the four Slot 2 connectors on the CPU baseboard.

Memory Interface

The memory subsystem consists of two memory modules installed in the two memory connectors on the midplane. The memory modules interface with the CPU baseboard through the midplane via the grand connector. The grand connector provides connectivity between the CPU baseboard, the PHP I/O baseboard, and memory modules through two 270-pin connectors and one 240-pin connector.

Each memory module contains sixteen 72-bit wide DIMM sockets that can provide up to 4 GB of EDO memory per module. The memory bus uses gunning transceiver logic (AGTL)+ signaling technology. Because the bus must be terminated on each end, both memory connectors must contain a memory module; however, only one memory module must be populated with memory.

DC-to-DC Voltage Converters

The plug-in VRM8.3 DC to DC converters, on the CPU baseboard, supply voltage for the processors and the L2 caches. All the converters convert off the +12 V supply rail.

- Four converters supply voltage for the four processor cores.
- Two converters supply voltage for the four processor L2 caches (two L2 caches share one converter).

An onboard switching converter provides the 1.5 V AGTL+ termination voltage (V_{TT}) required by the CPU baseboard, memory modules, and processors. A second onboard linear converter provides +2.5 V for the logic on the CPU baseboard (clock buffers and voltage shifters). Both converters use the +5 V supply rail as source voltage.

DS1624 SEEPROM

When the DS1624 on the CPU baseboard is accessed via the I²C bus, it provides a temperature reading of the ambient temperature of the CPU baseboard. The DS1624 also provides:

- time and date the CPU baseboard was manufactured
- name of the board manufacturer
- name and description of the board
- serial number of the board
- part number of the board

I/O Interface

The CPU baseboard interfaces with the PHP I/O baseboard and memory modules through the grand connector on the midplane. The I/O interface portion of the grand connector provides the primary and secondary expander buses, server management signals, front panel signals, and legacy signals. The expander buses provide source-synchronous, high-speed bidirectional point-to-point links between the CPU baseboard and the PHP I/O baseboard. Each expander bus has enough bandwidth for two 32-bit, 33 MHz PCI buses or one 64-bit, 33 MHz PCI bus. The expander buses use AGTL+ signaling technology.

Front Side Bus

The front side bus (FSB) is an ECC protected 64-bit bus that uses GTL+ signaling technology; it runs at 100 MHz. The FSB requires termination modules in each unused Slot 2 connector. When installing processors, always install them in sequence by starting with processor connector 1, then connector 2, and so on—bottom connector to top connector. For example, in a dual processor server, connectors 1 and 2 contain processors while connectors 3 and 4 contain terminator modules.

Front Side Bus Terminator Module


The FSB terminator module provides:

- the necessary termination for the AGTL+ signals on the FSB
- correct handling of JTAG scan signals

CPU Baseboard Configuration Jumpers

The J31 jumper block

- controls the VRMs and server management outputs
- determines core to bus ratio
- provides parking spaces for unused jumpers



OM07314

Figure 18-1. J31 Jumper Block

Table 18-1. J31 Jumpers for VRMs and Server Management

Pins 1 and 2	Pins 3 and 4	Status
1	1	Disable VRMs
1	0	Reserved
0	1	Disable Server Management
0	0	Default/Normal Operation

Key: 0 = open; 1 = closed

Installing jumpers across pins 5 and 6, 7 and 8, and 9 and 10 determines the processor core-to-FSB frequency ratios. The bus frequency is 100 MHz. The core frequencies are based on the 100 MHz bus frequency.

Table 18-2. J31 Jumpers for Bus Ratios

Pins 5 and 6	Pins 7 and 8	Pins 9 and 10	Bus Ratio	Core Frequency (MHz)
1	1	1	Reserved	
1	1	0	9:2	450
1	0	1	7:2	350
1	0	0	Reserved	
0	1	1	5:1	500
0	1	0	4:1	400
0	0	1	3:1	300
0	0	0	Reserved	


Key: 0 = open; 1 = closed

The jumper block provides three parking positions for storing the jumpers. They can be parked across pins 11 and 12, 13 and 14, and 15 and 16.

Changing a Jumper Setting

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Turn off the server, and unplug the power cord.
3. Remove the top and left side covers. See Chapter 12, “Server Covers: Removing/Reinstalling.”
4. From the tables above, determine which jumper you need to move. Then move it to the new location.
5. Reinstall the top and right side covers.
6. Plug in the power cord, turn on the server, and wait for POST to complete. See Chapter 3, “Power-on Self Test: Description/Running.”
7. Run the SSU to reconfigure your server. See Chapter 5, “System Setup Utility: When to Run.”

CPU Baseboard Layout



OM07312

Figure 18-2. CPU Baseboard Layout

- A. J31, Jumper block
- B. J3, VRM connector provides power for processor slot #2 (processor core power only)
- C. J1, VRM connector provides power for processor slot #1 (processor core power only)
- D. J2, VRM connector provides power for processor slots #1 and #2 (L2 cache power only)
- E. J5, VRM connector provides power for processor slots #3 and #4 (L2 cache power only)
- F. Memory interface connectors
- G. I/O connector
- H. Power connectors
- I. J4, VRM connector provides power for processor slot #3 (processor core power only)
- J. J6, VRM connector provides power for processor slot #4 (processor core power only)
- K. Processor slot #4
- L. Processor slot #3
- M. Processor slot #2
- N. Processor slot #1
- O. J32, Front panel connector

CPU Baseboard Connectors

Memory Connectors, J23 and J20: Rows A, B, and C

Signal	Pin	Signal	Pin	Signal	Pin
MD_L(35)	A1	GND	B1	MD_L(34)	C1
GND	A2	MD_L(32)	B2	GND	C2
MD_L(30)	A3	GND	B3	DSTBN_L(1)	C3
GND	A4	MD_L(28)	B4	GND	C4
MD_L(26)	A5	GND	B5	DSTBP_L(1)	C5
GND	A6	MD_L(24)	B6	GND	C6
MD_L(22)	A7	GND	B7	MD_L(21)	C7
GND	A8	GND	B8	GND	C8
MUXCLK0[A,B]	A9	GND	B9	MD_L(17)	C9
GND	A10	GND	B10	GND	C10
MRESET_L	A11	GND	B11	Reserved	C11
GND	A12	MD_L(16)	B12	GND	C12
MD_L(14)	A13	GND	B13	MD_L(13)	C13
GND	A14	MD_L(11)	B14	GND	C14
MD_L(9)	A15	GND	B15	DSTBP_L(0)	C15
GND	A16	MD_L(7)	B16	GND	C16
MD_L(5)	A17	GND	B17	DSTBN_L(0)	C17
GND	A18	MD_L(3)	B18	GND	C18
MD_L(2)	A19	GND	B19	MD_L(1)	C19
GND	A20	MD_L(0)	B20	GND	C20
MEM[A,B]_TCK	A21	GND	B21	MEMA_TDI	C21
GND	A22	MEM[A,B]_TRST_L	B22	GND	C22
MA_(12)	A23	GND	B23	MA_L(11)	C23
GND	A24	MA_L(9)	B24	GND	C24
MA_L(7)	A25	GND	B25	MA_L(6)	C25
GND	A26	MA_L(4)	B26	GND	C26
MA_L(3)	A27	GND	B27	MA_L(2)	C27
GND	A28	MA_L(1)	B28	GND	C28
MA_L(0)	A29	GND	B29	CSTB_L	C29
GND	A30	CMND1_L	B30	GND	C30
BANK1_L	A31	GND	B31	BANK2_L	C31
GND	A32	CARD[0,1]_L	B32	GND	C32

continued

Memory Connectors, J23 and J20: Rows A, B, & C (continued)

Signal	Pin	Signal	Pin	Signal	Pin
PHIT[A,B]_L	A33	GND	B33	RCMPLT [A,B]_L	C33
GND	A34	RHIT[A,B]_L	B34	GND	C34
Reserved	A35	GND	B35	Reserved	C35
GND	A36	MD_L(71)	B36	GND	C36
MD_L(69)	A37	GND	B37	MD_L(68)	C37
GND	A38	MD_L(66)	B38	GND	C38
MD_L(64)	A39	GND	B39	DSTBN_L(3)	C39
GND	A40	MD_L(62)	B40	GND	C40
MD_L(60)	A41	GND	B41	DSTBP_L(3)	C41
GND	A42	GND	B42	GND	C42
MUXCLK1 [A,B]	A43	GND	B43	MD_L(56)	C43
GND	A44	GND	B44	GND	C44
MD_L(54)	A45	GND	B45	Reserved	C45
GND	A46	Reserved	B46	GND	C46
MD_L(53)	A47	GND	B47	MD_L(52)	C47
GND	A48	MD_L(50)	B48	GND	C48
MD_L(48)	A49	GND	B49	DSTBP_L(2)	C49
GND	A50	MD_L(46)	B50	GND	C50
MD_L(44)	A51	GND	B51	DSTBN_L(2)	C51
GND	A52	MD_L(42)	B52	GND	C52
MD_L(40)	A53	GND	B53	MD_L(39)	C53
GND	A54	MD_L(37)	B54	GND	C54

Memory Connectors, J23 and J20: Rows D & E

Signal	Pin	Signal	Pin
GND	D1	MD_L(33)	E1
MD_L(31)	D2	+1.5V	E2
GND	D3	MD_L(29)	E3
MD_L(27)	D4	GND	E4
GND	D5	MD_L(25)	E5
MD_L(23)	D6	+1.5V	E6
GND	D7	MD_L(20)	E7
MD_L(19)	D8	GND	E8
GND	D9	MD_L(18)	E9
Reserved	D10	GND	E10
GND	D11	Reserved	E11
MD_L(15)	D12	+1.5V	E12
GND	D13	MD_L(12)	E13
MD_L(10)	D14	GND	E14
GND	D15	MD_L(8)	E15
MD_L(6)	D16	+1.5V	E16

continued

Memory Connectors, J23 and J20: Rows D & E (continued)

Signal	Pin	Signal	Pin
GND	D17	MD_L(4)	E17
GND	D18	GND	E18
GND	D19	RCGCLK1 [A,B]	E19
GND	D20	GND	E20
GND	D21	MEM[A,B]_TMS	E21
GND	D22	MA_L(13)	E22
GND	D23	MA_L(10)	E23
MA_L(8)	D24	+1.5V	E24
GND	D25	MA_L(5)	E25
GND	D26	GND	E26
GND	D27	RCGCLK0-[A,B]	E27
GND	D28	GND	E28
GND	D29	ROW_L	E29
BANK0_L	D30	+1.5V	E30
GND	D31	CMND0_L	E31
GND	D32	GND	E32
GND	D33	SDRAM [A,B]_CLK	E33
GND	D34	GND	E34
GND	D35	Reserved	E35
MD_L(70)	D36	Reserved	E36
GND	D37	MD_L(67)	E37
MD_L(65)	D38	+1.5V	E38
GND	D39	MD_L(63)	E39
MD_L(61)	D40	GND	E40
GND	D41	MD_L(59)	E41
MD_L(58)	D42	GND	E42
GND	D43	MD_L(57)	E43
MD_L(55)	D44	GND	E44
GND	D45	Reserved	E45
Reserved	D46	+1.5V	E46
GND	D47	MD_L(51)	E47
MD_L(49)	D48	GND	E48
GND	D49	MD_L(47)	E49
MD_L(45)	D50	+1.5V	E50
GND	D51	MD_L(43)	E51
MD_L(41)	D52	GND	E52
GND	D53	MD_L(38)	E53
MD_L(36)	D54	+1.5V	E54

I/O Connector

I/O Connector, J22: Rows A, B, & C

Signal	Pin	Signal	Pin	Signal	Pin
X1CLK	A1	5V_RET_SENSE	B1	GND	C1
GND	A2	GND	B2	5V_SENSE	C2
X1D_L(15)	A3	X1D_L(13)	B3	GND	C3
X1D_L(14)	A4	GND	B4	X1XSTBN_L	C4
X1D_L(12)	A5	X1D_L(10)	B5	X1BE_L(1)	C5
GND	A6	GND	B6	X1D_L(11)	C6
X1D_L(9)	A7	X1D_L(7)	B7	X1ADS_L	C7
X1D_L(8)	A8	GND	B8	GND	C8
X1D_L(6)	A9	X1D_L(5)	B9	X1PAR_L	C9
GND	A10	GND	B10	GND	C10
X1D_L(4)	A11	X1D_L(2)	B11	X1BE_L(0)	C11
X1D_L(3)	A12	GND	B12	GND	C12
X1D_L(1)	A13	X1XRTS_L	B13	X1HRTS_L	C13
X1D_L(0)	A14	GND	B14	GND	C14
GND	A15	DS2P_I2C_SDA	B15	DS2P_I2C_SCL	C15
I2C_FPC_SDA	A16	GND	B16	GND	C16
I2C_FPC_SCL	A17	VCC_STDBY	B17	HARD_RESET	C17
VCC_STDBY	A18	GND	B18	GND	C18
ISP_SDI	A19	FAN_FAILED_L	B19	SPEAKER_DATA	C19
INTRUSION_L	A20	GND	B20	DTR_TTL_FP	C20
ISP_SDO	A21	RTS_TTL_FP	B21	GND	C21
RI_TTL_FP	A22	GND	B22	ISP_FPC_SDO	C22
CTS_TTL_FP	A23	ISP_CONNECTOR_SCLK	B23	GND	C23
GND	A24	GND	B24	RESERVED	C24
X0CLK	A25	DSR_TTL_FP	B25	GND	C25
GND	A26	GND	B26	ISP_HSBP_SDO	C26
X0D_L(15)	A27	X0D_L(13)	B27	GND	C27
X0D_L(14)	A28	GND	B28	X0XSTBN_L	C28
X0D_L(12)	A29	X0D_L(10)	B29	X0BE_L(1)	C29
GND	A30	GND	B30	X0D_L(11)	C30
X0D_L(9)	A31	X0D_L(7)	B31	X0ADS_L	C31
X0D_L(8)	A32	GND	B32	GND	C32
X0D_L(6)	A33	X0D_L(5)	B33	X0PAR_L	C33
GND	A34	GND	B34	GND	C34
X0D_L(4)	A35	X0D_L(2)	B35	X0BE_L(0)	C35
X0D_L(3)	A36	GND	B36	GND	C36

continued

I/O Connector, J22: Rows A, B, & C (continued)

Signal	Pin	Signal	Pin	Signal	Pin
X0D_L(1)	A37	X0XRTS_L	B37	X0HRTS_L	C37
X0D_L(0)	A38	GND	B38	GND	C38
GND	A39	IGNNE_L	B39	I2C_GLOBAL_SDA	C39
NMI_5V	A40	GND	B40	SMI_L	C40
I2C_BMC_SDA	A41	BMC_SPI_BUS(3)	B41	BMC_SPI_BUS(5)	C41
I2C_BMC_SCL	A42	GND	B42	GND	C42
BMC_SPI_BUS(0)	A43	CPU_CPI_RESET_L	B43	PROC_RESET_L	C43
BMC_SPI_BUS(6)	A44	GND	B44	A20M_L	C44
BMC_SPI_BUS(1)	A45	IO_TDI	B45	PWRGDB	C45
IO_TDO	A46	GND	B46	IO_TMS	C46
IO_TCK	A47	XIMB_SOUT_ENT	B47	SIN_TTL_COM2	C47
COM2_TO_FP_EN	A48	GND	B48	GND	C48

I/O Connector, J22: Rows D & E

Signal	Pin	Signal	Pin
X1HSTBN_L	D1	GND	E1
X1HSTBP_L	D2	GND	E2
GND	D3	GND	E3
X1XSTBP_L	D4	RESERVED	E4
GND	D5	GND	E5
I2C_BACKUP_SDA	D6	MIOC_INTREQ_L	E6
GND	D7	GND	E7
I2C_BACKUP_SCL	D8	X1RST_L	E8
GND	D9	GND	E9
I2C_CEL_CONNECT	D10	X1BLK_L	E10
GND	D11	GND	E11
PWR_CNTRL_RTC	D12	I2C_CEL_CONNECT_FPC	E12
GND	D13	GND	E13
FP_NMI_SWT_L	D14	PWR_CNTRL_SFC_L	E14
PS_PWR_ON	D15	GND	E15
X1IB_L	D16	PWR_GOOD	E16
RESERVED	D17	GND	E17
FP_TO_PII4_PWR	D18	SECURE_MODE_BMC	E18
GND	D19	GND	E19
ISP_EN2_L	D20	CPU_SLP_L	E20
-12V	D21	GND	E21
ISP_FPC_EN_L	D22	-12V	E22

continued

I/O Connector, J22: Rows D & E (continued)

Signal	Pin	Signal	Pin
ISP_SCLK	D23	GND	E23
ISP_MODE	D24	ISP_EN_L	E24
X0HSTBN_L	D25	GND	E25
X0HSTBP_L	D26	GND	E26
GND	D27	GND	E27
X0XSTBP_L	D28	DCD_TTL_FP	E28
GND	D29	GND	E29
SOUT_TTL_COM2	D30	SOUT_TTL_XIMB	E30
GND	D31	GND	E31
SIN_TTL_XIMB	D32	X0RST_L	E32
GND	D33	GND	E33
RESERVED	D34	X0BLK_L	E34
GND	D35	GND	E35
RESET_HSBP_L	D36	FERR_L	E36
GND	D37	GND	E37
I2C_GLOBAL_SCL	D38	INTR	E38
IO_PWRGD	D39	RESERVED	E39
X0IB_L	D40	RESERVED	E40
GND	D41	GND	E41
BMC_SPI_BUS(2)	D42	BMC_SPI_BUS(4)	E42
GND	D43	GND	E43
INIT_L	D44	RESET_PWR_DIST_L	E44
PICD(0)	D45	GND	E45
IO_TRST_L	D46	PICD(1)	E46
STPCLK_L	D47	GND	E47
COM2_TO_SIO_EN	D48	PIC_CLK	E48

Power Connectors

Power Connectors, J21B, J21C, J12D, J24B, J24C, and J24D

J21B									
Pin	Signal								
P1A1	GND	P1B1	GND	P1C1	+12V	P1D1	+12V	P1E1	+3.3V
P1A2	GND	P1B2	GND	P1C2	+12V	P1D2	+12V	P1E2	+3.3V
P1A3	GND	P1B3	GND	P1C3	+12V	P1D3	+12V	P1E3	+3.3V
P2A1	GND	P2B1	GND	P2C1	+12V	P2D1	+12V	P2E1	+3.3V
P2A2	GND	P2B2	GND	P2C2	+12V	P2D2	+12V	P2E2	+3.3V
P2A3	GND	P2B3	GND	P2C3	+12V	P2D3	+12V	P2E3	+3.3V

J21C									
Pin	Signal								
P1A1	GND	P1B1	GND	P1C1	+12V	P1D1	+5V	P1E1	+3.3V
P1A2	GND	P1B2	GND	P1C2	+12V	P1D2	+5V	P1E2	+3.3V
P1A3	GND	P1B3	GND	P1C3	+12V	P1D3	+5V	P1E3	+3.3V
P2A1	GND	P2B1	GND	P2C1	+12V	P2D1	+5V	P2E1	+3.3V
P2A2	GND	P2B2	GND	P2C2	+12V	P2D2	+5V	P2E2	+3.3V
P2A3	GND	P2B3	GND	P2C3	+12V	P2D3	+5V	P2E3	+3.3V

J21D									
Pin	Signal								
P1A1	GND	P1B1	GND	P1C1	+12V	P1D1	+5V	P1E1	+3.3V
P1A2	GND	P1B2	GND	P1C2	+12V	P1D2	+5V	P1E2	+3.3V
P1A3	GND	P1B3	GND	P1C3	+12V	P1D3	+5V	P1E3	+3.3V
P2A1	GND	P2B1	GND	P2C1	+12V	P2D1	+5V	P2E1	+3.3V
P2A2	GND	P2B2	GND	P2C2	+12V	P2D2	+5V	P2E2	+3.3V
P2A3	GND	P2B3	GND	P2C3	+12V	P2D3	+5V	P2E3	+3.3V

J24B									
Pin	Signal								
P1A1	GND	P1B1	GND	P1C1	+12V	P1D1	+5V	P1E1	+3.3V
P1A2	GND	P1B2	GND	P1C2	+12V	P1D2	+5V	P1E2	+3.3V
P1A3	GND	P1B3	GND	P1C3	+12V	P1D3	+5V	P1E3	+3.3V
P2A1	GND	P2B1	GND	P2C1	+12V	P2D1	+5V	P2E1	+3.3V
P2A2	GND	P2B2	GND	P2C2	+12V	P2D2	+5V	P2E2	+3.3V
P2A3	GND	P2B3	GND	P2C3	+12V	P2D3	+5V	P2E3	+3.3V

Power Connectors, J21B, J21C, J12D, J24B, J24C, and J24D (continued)

J24C									
Pin	Signal								
P1A1	GND	P1B1	GND	P1C1	+12V	P1D1	+5V	P1E1	+5V
P1A2	GND	P1B2	GND	P1C2	+12V	P1D2	+5V	P1E2	+5V
P1A3	GND	P1B3	GND	P1C3	+12V	P1D3	+5V	P1E3	+5V
P2A1	GND	P2B1	GND	P2C1	+12V	P2D1	+5V	P2E1	+5V
P2A2	GND	P2B2	GND	P2C2	+12V	P2D2	+5V	P2E2	+5V
P2A3	GND	P2B3	GND	P2C3	+12V	P2D3	+5V	P2E3	+5V

J24D									
Pin	Signal								
P1A1	GND	P1B1	GND	P1C1	+12V	P1D1	+5V	P1E1	+5V
P1A2	GND	P1B2	GND	P1C2	+12V	P1D2	+5V	P1E2	+5V
P1A3	GND	P1B3	GND	P1C3	+12V	P1D3	+5V	P1E3	+5V
P2A1	GND	P2B1	GND	P2C1	+12V	P2D1	+5V	P2E1	+5V
P2A2	GND	P2B2	GND	P2C2	+12V	P2D2	+5V	P2E2	+5V
P2A3	GND	P2B3	GND	P2C3	+12V	P2D3	+5V	P2E3	+5V

Front Panel Connector

Front Panel Connector, J32

Signal	Pin	Signal	Pin
GND	1	GND	41
+12V	2	-12V	42
+12V	3	+12V	43
GND	4	GND	44
GND	5	GND	45
+12V	6	+12V	46
+12V	7	+12V	47
SPEAKER_DATA	8	GND	48
ISP_SCLK	9	GND	49
FAN_FAILED_L	10	+5V	50
GND	11	ISP_SDI	51
ISP_FPC_EN_L	12	+5V	52
FP_TO_PII_X_PWRBTN	13	ISP_MODE	53
ISP_FPC_SDO	14	+5V	54
Reserved	15	Reserved	55
COM2_TO_FP_EN	16	+5V	56
COM2_TO_SIO_EN_A	17	PROC_RESET_L	57
GND	18	Reserved	58
SECURE_MODE_BMC	19	XIMB_SOUT_EN	59

continued

Front Panel Connector, J32 (continued)

Signal	Pin	Signal	Pin
HARD_RESET	20	GND	60
FP_NMI_SWT_L	21	Reserved	61
SIN_TTL_COM2	22	Reserved	62
SIN_TTL_XIMB	23	Reserved	63
GND	24	GND	64
SOUT_TTL_XIMB	25	PWR_CNTRL_SFC_L	65
PWR_CNTRL_RTC_L	26	SOUT_TTL_COM2	66
GND	27	GND	67
PS_PWR_ON	28	PWR_GOOD	68
DSR_TTL_FP	29	DCD_TTL_FP	69
I2C_CEL_CONNECT_FPC	30	GND	70
CTS_TTL_FP	31	Reserved	71
I2C_CEL_CONNECT_BMC_A	32	Reserved	72
I2C_FPC_SCL	33	RI_TTL_FP	73
I2C_FPC_SDA	34	Reserved	74
GND	35	RTS_TTL_FP	75
GND	36	DTR_TTL_FP	76
I2C_BACKUP_SDA	37	I2C_BACKUP_SCL	77
VCC_STDBY	38	VCC_STDBY	78
VCC_STDBY	39	VCC_STDBY	79
Reserved	40	GND	80

19 Memory Modules: Description/Adding Memory

This chapter describes the memory module and tells how to populate the DIMM sockets on the memory module.

Warnings and Cautions

Only a *qualified service technician* is authorized to remove the server covers and to access any of the components inside the server. Before removing the covers, see “Safety Guidelines” on page 115.

Module Features

Memory module:

- Up to 4 GB of ECC memory using sixteen 72-bit dual inline memory modules (DIMMs)
- 60 ns and 50 ns, 3.3 V, buffered EDO DRAM
- Four-way interleaving
- A minimum configuration of 128 MB using four 32 MB DIMMs
- Supports buffered DIMMs with capacities of 32, 64, and 256 MB
- Provides server management data with an onboard EEPROM, including thermal monitoring, FRU information, and presence-detect bit access
- Can act as a memory terminator module when not populated with DIMMs

You must install two high-capacity DRAM memory modules and one of them must be populated with DIMMs.

ECC memory detects and corrects single-bit errors from DRAM in real time, allowing your server to function normally despite data transmission errors. ECC detects all double-bit errors but does not correct them; it also detects, but does not correct, three-bit and four-bit adjacent errors in a DRAM nibble. Single-bit errors are reported down to the exact bit within DIMM. Multiple-bit errors are reported down to an interleave which corresponds to a single DIMM.

EDO DRAM Array

The extended data out (EDO) DRAM array on the memory module consists of sixteen 72-bit (64-bit data plus 8 ECC bits) DIMM sockets. They are divided into four memory banks, A–D, of four sockets each. These banks support only 4:1 interleaving (DIMMs in all four sockets). For example, in bank A socket

- J1 contains interleave 0
- J2 contains interleave 1
- J3 contains interleave 2
- J4 contains interleave 3

Because each interleave provides access to 72 bits of data, 4:1 interleaving yields 288 bits (32 bytes) per DRAM transaction—one cache line for the processor. If the CPU baseboard contains two 4:1 interleaving memory modules, successive DRAM transactions occurring in the different memory modules complete at a maximum rate of one transaction every 30 ns. This yields a maximum data rate of 1.067 GB per second.

Although several DIMM population options are available, the following table lists the populations that should be used to add memory to the system.

Table 19-1. Memory Module DIMM Support

Category	Supported DIMM Variety
Speed	50 ns, 60 ns
Capacity/Organization/Refresh	32 MB: 16 Mbit, 4Mx4 DRAM; 2 K or 4 K refresh* 64 MB: 64 Mbit, 8Mx8 DRAM; 4 K refresh* 256 MB: Double-high; 64 Mbit, 16Mx4 DRAM; 4K or 8K refresh*
Voltage	3.3 V
Data Width	x72 (ECC)
Page Mode	EDO
Buffered/Non	Buffered
Maximum Height	2.4 inches
DRAM Package	TSSOP

* The memory module supports only CAS-before-RAS refresh. When selecting a module, make sure that the target refresh number corresponds to CBR refresh.

All DIMMs within a given bank must be identical. From bank to bank, the 450NX PCI chipset supports different varieties of DIMM sizes, manufacturers, and speeds.

Only configuration adhering to the following rules are validated, and they are the only configuration that are fully supported:

- All DIMMs within a given bank must be identical.
- Install 32, 64, and 256 MB DIMMs in the memory banks.
- The total number of DIMMs on both memory modules: 4, 8, 16, 24, or 32 (two memory module configuration).
- The total number of DIMMs using only one memory module must be: 4, 8, 12, or 16 (one memory module and one memory terminator configuration).

- Install an equal number of DIMMs on each memory module, in the two memory module configuration, except when only four DIMMs are used. In that case, all four DIMMs are on the primary memory module installed in primary connector on the midplane.
- All DIMMs on a memory module are identical in size and speed.
- DIMMs may differ in size and speed between memory modules. However, the maximum data transfer rate can only be provided when the banks of each module are configured identically (through module-to-module interleaving as indicated in the rules below).

To take advantage of address bit permuting (ABP), which increases memory access performance across sequential cache line accesses, the following rules must be followed:


- All banks that are used must be populated with four DIMMs.
- There must be a power of two banks populated (2, 4, 8, or 16).
- All banks in an ABP group (two banks in 2-bank permuting or four banks in 4-bank permuting) must be the same size.
- All populated banks must be adjacent and start at bank 0.
- When it is required that both memory modules be in the server, both must be configured to allow equivalent ABP settings. For example, the chip set cannot support 2-bank permuting on one module and 4-bank permuting on the other.

To take advantage of module-to-module interleaving, which provides maximum performance across sequential cache line accesses, the following rules must be followed:

- All ABP rules above must be followed.
- Two memory modules must be used, and corresponding banks must be identically populated with DIMMs of the same size and type.

Before allowing the processors to come out of reset, server management firmware scans the presence-detect bits of all DIMMs installed on the memory modules. If they are 50-ns DIMMs, then server management changes the value of the chipset's DRAM speed-mode bit. The default value on this bit is a high voltage level, which corresponds to 60-ns timings; changing the value to a low voltage level places this bit in the 50-ns mode. Changing the value of the bit can only be effected by software, and it must be before the processors come out of reset. If the bit changes while a memory access is in process, the results are unpredictable. After deciding the value of the bit and making any necessary changes, server management may proceed with processor reset. While changing this bit will not increase the theoretical maximum bandwidth, it will decrease initial latency of DRAM reads by one clock and increase bandwidth of consecutive page misses.


When installing less than 16 DIMMs on a memory module, there is a preferred order for populating the DIMM sockets to maintain optimal signal integrity. When installing two memory modules on the CPU baseboard, you should always alternate DIMM installation between memory modules. For instance, when installing 16 DIMMs in the system, the quantities should be divided such that eight fill the first two banks of one module and eight more fill the same two banks in the second module. See the DIMM interleave configurations in Figures 19-1 through 19-3.



OM07332

Figure 19-1. 4:1 Interleave With Four DIMMs


- | | |
|------------------------------|----------------------------|
| A. Bank A, J1-J4 (populated) | C. Bank C, J9-J12 (empty) |
| B. Bank B, J5-J8 (empty) | D. Bank D, J13-J16 (empty) |



OM07340

Figure 19-2. 4:1 Interleave With Eight DIMMs

- A. Bank A, J1-J4 (populated)
- B. Bank B, J5-J8 (populated)
- C. Bank C, J9-J12 (empty)
- D. Bank D, J13-J16 (empty)



OM07341

Figure 19-3. 4:1 Interleave With 12 DIMMs

- A. Bank A, J1-J4 (populated)
- B. Bank B, J5-J8 (populated)
- C. Bank C, J9-J12 (populated)
- D. Bank D, J13-J16 (empty)

Memory Module Layout




Figure 19-4. Memory Module Layout

- A. J1-J4, 168-pin DIMM sockets, Bank A
- B. J5-J8, 168-pin DIMM sockets, Bank B
- C. J9-J12, 168-pin DIMM sockets, Bank C
- D. J13-J16, 168-pin DIMM sockets, Bank D
- E. U6E2, DS1624, I²C EEPROM and temperature sensor (package)
- F. J21 memory interface connector
- G. Eject/insert levers

Installing DIMMs



CAUTION

DIMM devices with gold contacts should not be installed in DIMM sockets with tin-lead contacts or vice versa. Mixing dissimilar metal contacts types has been shown to result in unreliable memory operation.

To avoid potential memory problems, use only DIMMs from JEDEC-compatible manufacturers that have been tested for compatibility with the memory module. Contact your sales representative or dealer for a list of approved DIMMs.

See Figures 19-5 and 19-6.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Remove the top and side covers as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Remove the memory module as described in Chapter 13, "Server Components: Removing/Reinstalling."
4. Being careful not to touch the components on the memory module, place the module DIMM-side up on a nonconductive, static-free surface.
5. Hold the DIMM only by the edges as you remove the DIMM from the antistatic package.
6. Beginning with bank A (Figure 19-5), socket J1, orient the DIMM so that the two notches in the bottom edge align with the keyed socket.





Figure 19-5. DIMM Orientation

**CAUTION**

Use extreme care when installing a DIMM. Applying too much pressure can damage the socket slot. DIMMs are keyed such that they can be inserted in only one way.

7. Insert the bottom edge of the DIMM into socket J1, and press down firmly on the DIMM until it seats correctly (Figure 19-6).



OM06767

Figure 19-6. Properly Seated DIMM

8. Repeat the above steps to install more DIMMs. Always install them in sequence by installing the next DIMM in bank A, socket J2 and so on, with the last one in bank D, socket J16.
9. Reinstall the memory module as described in Chapter 13.
10. Reinstall the top and side covers as described in Chapter 12.
11. Reconnect all external cables and the power cords to the server.
12. Turn on your monitor and then your server.
13. Run the SSU to configure the server and to properly attribute ECC memory. Failure to do so may degrade the performance of your server. For information about running the SSU, see Chapter 5, "System Setup Utility: When to Run."

Removing DIMMs

See Figure 19-7.

1. Observe the precautions on page 115, "Safety Guidelines."
2. Remove the top and side covers as described in Chapter 12, "Server Covers: Removing/Reinstalling."
3. Remove the memory module as described in Chapter 13, "Server Components: Removing/Reinstalling."
4. Starting with the first DIMM-filled socket closest to the top edge of the module, remove the DIMMs one at a time.



CAUTION

Use extreme care when removing a DIMM. Too much pressure can damage the socket slot. Apply only enough pressure on the plastic ejector levers to release the DIMM.

5. Gently push the plastic ejector levers out and down to eject the DIMM from the socket (Figure 19-7).
6. Carefully lift the DIMM away from the socket, and store it in an antistatic package.
7. Repeat the above steps to remove other DIMMs.




Figure 19-7. Removing DIMMs

8. Reinstall the memory module as described in Chapter 13.
9. Reinstall the top and side covers as described in Chapter 12.
10. Reconnect all external cables and the power cords to the server.
11. Turn on your monitor and then your server.
12. Run the SSU to configure the server and to properly attribute ECC memory. Failure to do so may degrade the performance of your server. For information about running the SSU, see Chapter 5, "System Setup Utility: When to Run."

System Management Interface

The devices on I²C bus of the memory module provide system management software with module operating temperature, DIMM configuration, and field replacement unit (FRU) data. The devices also provide

- time and date the module was manufactured
- name of the module manufacturer
- name and description of the module
- serial number of the module
- part number of the module

Memory Module Connector

Signal	Pin	Signal	Pin	Signal	Pin
GND	A1	MD36_L	B1	GND	C1
GDCMPLT_L	A2	VCC	B2	DSTBN2_L	C2
GND	A3	MD39_L	B3	GND	C3
MD41_L	A4	VCC	B4	DSTBP2_L	C4
GND	A5	MD43_L	B5	GND	C5
MD45_L	A6	VCC	B6	MD46_L	C6
GND	A7	MD48_L	B7	GND	C7
MD50_L	A8	VCC	B8	MD51_L	C8
GND	A9	MD53_L	B9	GND	C9
VTT	A10	VCC	B10	MD54_L	C10
GND	A11	GND	B11	VTT	C11
MUXCLK1	A12	GND	B12	MD56_L	C12
GND	A13	GND	B13	VTT	C13
MD59_L	A14	VCC	B14	DSTBP3_L	C14
GND	A15	MD61_L	B15	GND	C15
MD63_L	A16	VCC	B16	DSTBN3_L	C16
GND	A17	MD65_L	B17	GND	C17
VTT	A18	VCC	B18	MD67_L	C18
GND	A19	MD69_L	B19	GND	C19
MD71_L	A20	VCC	B20	VTT	C20
GND	A21	NC	B21	GND	C21
VTT	A22	VCC	B22	CARD_NUM	C22
GND	A23	GND	B23	VTT	C23
SPAREKCLK1	A24	GND	B24	PHIT_L	C24
GND	A25	GND	B25	VTT	C25
WDEVT_L	A26	VCC	B26	RCMPLT_L	C26
GND	A27	CMND0_L	B27	GND	C27
DCMPLT_L	A28	VCC	B28	BANK0_L	C28
GND	A29	BANK2_L	B29	GND	C29
DVALID_L	A30	VCC	B30	ROW_L	C30
GND	A31	MA0_L	B31	VTT	C31
DOFF0_L	A32	GND	B32	MA2_L	C32
GND	A33	MA4_L	B33	VTT	C33
DOFF1_L	A34	VCC	B34	MA6_L	C34
GND	A35	MA8_L	B35	GND	C35
DSEL_L	A36	VCC	B36	MA10_L	C36
GND	A37	GND	B37	GND	C37
RCGCLK	A38	GND	B38	MA13_L	C38

continued

Memory Module Connector: A, B, & C (continued)

Signal	Pin	Signal	Pin	Signal	Pin
GND	A39	GND	B39	VTT	C39
SPARECLK0	A40	GND	B40	NC	C40
GND	A41	GND	B41	VTT	C41
MD0_L	A42	VCC	B42	MD1_L	C42
GND	A43	MD3_L	B43	GND	C43
MD5_L	A44	VCC	B44	DSTBN0_L	C44
GND	A45	MD7_L	B45	GND	C45
MD9_L	A46	VCC	B46	DSTBP0_L	C46
GND	A47	MD11_L	B47	GND	C47
MD13_L	A48	VCC	B48	MD14_L	C48
GND	A49	TDI	B49	GND	C49
MD16_L	A50	VCC	B50	TRST_L	C50
GND	A51	GND	B51	VTT	C51
MUXCLK0	A52	GND	B52	MD18_L	C52
GND	A53	GND	B53	VTT	C53
MD21_L	A54	VCC	B54	MD22_L	C54
GND	A55	MD24_L	B55	GND	C55
MD26_L	A56	VCC	B56	DSTBP1_L	C56
GND	A57	MD28_L	B57	GND	C57
GDCMPLT_L	A58	VCC	B58	DSTBN1_L	C58
GND	A59	MD31_L	B59	GND	C59
MD33_L	A60	VCC	B60	MD34_L	C60

Memory Module Connector: D & E

Signal	Pin	Signal	Pin
MD37_L	D1	VCC	E1
GND	D2	MD38_L	E2
MD40_L	D3	VCC	E3
GND	D4	MD42_L	E4
MD44_L	D5	VCC	E5
GND	D6	MD47_L	E6
MD49_L	D7	VCC	E7
GND	D8	MD52_L	E8
TDO	D9	VCC	E9
GND	D10	VCC	E10
MD55_L	D11	VCC	E11
GND	D12	MD57_L	E12
MD58_L	D13	VCC	E13
GND	D14	MD60_L	E14

continued

Memory Module Connector: D & E (continued)

Signal	Pin	Signal	Pin
MD62_L	D15	VCC	E15
GND	D16	MD64_L	E16
MD66_L	D17	VCC	E17
GND	D18	MD68_L	E18
MD70_L	D19	VCC	E19
GND	D20	VCC	E20
NC	D21	VCC	E21
GND	D22	I2C_BMC_SCL	E22
PWRGD	D23	VCC	E23
GND	D24	I2C_BMC_SDA	E24
RHIT_L	D25	VCC	E25
GND	D26	GRCMPLT_L	E26
CARD_L	D27	VCC	E27
GND	D28	BANK1_L	E28
CMND1_L	D29	VCC	E29
GND	D30	CSTB_L	E30
MA1_L	D31	VCC	E31
GND	D32	MA3_L	E32
MA5_L	D33	VCC	E33
GND	D34	MA7_L	E34
MA9_L	D35	VCC	E35
GND	D36	MA11_L	E36
MA12_L	D37	VCC	E37
GND	D38	VCC	E38
VCC	D39	VCC	E39
GND	D40	TCK	E40
VCC	D41	VCC	E41
GND	D42	MD2_L	E42
MD4_L	D43	VCC	E43
GND	D44	MD6_L	E44
MD8_L	D45	VCC	E45
GND	D46	MD10_L	E46
MD12_L	D47	VCC	E47
GND	D48	MD15_L	E48
TMS	D49	VCC	E49
GND	D50	MRESET_L	E50
MD17_L	D51	VCC	E51
GND	D52	MD19_L	E52
MD20_L	D53	VCC	E53

continued

Memory Module Connector: D & E (continued)

Signal	Pin	Signal	Pin
GND	D54	MD23_L	E54
MD25_L	D55	VCC	E55
GND	D56	MD27_L	E56
MD29_L	D57	VCC	E57
GND	D58	MD30_L	E58
MD32_L	D59	VCC	E59
GND	D60	MD35_L	E60

20 Power System: Description/Calculating Power Usage

This chapter describes the modular power system and explains how to calculate power usage for your server.

Warnings and Cautions

Only a *qualified service technician* is authorized to remove the server covers and to access any of the components inside the server. Before removing the covers, see “Safety Guidelines” on page 115.

AC Input Power

The server can operate with input voltages of 200-240VAC or 100-120VAC. A jumper located on the midplane selects the input voltage at which the server will operate. The jumper also enables/disables the brown out recovery feature that aids server startup during low AC input voltage conditions.

JP1 Position	Valid AC Input Range	AC Mains	Brown Out Feature
Installed	200-240VAC or 100-120VAC	15A	Disabled
		15A	Disabled
Removed	200-240VAC	15A	Enabled

Enabling the brown out feature ensures that all power supplies will turn on when the AC input voltage reaches at least 180VAC following an AC main brown out condition.


Disabling the brown out feature can cause power problems when the system tries to recover from a brown out condition. The problems that can result depend on server AC input voltages.

- For 100-120VAC input power after a brown out: AC input voltage may slowly rise to its nominal level and because of slight differences in power supply turn on thresholds at 90V, one power supply may turn on before the others. This power supply will most likely see too large a DC load and shut down (other power supplies may do the same), removing all DC voltages from the server.
- For 200-240VAC input power after a brown out: AC input voltage may slowly rise to its nominal level and the power supplies turn on at 90V doubling the current load on the AC main and causing them to trip.
- For power supply input voltages see Table 20-3.

Jumper JP1 Installing/Removing

See Figure 20-1.

1. Shut down the server and disconnect it from its power source.
2. Remove the memory module cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
3. Remove the peripheral bay as described in Chapter 13, “Server Components: Removing/Reinstalling.”
4. Install or remove the jumper.
5. Reinstall the peripheral bay.
6. Reinstall the memory module cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
7. Reconnect the server to power and start the server.



OM07348

Figure 20-1. Jumper JP1

Power System

The modular power system for the server is provided by up to three autoranging power supplies and a midplane. When connected to 100-120VAC mains each power supply is capable of delivering 650 watts DC. When connected to 200-240VAC mains each power supply is capable of delivering 750 watts DC. The power system may be configured with two power supplies (standard) or three power supplies (2 + 1, redundant). The power supplies are mounted in a 2 + 1 pattern in the back of the chassis along the bottom. Each power supply has an integrated fan for cooling.

The midplane provides connectors for the hot-swap power supplies. The midplane is the DC power distribution hub providing connectors for the CPU baseboard, memory modules, I/O baseboard, and peripheral bay. The midplane also provides the interface logic for power supply related management functions.

Operator accessible areas are mechanically shielded from energy hazards while hot-swapping—installing or removing—a hard disk drive, or a system fan. PCI hot-plug expansion boards are 240VA protected by current limiting circuitry on the PHP I/O board.

Care must be taken not to overload an AC mains circuit by plugging too many loads into a single AC circuit. It is recommended to either plugging the power cord of the server in a separate circuit or calculating the current drawn from loads attached to an AC circuit to make sure AC current limits will not be exceeded.

If a power supply fails in the redundant power system, an LED marked “FAIL” at the back of the power supply illuminates yellow. If a power supply predictive failure event occurs in the redundant power system, an LED marked “PRFL” at the back of the power supply blinks yellow. In both cases, the yellow power supply failure LED on the front panel starts flashing. The supply can be hot-swapped—removed and replaced—without turning off the power or impacting server operations. If the load on a single power supply exceeds the output ratings defined in Table 20-2, an LED marked “FAIL” at the back of the power supply blinks yellow and the entire power system is shut down.

Power Supply Input Voltages

Table 20-1. Power Supply AC Input Ratings

Parameter	Minimum	Nominal	Maximum	Units
V in (115)	90	100-120	132	V RMS
V in (230)	180	200-240	264	V RMS
V in Frequency	47	50/60	63	Hz
AC Input Current (at maximum load)		13 A @115 VAC 7 A @ 220 VAC		Ampere

Power Supply Output Voltages

Table 20-2. Power Supply Output Ratings

Power Supply Outputs	Individual Supply at 100-120VAC	Individual Supply at 220-240VAC	Two or Three ¹ Supplies at 100-120VAC	Two or Three ¹ Supplies at 200-240VAC
3.3 V	31 A	36 A	58 A	68 A
5 V	31 A	36 A	58 A	64 A
12 V	31 A	36 A	58 A	68 A
-12 V	1 A	1 A	1 A	1 A
5 V Standby	1 A	1 A	1.75 A	1.75 A
15 V	200 mA	200 mA	200 mA	200 mA

¹ Forced load sharing is for 5, 3.3, and 12 V only. Passive load sharing is used for 5V Standby, -12 and 15V.

Server Current Usage

Table 20-3 shows the current usage for both minimally and fully configured servers. You can easily calculate power usage in the server from the numbers provided. The table is for reference only. It is not meant to provide the exact current usage in the server.

⇒ NOTE

The current usage will vary depending on the number of processors, the number of I/O card, the number of hard drives, and the size and number of DIMMs on the memory modules installed in your server.

Table 20-3. Server Board Set Voltages and Currents

	+3.3 V		+5 V		+12 V		+5 V Standby		-12 V	
	Min. ¹ Current	Max. ² Current	Min. Current	Max. Current	Min. Current	Max. Current	Min. Current	Max. Current	Min. Current	Max. Current
CPU baseboard with processors	4.6 A	4.6 A	800 mA	6.2 A	0.2 A	28.5 A	0 A	0 A	0 A	0 A
Front panel ⁸	0 A	0 A	50mA	2.23A	3.1A	4.0A	100 mA	1.0A	1 mA	10 mA
Total (CPU baseboard)	4.6 A	4.6 A	850 mA	8.4 A	3.3 A	32.5 A	100 mA	1.0 A	1 mA	10 mA
Total DRAM (8 GB)	2.4 A	27.2 A	0 A	0 A	0 A	0 A	0 A	0 A	0 A	0 A
PHP I/O baseboard	600 mA	5 A	600 mA	4.25 A	0 A	20 mA	5 mA	500 mA	0 A	0 A
PCI/ISA ^{3, 4, 5, 6, 7}	0 A	23 A	0 A	35.68 A	0 A	5.0 A	0 A	0 A	0 A	1.0 A
I/O riser card	0 A	0 A	0 A	70 mA	0 A	30 mA	5 mA	150 mA	0 A	0 A
Total (I/O baseboard)	600 mA A	28 A	600 mA	40 A	0 A	5.05 A	10 mA	650 mA	0 A	1.0 A
Total Current (DRAM, CPU and I/O baseboards)	9.2 A	59.8 A	1.5 A	48.4 A	3.3 S	37.6 A	110 mA	1.7 A	1 mA	1.0 A
Total Power (DRAM, CPU and I/O baseboards)	304 W	197.3 W	7.5 W	242 W	39.6 W	451.2 W	0.55 W	8.5 W	0.01 W	12 W

- 1 Minimum server configuration: one idle processor, two VRMs, three processor termination modules, two memory modules totaling 128 MB DRAM, no I/O adapter cards, front panel with system fans at low speed, I/O riser card, no keyboard, no mouse, no video, no parallel-port connections, and no bus activity.
- 2 Maximum server configuration: four 65 W processors six VRMs operating at 80% efficiency, front panel with system fans at high speed, I/O riser card, keyboard, mouse, video, parallel port connected, two memory modules with 8 GB DRAM, and all I/O adapter slots filled. See notes 3-8. Maximized bus activity.
- 3 Current must not exceed 7.58 A (25 W) per PCI slot or 23 A total for all PCI expansion slots on +3.3 V.
- 4 Current must not exceed 5 A (25 W) per PCI slot or 35.68 A total for all expansion slots on +5 V.
- 5 Current must not exceed 2 A per ISA slot or 35.68 A total for all expansion slots on +5 V.
- 6 Current must not exceed 500 mA per PCI or ISA slot or 5 A total for all expansion slots on +12 V.
- 7 Current must not exceed 100 mA per slot or 1.0 A total for all expansion slots on -12 V.
- 8 These values are included for reference only. They are not included in the maximum configuration requirements.

Calculating Power Usage

Use the worksheets in Tables 20-4 and 20-5 to calculate the total DC power used by your server configuration.

The documentation that comes with each add-in device should specify its current and voltage requirements.

To calculate the total combined wattage for your server, do this:

1. List the current for each board and device in the appropriate voltage level column in Table 20-4.
2. Add the currents in each column of Table 20-4, and enter the total current for each column in Table 20-5.
3. Multiply the voltage by the total current to get the total wattage for each voltage level.
4. Add the total wattage for each voltage level to arrive at a total combined power usage on the power supply.

Table 20-4. Worksheet for Calculating DC Power Usage

Device	Current (maximum) at voltage levels:				
	+3.3 V	+ 5V stby	+5 V	+12 V	-12 V
PHP I/O baseboard	5 A	0.65 A	4.32 A	0.05 A	0 A
16-bit ISA slot, J3B					
32-bit primary PCI slot 1, P1					
32-bit primary PCI slot 2, P2					
32-bit secondary PCI slot 3, P3					
32-bit secondary PCI slot 4, P4					
32-bit secondary PCI slot 5, P5					
32-bit secondary PCI slot 6, P6					
64-bit PCI slot 7, P7					
64-bit PCI slot 8, P8					
64-bit PCI slot 9, P9					
64-bit PCI slot 10, P10					
CPU baseboard with four 65 W processors	4.6 A		6.2 A	28.5 A	
Primary memory module (16 256MB DIMMs)	13.6 A				
Secondary memory module (16 256MB DIMMs)	13.6 A				
3.5-inch diskette drive			0.65 A		
CD-ROM drive			0.55 A	0.60 A	
1st SCA hard disk drive					
2nd SCA hard disk drive					

continued

Table 20-4. Worksheet for Calculating DC Power Usage (continued)

Device	Current (maximum) at voltage levels:				
	+3.3 V	+5 V stby	+5 V	+12 V	-12 V
Front panel plus six cooling fans				4.0 A	
Total Current					

⇒ **NOTE**

The total combined wattage must be less than 935 watts for your server configuration. The current for each voltage level must be less than the limits prescribed by the above power supply output voltage specification; see Table 20-2.

Table 20-5. Total Combined Power Used by Your Server

Voltage Level and Total Current (V x A = W)	Total Watts for Each Voltage Level
(+3.3 V) x (A)	W
(+5 V) x (A)	W
(-5 V) x (A)	W
(+12 V) x (A)	W
(-12 V) x (A)	W
(+5 V Standby) x (A)	W
Total Combined Wattage =	W

21 Back-up Battery: Replacing/Disposing

This chapter tells how to replace the lithium back-up battery on the PHP I/O baseboard.

Warnings and Cautions

Only a *qualified service technician* is authorized to remove the server covers and to access any of the components inside the server. Before removing the covers, see “Safety Guidelines” on page 115.

Tools and Supplies You Need

- Flat-head) screwdriver (#1 bit and #2 bit)
- Antistatic wrist strap (recommended)
- Pen or pencil

Equipment Log

Use the equipment log form provided in Appendix B, “Equipment Log,” to record the model and serial numbers of the server, all installed options, and any other pertinent information about the server. You will need this information when running the SSU.

Back-up Battery

The lithium battery on the PHP I/O baseboard powers the real-time clock (RTC) for up to ten years in the absence of power. The RTC contains 256 bytes of general purpose RAM that stores the system BIOS configuration information, clock registers, and general purpose control registers.

Contact your sales representative or dealer for a list of approved replacement devices and available service.



CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the equipment manufacturer. Discard used battery according to manufacturer's instructions.



ADVARSEL!

Lithiumbatteri - Eksplosjonsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Levér det brugte batteri tilbage til leverandøren.



ADVARSEL!

Lithiumbatteri - Eksplosjonsfare. Ved utskifting benyttes kun batteri som anbefalt av apparatfabrikanten. Brukt batteri returneres apparatleverandøren.



WARNING

Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruktion.




VAROITUS

Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

Replacing the Back-up Battery

See Figure 21-1.

1. Observe the precautions on page 115, “Safety Guidelines.”
2. Turn the server off and unplug the AC power cord.
3. Remove the top cover as described in Chapter 12, “Server Covers: Removing/Reinstalling.”
4. Using the tip of your finger, press down lightly on the lithium battery, and slide it toward the tabs on the socket.
5. Gently lift the battery out of the socket, and dispose of it according to local ordinance.
6. Remove the new battery from its package, and, being careful to observe correct polarity (positive-side up), gently insert it into the battery socket.
7. Reinstall the top cover as described in Chapter 12.
8. Run the SSU to restore the configuration settings to the RTC. For information about running this utility, see Chapter 5, “System Setup Utility: When to Run.”



OM07316

Figure 21-1. Lithium Back-up Battery

- A. Tab
- B. Positive-side up
- C. Battery

22 Solving Problems: Troubleshooting/Error Messages

This chapter helps you identify and solve problems that might occur while you are using the server.

For detailed instructions about removing or installing a component or checking jumpers, see the chapter whose number appears in parentheses after a given checklist item. Also check the Contents and Index for specific page locations.

Warnings and Cautions

Only a *qualified service technician* is authorized to remove the server covers and to access any of the components inside the server. Before removing the covers, see “Safety Guidelines” on page 115.

Resetting the Server

You can reset the server in several ways.

Manually

Press	To
<Ctrl+Alt+Del>	Clear server memory and reload the operating system. This is a "soft boot" reset.
Reset button	Clear server memory, restart POST, and reload the operating system.
Power off/on	Turn the server power off and then on. This is a "cold boot" reset; it has the same effect as pushing the reset button except that power is halted to all peripherals.

Programmed

You can reset the server with software.

Initial Startup of the Server

Problems that occur at initial startup are usually caused by incorrect installation or configuration of the server. Hardware failure is a less frequent cause.

Checklist

- Are all cables correctly connected and secured?
- Are the processors packaged in S.E.C. cartridges fully seated in the slot 2 connectors on the CPU baseboard? (Chapter 13)
- Are front side bus terminator modules installed in all unused slot 2 connectors on the CPU baseboard? (Chapter 13)
- Are the memory modules fully seated in the connectors on the midplane? (Chapter 13)
- Are all DIMMs on the memory module installed correctly? (Chapter 19)
- Are all add-in ISA and PCI boards fully seated in their slots on the PHP I/O baseboard? (Chapter 13)
- Are all jumper settings on the PHP I/O and CPU baseboards correct? (Chapters 17 and 18)
- Are all jumper and switch settings on add-in boards and peripheral devices correct? To check settings, refer to the manufacturer's documentation. Ensure there are no conflicts—for example, two add-in boards sharing the same interrupt.
- Are all add-in boards installed correctly? (Chapter 13)
- If the server has a hard disk drive, is it properly formatted or defined?
- Is the disk backplane configured correctly? (Chapter 16)
- Are all device drivers properly installed? (Chapter 2)
- Are the configuration settings made with the SSU correct? (Chapter 5)
- Is the operating system properly loaded? Refer to the operating system documentation.
- Did you press the on/off power switch on the front panel to turn the server on (power-on LED should be lit)?
- Is the power cord plugged into the AC inlet filter of the server and into a NEMA 5-15R outlet for 100-120 V~ or a NEMA 6-15R outlet for 200-240 V~? (Chapter 2)
- Is AC power available at the wall outlet?

If these items are correct but the problem recurs, refer to "More Troubleshooting Procedures" on page 264.

Running New Application Software

Problems that occur when you run new application software are usually related to the new software. Faulty equipment is much less likely, especially if other software runs correctly.

Checklist

- Does the server meet the minimum hardware requirements for the software? Refer to the software documentation.
- Is the software an authorized copy? If not, get one; unauthorized copies often do not work.
- If you are running the software from a diskette, is it a good copy?
- If you are running the software from a CD, is it scratched or dirty?
- If you are running the software from a hard disk drive, is the software correctly installed? Were all necessary procedures followed and files installed?
- Are the correct device drivers installed?
- Is the software correctly configured for the server?
- Are you using the software correctly?

If the problems persist, contact the software vendor's customer service representative.

After the Server Has Been Running Correctly

Problems that occur after the server hardware and software have been running correctly often indicate equipment failure. Many situations that are easy to correct, however, can also cause such problems.

Checklist

- If you are running the software from a diskette, try a new copy of the software.
- If you are running the software from a CD, try a different CD to see if the problem occurs on all CDs.
- If you are running the software from a hard disk drive, try running it from a diskette. If the software runs correctly, there may be a problem with the copy on the hard disk drive. Reinstall the software on the hard disk drive, and try running it again. Make sure all the necessary files are installed.
- If the problems are intermittent, there may be a loose cable, dirt in the keyboard (if keyboard input is incorrect), a marginal power supply, or other random component failures.
- If you suspect that a transient voltage spike, power outage, or brownout might have occurred, reload the software and try running it again. (For example, symptoms of voltage spikes include a flickering video monitor, unexpected server reboots, and the server does not respond to user commands.)

⇒ NOTE

If you are getting random errors in your data files, they may be getting corrupted by voltage spikes on your power line. If you are experiencing any of the above symptoms that might indicate voltage spikes on the power line, you may want to install a surge suppressor between the power outlet and the server power cord.

- ❑ If the problem recurs after you have checked and corrected all the above items, refer to "More Troubleshooting Procedures" on page 264.
- ❑ If you receive any error messages, refer to "Error Codes and Messages" on page 269 for an explanation and suggestions.

More Troubleshooting Procedures

This section provides a more detailed approach to identifying a problem and locating its source.

Preparing the Server for Diagnostic Testing

**CAUTION**

Before disconnecting any peripheral cables from the server, turn off the server and any external peripheral devices. Failure to do so can cause permanent damage to the server and/or the peripheral devices.

1. Turn off the server and all external peripheral devices. Disconnect all devices from the server, except the keyboard and video monitor.
2. Make sure the server power cord is plugged into a properly grounded AC outlet. (Chapter 2)
3. Make sure your video monitor and keyboard are correctly connected to the server. Turn on the monitor. Set its brightness and contrast controls to at least two-thirds of their maximum ranges (refer to the documentation supplied with your monitor).
4. If the operating system normally loads from the hard disk drive, make sure there is no diskette in drive A. If the OS normally loads from a diskette, place the diskette containing the OS files in drive A.
5. Turn on the server. If the power LED does not light, refer to "Power Light Does Not Light" on page 266.

Monitoring POST

See Chapter 3.

Verifying Proper Operation of the Server Lights

As POST determines the server configuration, it tests for the presence of each mass storage device installed in the server. As each device is checked, its activity light should turn on briefly. Check for the following:

- ❑ Does the diskette drive activity light turn on briefly? If not, refer to "Diskette Drive Activity Light Does Not Light" on page 268.
- ❑ If there is a hard disk drive or a SCSI device installed in the server, does the drive activity light on the front panel turn on briefly? If not, refer to "Hard Disk Drive Activity Light Does Not Light" on page 268.

⇒ NOTE

For information about the controls and indicators, see Chapter 1.

Confirming Loading of the Operating System

Once the server boots up, the operating system prompt appears on the screen. The prompt varies according to the operating system. If the operating system prompt does not appear, refer to "Initial Startup of the Server" on page 262.

Specific Problems and Corrective Actions

This section provides possible solutions for the following specific problems:

- Power light does not light.
- Server cooling fans do not rotate or rotate slowly.
- No characters appear on screen.
- Characters on the screen appear distorted or incorrect.
- No beep or incorrect beep pattern emitted.
- Activity light on the diskette drive does not light.
- Activity light on the hard disk drive does not light.
- Activity light on the CD-ROM drive does not light.
- Application software problems are unresolved.
- Server powers up, and it immediately powers down.

Try the solutions in the order given. If you cannot correct the problem, contact your service representative or authorized dealer for assistance.

Power Light Does Not Light

Check the following:

- Is the server operating normally? If so, the power LED is probably defective.
- Are there other problems with the server? If so, check the items listed under "Server Cooling Fans Do Not Rotate Properly."
- Is the yellow power supply failure LED flashing? If so, replace the failing power supply.

If all items are correct and problems persist, contact your service representative or authorized dealer for assistance.

Server Cooling Fans Do Not Rotate Properly

If the server cooling fans are not operating properly, server components will be damaged.

⇒ NOTE

The server contains six fans that provide cooling for the components. The integrated fan on each power supply provides more cooling for the SCSI hard disk drives in the hot-docking bays. In case of cooling problems, you cannot access or replace the fans integrated in the power supplies. There are no serviceable components in the power supply. If the power supply is opened, the warranty is voided.

Check the following:

- Is AC power available at the wall outlet?
- Is the server power cord properly connected to AC inlet filter and the wall outlet?
- Did you press the power on/off push-button switch?
- Is the power-on light lit?
- Have any of the fan motors stopped (use the server management subsystem to check the fan status)?

If switches and connections are correct and AC power is available at the wall outlet, contact your service representative or authorized dealer for assistance.

No Characters Appear on Screen

Check the following:

- Is the keyboard working?
- Is the video monitor plugged in and turned on?
- Are the brightness and contrast controls on the video monitor properly adjusted?
- Are the switch settings on the video monitor correct?
- Is the video monitor signal cable properly installed?

If you are using an add-in video controller board, do the following:

1. Verify that the video controller board is fully seated in the PHP I/O baseboard connector.
2. Run the SSU to specify that an add-in VGA/EGA controller board is installed.
3. Reboot the server for changes to take effect.
4. If there are still no characters on the screen after you reboot the server and POST emits a beep code, write down the beep code you hear. This information is useful for your service representative. See "Error Codes and Messages" on page 269.
5. If you do not receive a beep code and characters do not appear, the video monitor or video controller may have failed. Contact your service representative or authorized dealer for assistance.

Characters Are Distorted or Incorrect

Check the following:

- Are the brightness and contrast controls properly adjusted on the video monitor? Refer to the manufacturer's documentation.
- Are the video monitor signal and power cables properly installed?

If the problem persists, the monitor may be faulty or it may be the incorrect type. Contact your service representative or authorized dealer for assistance.

Incorrect or no Beep Codes

If the server operates normally but there was no beep, the speaker may be defective. Run the SSU to verify that the speaker is enabled (Chapter 5). If the speaker is enabled but not functioning, contact your service representative or authorized dealer for assistance.

Record the beep code emitted by POST, and refer to "Error Codes and Messages" on page 269 for information about beep codes and error messages.

Diskette Drive Activity Light Does Not Light

Check the following:

- Are the power and signal cables to the diskette drive properly installed?
- Are all relevant switches and jumpers on the diskette drive set correctly?
- Is the diskette drive properly configured?
- Is the diskette drive activity light always on? If so, the signal cable may be plugged in incorrectly.

If you are using the onboard diskette controller, use the SSU to make sure that controller is enabled. If you are using an add-in diskette controller, make sure that the onboard controller is disabled. (Chapter 5)

If the problem persists, there may be a problem with the diskette drive, PHP I/O baseboard, or drive signal cable. Contact your service representative or authorized dealer for assistance.

Hard Disk Drive Activity Light Does Not Light

If you have installed one or more hard disk drives in your server, check the following:

- Are the power and signal cables to the IDE hard disk drive properly installed?
- Are all relevant switches and jumpers on the hard disk drive and controller board set correctly?
- Is the onboard IDE controller enabled?

⇒ NOTE

The hard disk drive activity light on the front panel lights when either an IDE hard disk drive or SCSI device is in use.

- Is the hard disk drive properly configured?
- Are the SCSI signal cables properly connected to the peripheral bay backplane?

If you received error messages, refer to "Error Codes and Messages" on page 269 for information about error messages.

If you did not receive error messages, run the SSU and make sure the hard disk drive is configured with the correct parameters. (Chapter 5)

If the problem persists, there may be a problem with the hard disk drive, PHP I/O baseboard, drive signal cable, or LED connector. Contact your service representative or authorized dealer for assistance.

Problems With Application Software

If you have problems with application software, do the following:

1. Verify that the software is properly configured for the server. Refer to the software installation and operation documentation to set up and use the software.
2. Try a different copy of the software to see if the problem is with the copy you are using.
3. Make sure all cables are installed correctly.
4. Verify that the baseboard jumpers are set correctly.
5. If other software runs correctly on the server, contact your vendor about the failing software.

If the problem persists, contact the software vendor's customer service representative for assistance.

Server Powers Up and Immediately Powers Down

If the server powers up after a DC power failure and then immediately powers down, check the power supply failure LED. If it is lit, wait until it goes out before turning the server back on. If the LED does not go out, you may have to unplug the power cord from the AC wall outlets. When the LED goes out, plug the power cords back into the outlets.

If the problem persists, the power distribution backplane may be defective. Contact your service representative or authorized dealer for assistance.

Error Codes and Messages

The server BIOS displays POST error codes and messages on the video monitor. When you turn on the server, POST displays messages that provide information about the server. If a failure occurs, POST emits beep codes that indicate errors in hardware, software, or firmware. Before the video adapter is initialized, audible beep codes inform you of errors. The errors are logged in the event log and the Extended BIOS Data Area (EBDA). If POST can display a message on the monitor, it causes the speaker to beep twice as the message appears.

Port 80h Codes

After the video adapter has been successfully initialized after the server is turned on, the BIOS indicates the current testing phase during POST by writing a 2-digit hex code to I/O location 80h. If a port-80h card is installed, it displays this 2-digit code on a pair of hex display LEDs.

The following table contains the port-80h codes displayed during the boot process. The table also describes the error conditions associated with each beep code and the corresponding POST checkpoint (CP) code as seen by a port-80h card. A beep code is a series of individual beeps emitted by the server speaker, each equal in length. For example, if an error occurs at checkpoint 20h, a beep code of 1-3-1-1 is generated (1 = a single beep, 3 = burst of three beeps).

CP	Beeps	Reason
02		Verify real mode
04		Get processor type
06		Initialize system hardware
08		Initialize chip set registers with initial POST values
09		Set in-POST flag
0A		Initialize processor registers
0B		Enable processor cache
0C		Initialize caches to initial POST values
0E		Initialize I/O
0F		Initialize the local bus IDE
10		Initialize Power Management
11		Load alternate registers with initial new POST values
12		Restore processor control word during warm boot
14		Initialize keyboard controller
16	1-2-2-3	BIOS ROM checksum
18		Initialize 8254 timer
1A		Initialize 8237 DMA controller
1C		Reset Programmable Interrupt Controller
20	1-3-1-1	Test DRAM refresh
22	1-3-1-3	Test 8742 Keyboard Controller
24		Set ES segment register to 4 GB
28	1-3-3-1	Autosize DRAM
2A		Clear 512K base RAM
2C	1-3-4-1	RAM failure on address line xxxx*
2E	1-3-4-3	RAM failure on data bits xxxx* of low byte of memory bus
30	1-4-1-1	RAM failure on data bits xxxx* of high byte of memory bus
32		Test processor bus-clock frequency
34		Test CMOS
35		RAM initialize alternate chip set registers
36		Warm start shutdown

continued

Port 80h Codes (continued)

CP	Beeps	Reason
37		Reinitialize the chip set (MB only)
38		Shadow system BIOS ROM
39		Reinitialize the cache (MB only)
3A		Autosize cache
3C		Configure advanced chip set registers
3D		Load alternate registers with new CMOS values
40		Set initial new processor speed
42		Initialize interrupt vectors
44		Initialize BIOS interrupts
46	2-1-2-3	Check ROM copyright notice
47		Initialize manager for PCI Option ROMs
48		Check video configuration against CMOS
49		Initialize PCI bus and devices
4A		Initialize all video adapters in system
4B		Display QuietBoot screen
4C		Shadow video BIOS ROM
4E		Display copyright notice
50		Display processor type and speed
52		Test keyboard
54		Set key click if enabled
56		Enable keyboard
58	2-2-3-1	Test for unexpected interrupts
5A		Display prompt "Press F2 to enter SETUP"
5C		Test RAM between 512 and 640k
60		Test extended memory
62		Test extended memory address lines
64		Jump to UserPatch1
66		Configure advanced cache registers
68		Enable external and processor caches
6A		Display external cache size
6C		Display shadow message
6E		Display nondisposable segments
70		Display error messages
72		Check for configuration errors
74		Test real-time clock
76		Check for keyboard errors
7A		Test for key lock on
7C		Set up hardware interrupt vectors
7E		Test coprocessor if present

continued

Port 80h Codes (continued)

CP	Beeps	Reason
80		Detect and install external RS232 ports
82		Detect and install external parallel ports
85		Initialize PC-compatible PnP ISA devices
86		Reinitialize onboard I/O ports
88		Initialize BIOS Data Area
8A		Initialize Extended BIOS Data Area
8C		Initialize floppy controller
90		Initialize hard disk controller
91		Initialize local bus hard disk controller
92		Jump to UserPatch2
93		Build MPTABLE for multiprocessor boards
94		Disable A20 address line
95		Install CD ROM for boot
96		Clear huge ES segment register
98	1-2	Search for option ROMs; one long beep and two short beeps on checksum failure
9A		Shadow option ROMs
9C		Set up Power Management
9E		Enable hardware interrupts
A0		Set time of day
A2		Check key lock
A4		Initialize typematic rate
A8		Erase F2 prompt
AA		Scan for F2 key stroke
AC		Enter SETUP
AE		Clear in-POST flag
B0		Check for errors
B2		POST done—prepare to boot operating system
B4	1	One short beep before boot
B5		Display MultiBoot menu
B6		Check password (optional)
B8		Clear global descriptor table
BC		Clear parity checkers
BE		Clear screen (optional)
BF		Check virus and backup reminders
C0		Try to boot with INT 19
D0		Interrupt handler error
D2		Unknown interrupt error
D4		Pending interrupt error

continued

Port 80h Codes (continued)

CP	Beeps	Reason
D6		Initialize option ROM error
D8		Shutdown error
DA		Extended Block Move
DC		Shutdown 10 error
FB		FRB in progress
FC		Five second wait for BMC to initialize
FD		FRB 2 watchdog timer failed, reset will occur in five seconds

POST Error Codes and Messages

The table below contains POST error codes and their associated messages.

Code	Error message
0002	Primary boot device not found
0010	Cache memory failure, do not enable cache
0015	Primary output device not found
0016	Primary input device not found
0042	ISA Config contains invalid info
0050	PnP memory conflict
0051	PnP 32-bit memory conflict
0052	PnP IRQ conflict
0053	PnP DMA conflict
0054	PnP error log is full
0055	Bad PnP serial id checksum
0056	Bad PnP resource data checksum
0060	Keyboard is locked ... Please unlock it
0070	CMOS time & date not set
0080	Option ROM has bad checksum
0083	Shadow of PCI ROM failed
0085	Shadow of ISA ROM failed
0131	Floppy drive A:
0132	Floppy drive B:
0135	Floppy disk controller failure
0140	Shadow of System BIOS Failed
0170	Disabled CPU slot #
0171	CPU Failure—CPU # 1
0172	CPU Failure—CPU # 2
0173	CPU Failure—CPU # 3
0174	CPU Failure—CPU # 4
0175	CPU modules are incompatible or one is not present.

continued

POST Error Codes and Messages (continued)

Code	Error message
0176	Previous CPU Failure—CPU # 1
0177	Previous CPU Failure—CPU # 2
0178	Previous CPU Failure—CPU # 3
0179	Previous CPU Failure—CPU # 4
0180	Attempting to boot with failed CPU
0181	BSP switched, system may be in uniprocessor mode
0191	CMOS battery failed
0195	CMOS system options not set
0198	CMOS checksum invalid
0289	System memory size mismatch
0295	Address line short detected
0297	Memory size decreased
0299	ECC Error Correction failure
0370	Keyboard controller error
0373	Keyboard stuck key detected
0375	Keyboard and mouse swapped
0430	Timer Channel 2 failure
0440	Gate-A20 failure
0441	Unexpected interrupt in protected mode
0445	Master interrupt controller error
0446	Slave interrupt controller error
0450	Master DMA controller error
0451	Slave DMA controller error
0452	DMA controller error
0460	Fail-safe timer NMI failure
0461	Software port NMI failure
0465	Bus time-out NMI in slot
0467	Expansion board NMI in slot
0510	PCI parity error
0710	Baseboard device resource conflict
0711	Static device resource conflict
0780	PCI Segment 1 memory request exceeds 998 MB
0781	PCI Segment 1 I/O requests exceeds 12K
0782	PCI I/O request exceeds amount available
0783	PCI memory request exceeds amount available
0784	Illegal bus for memory request below 1 MB
0785	Memory request below 1 MB exceeds 1 MB
0800	PCI I/O port conflict
0801	PCI memory conflict

continued

POST Error Codes and Messages (continued)

Code	Error message
0802	PCI IRQ conflict
0804	PCI ROM not found, may be OK for this card
0805	Insufficient memory to shadow PCI ROM
0806	Memory allocation failure for second PCI segment
0810	Floppy disk controller resource conflict
0811	Primary IDE controller resource conflict
0812	Secondary IDE controller resource conflict
0815	Parallel port resource conflict
0816	Serial port 1 resource conflict
0817	Serial port 2 resource conflict
0820	Expansion board disabled in slot
0900	NVRAM checksum error, NVRAM cleared
0903	NVRAM data invalid, NVRAM cleared
0982	I/O expansion board NMI in slot
0984	Expansion board disabled in slot
0985	Fail-safe timer NMI
0986	System reset caused by watchdog timer
0987	Bus time-out NMI in slot
8100	Processor 0 failed BIST
8101	Processor 1 failed BIST
8102	Processor 2 failed BIST
8103	Processor 3 failed BIST
8104	Processor 0 internal error (IERR)
8105	Processor 1 internal error (IERR)
8106	Processor 0 thermal trip error
8107	Processor 1 thermal trip error
8108	Watchdog timer failed on last boot
810B	Processor 0 failed initialization
810C	Processor 0 disabled
810D	Processor 1 disabled
810E	Processor 0 failed FRB-3 timer
810F	Processor 1 failed FRB-3 timer
8110	Server management interface failed to function
8128	Processor 2 internal error (IERR)
8129	Processor 3 internal error (IERR)
8130	Processor 2 thermal trip error
8131	Processor 3 thermal trip error
8138	Processor 2 failed FRB-3 timer
8139	Processor 3 failed FRB-3 timer

continued

POST Error Codes and Messages (continued)

Code	Error message
8140	Processor 2 disabled
8141	Processor 3 disabled
8148	Processor 1 failed initialization
8149	Processor 2 failed initialization
814A	Processor 3 failed initialization
8150	NVRAM cleared by jumper
8152	ESCD data cleared
8153	Password cleared by jumper
8160	Unable to apply BIOS update for processor 1
8161	Unable to apply BIOS update for processor 2
8162	Unable to apply BIOS update for processor 3
8163	Unable to apply BIOS update for processor 4
8168	Processor 1 L2 cache failed
8169	Processor 2 L2 cache failed
816A	Processor 3 L2 cache failed
816B	Processor 4 L2 cache failed
8170	BIOS does not support current stepping for processor 1
8171	BIOS does not support current stepping for processor 2
8172	BIOS does not support current stepping for processor 3
8173	BIOS does not support current stepping for processor 4
8180	PXB1 failed to respond
8181	Mismatch among processors detected
8182	L2 cache size mismatch
8200	Baseboard management controller failed to function
8201	Front panel controller failed to function
8203	Primary hot-swap controller failed to function
8204	Secondary hot-swap controller failed to function

23 Front Panel: Description/Voltages

This chapter describes the front panel.

Warnings and Cautions

Only a *qualified service technician* is authorized to remove the server covers and to access any of the components inside the server. Before removing the covers, see “Safety Guidelines” on page 115.

Front Panel Board

The front panel board provides the user interface to the server. Three push-button switches control server power, reset, and NMI assertion. Four LEDs indicate power on, power supply failure, hard drive failure, and fan or other server cooling failure. The LCD panel provides information about the server such as boot status, available number of processors, and other server management information.

The front panel board also allows other servers to communicate with this server—even while power is down—via an external Intelligent Chassis Management Bus (ICMB). The ICMB is an extension of the internal ICMB. A Phillips 80C652 microcontroller on the board controls all front panel functions while AC power is available.

The board connects to the rest of the server through a connector on the CPU baseboard. All six system fans plug into hot-plug connectors on the front panel board. The microcontroller controls fan speed, monitors fan tachometer outputs, and indicates via LEDs—one for each fan—when fan failures occur. The converter circuit converts 8.4 VDC to 12 VDC and provides over current protection.

Fan Speed Control Voltage

The server fans operate at two speeds: slow and fast. The low voltage setting allows the fans to run at a slower speed to minimize acoustic noise under normal conditions. When the Front Panel Controller (FPC) senses a fan failure or the ambient air temperature sensor reads 30 °C or higher, it sets the fan voltage to high to increase the fan speed. The ambient air temperature must drop to 28 °C or the failing condition must be cleared before the FPC returns the fans to slow speed again. When the ambient air temperature reads between 28 °C and 30 °C, the fans remain at their current speed.

Table 23-1. Fan Speed Control

Fan Failure	Ambient Air Temperature	Fan Speed	Voltage
No	<28°C	Slow	Low
Yes	<28°C	Fast	High
No	>30°C	Fast	High
Yes	>30°C	Fast	High

Speaker

Either the FPC or the PHP I/O baseboard can control the speaker on the front panel board.

I²C Bus

The private I²C bus monitors failures and voltage margining in the server. The 5 V standby voltage provides power for the bus, and it is available even when server power is off.

24 Peripheral Bay Blindmate Board: Description

This chapter describes the peripheral bay blindmate board.


Warnings and Cautions

Only a *qualified service technician* is authorized to remove the server covers and to access any of the components inside the server. Before removing the covers, see “Safety Guidelines” on page 115.

Features

The peripheral bay blindmate board provides power and signal interconnection from the midplane and PHP I/O baseboard to the system peripheral devices (diskette drive and CD ROM drive) and the disk backplane.

Peripheral Bay Blindmate Connectors



OM07329

Figure 24-1. Peripheral Bay Blindmate Connectors

- A. Bindmate connector (J1)
- B. Power connector (J2)
- C. Wide SCSI connector (J5)
- D. Reserved (J6)
- E. IDE connector (J4)
- F. Diskette connector (J3)

Blind Mate Connector J1

Pins	Signals				
	A	B	C	D	E
1	RESET(1)	GND	DD8 (4)	GND	FD_DSKCHG_L
2	DD7 (3)	GND	DD9 (6)	GND	FD_HDSEL_L
3	DD6 (5)	GND	DD10 (8)	GND	FD_RDATA_L
4	DD5 (7)	GND	DD11 (10)	GND	FD_WPROT_L
5	DD4 (9)	GND	DD12 (12)	GND	FD_MSEN0
6	DD3 (11)	GND	DD13 (14)	GND	FD_TRK0_L
7	DD2 (13)	GND	DD14 (16)	GND	FD_WGATE_L
8	DD1 (15)	GND	DD15 (18)	GND	FD_WDATA_L
9	DD0 (17)	GND	GND	GND	FD_STEP_L
10	GND	GND	DIOW (23)	GND	FD_DIR_L
11	DMARQ (21)	GND	CSEL (28)	GND	FD_MSEN1
12	GND	GND	DIOR (25)	GND	FD_MTR1_L
13	IORDY (27)	GND	GND	GND	FD_DR0_L
14	DMACK (29)	GND	RESERVED (32)	GND	FD_DR1_L
15	GND	GND	PDIAG (34)	GND	FD_MTR0_L
16	INTRQ (31)	GND	DA2 (36)	GND	FD_INDEX_L
17	DA1 (33)	GND	CS0 (37)	GND	FD_DRATE0
18	DASP (39)	GND	DA0 (35)	GND	KEY
19	GND	GND	CS1 (38)	GND	N/C
20	GND	GND	GND	GND	FD_DENSEL
21	GND	GND	GND	GND	OEM 1
22	GND	GND	S68 (-DB 11)	GND	OEM 2
23	GND	GND	S34 (+DB 11)	GND	OEM 3
24	GND	GND	S65 (-DB8)	S32 (+DB 9)	S67 (-DB 10)
25	+12v	+12v	S31 (+DB 8)	S66 (-DB 9)	S33 (+DB 10)
26	+12v	+12v	S62 (-C/D)	S29 (+REQ)	S64 (-I/O)
27	+12v	+12v	S28 (+C/D)	S63 (-REQ)	S30 (+I/O)
28	+12v	+12v	S59 (-RST)	S26 (+MSG)	S61 (-SEL)
29	+12v	+12v	S25 (+RST)	S60 (-MSG)	S27 (+SEL)
30	+12v	+12v	S56	S23 (+BSY)	S58 (-ACK)
31	+12v	+12v	S22	S57 (-BSY)	S24 (+ACK)
32	+12v	+12v	S53 (RESERVED)	S20	S55 (-ATN)
33	+12v	+12v	S19 (RESERVED)	S54	S21 (+ATN)
34	+12v	+12v	S50	S17 (TERMPWR)	S52 (TERMPWR)
35	+12v	+12v	S16 (DIFFSENS)	S51 (TERMPWR)	S18 (TERMPWR)
36	+12v	+12v	S47 (-DB 7)	S14 (+DB P)	S49
37	+5v	+5v	S13 (+DB 7)	S48 (-DB P)	S15
38	+5v	+5v	S44 (-DB 4)	S11 (+DB5)	S46 (-DB 6)
39	+5v	+5v	S10 (+DB 4)	S45 (-DB 5)	S12 (+DB 6)
40	+5v	+5v	S41 (-DB 1)	S8 (+DB 2)	S43 (-DB 3)
41	+5v	+5v	S7 (+DB 1)	S42 (-DB 2)	S9 (+DB 3)
42	+5v	+5v	S38 (-DB 15)	S5 (+DB P1)	S40 (-DB 0)
43	+5v	+5v	S4 (+DB 15)	S39 (-DB P1)	S6 (+DB 0)
44	+5v	+5v	S35 (-DB 12)	S2 (+DB 13)	S37 (-DB 14)
45	+5v	+5v	S1 (+DB 12)	S36 (-DB 13)	S3 (+DB 14)
46	+5v	+5v	GND	GND	GND
47	+5v	+5v	GND	SDA	Reserved
48	+5v	+5v	GND	PWR_GOOD	SCL

Power Connector J2

Pin	Signal	Pin	Signal
1	+12v	11	+12v
2	GND	12	GND
3	+12v	13	+12v
4	+5v	14	+5v
5	GND	15	GND
6	+5v	16	+5v
7	GND	17	GND
8	SCL	18	SDA
9	GND	19	GND
10	PWR_GOOD	20	Reserved

Diskette Connector J3

Pin	Signal	Pin	Signal
1	GND	2	FD_DENSEL
3	GND	4	N/C
5	KEY	6	FD_DRATE0
7	GND	8	FD_INDEX_L
9	GND	10	FD_MTR0_L
11	GND	12	FD_DR1_L
13	GND	14	FD_DR0_L
15	GND	16	FD_MTR1_L
17	FD_MSEN1	18	FD_DIR_L
19	GND	20	FD_STEP_L
21	GND	22	FD_WDATA_L
23	GND	24	FD_WGATE_L
25	GND	26	FD_TRK0_L
27	FD_MSEN0	28	FD_WPROT_L
29	GND	30	FD_RDATA_L
31	GND	32	FD_HDSEL_L
33	GND	34	FD_DSKCHG_L

IDE Connector J4

Pin	Signal	Pin	Signal
1	RESET	2	GND
3	DD7	4	DD8
5	DD6	6	DD9
7	DD5	8	DD10
9	DD4	10	DD11
11	DD3	12	DD12
13	DD2	14	DD13
15	DD1	16	DD14
17	DD0	18	DD15
19	GND	20	KEYPIN (NC)
21	DMARQ	22	GND
23	DIOW	24	GND
25	DIOR	26	GND
27	IORDY	28	CSEL
29	DMACK	30	GND
31	INTRQ	32	RESERVED
33	DA1	34	PDIAG
35	DA0	36	DA2
37	CS0	38	CS1
39	DASP	40	GND

Wide SCSI Connector J5

Pin	Signal	Pin	Signal
1	S1 (+DB 12)	35	S35 (-DB 12)
2	S2 (+DB 13)	36	S36 (-DB 13)
3	S3 (+DB 14)	37	S37 (-DB 14)
4	S4 (+DB 15)	38	S38 (-DB 15)
5	S5 (+DB P1)	39	S39 (-DB P1)
6	S6 (+DB 0)	40	S40 (-DB 0)
7	S7 (+DB 1)	41	S41 (-DB 1)
8	S8 (+DB 2)	42	S42 (-DB 2)
9	S9 (DB 3)	43	S43 (-DB 3)
10	S10 (+DB 4)	44	S44 (-DB 4)
11	S11 (+DB5)	45	S45 (-DB 5)
12	S12 (+DB 6)	46	S46 (-DB 6)
13	S13 (+DB 7)	47	S47 (-DB 7)
14	S14 (+DB P)	48	S48 (-DB P)
15	S15	49	S49
16	S16 (DIFFSENS)	50	S50
17	S17 (TERMPWR)	51	S51 (TERMPWR)
18	S18 (TERMPWR)	52	S52 (TERMPWR)
19	S19 (RESERVED)	53	S53 (RESERVED)
20	S20	54	S54
21	S21 (+ATN)	55	S55 (-ATN)
22	S22	56	S56
23	S23 (+BSY)	57	S57 (-BSY)
24	S24 (+ACK)	58	S58 (-ACK)
25	S25 (+RST)	59	S59 (-RST)
26	S26 (+MSG)	60	S60 (-MSG)
27	S27 (+SEL)	61	S61 (-SEL)
28	S28 (+C/D)	62	S62 (-C/D)
29	S29 (+REQ)	63	S63 (-REQ)
30	S30 (+I/O)	64	S64 (-I/O)
31	S31 (+DB 8)	65	S65 (-DB8)
32	S32 (+DB 9)	66	S66 (-DB 9)
33	S33 (DB +10)	67	S67 (-DB 10)
34	S34 (DB +11)	68	S68 (-DB 11)

A Regulatory Specifications

The AC450NX server meets specifications and regulations for safety and EMC.

Declaration of Compliance

The CE marking on this product indicates that it is in compliance with the European community's EMC Directive (89/336/EEC) and Low Voltage Directive (73123/EEC)

Safety Compliance

USA/Canada:	UL 1950-CSA 950-95
Europe:	TUV to EN60950 (A1+A2+A3+A4) EU Low Voltage Directive (73/23/EEC) (CE Mark)
International:	CB Certificate to IEC950 plus EMKO-TSE(74-SEC) 207/94

Electromagnetic Compatibility (EMC)

USA:	FCC 47 CFR Parts 2 and 15, Class A
Canada:	ICES-003 Class A
Europe:	EN55022, Class A EN50082-1 EN61000-4-2 Electrostatic Discharge (ESD) EN61000-4-3 Radiated Immunity IEN61000-4-4 Electrical Fast Transient EN 61000-3-2; -3, Harmonic Currents EU EMC Directive 89/336/EEC (CE Mark)
International:	CISPR 22, Class A
Australia/New Zealand:	AS/NZS 3548, Class A Limits (using CISPR 22 Class A Limits)
Japan:	VCCI Class A ITE (using CISPR 22 Class A Limit)

Electromagnetic Compatibility Notice (USA)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

⇒ NOTE

If a Class A device is installed within this system, then the system is to be considered a Class A system. In this configuration, operation of this equipment in a residential area is likely to cause harmful interference.

Electromagnetic Compatibility Notices (International)

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラス A 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

English translation of the notice above:

This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may arise. When such trouble occurs, the user may be required to take corrective actions.

Cet appareil numérique respecte les limites bruits radioélectriques applicables aux appareils numériques de Classe A prescrites dans la norme sur le matériel brouilleur: “Appareils Numériques”, NMB-003 édictée par le Ministre Canadian des Communications.

English translation of the notice above:

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the interference-causing equipment standard entitled “Digital Apparatus,” ICES-003 of the Canadian Department of Communications.

B Equipment Log

Use this equipment log to record pertinent information about your server. You will need some of this information when you run the System Setup Utility (SSU).

Record the model and serial numbers of the server components, dates of component removal or replacement, and the vendor's name. Be sure to record the same information for any components added to the server, such as hard disk drives, add-in boards, or printers.

The location of serial numbers on add-in boards, hard disk drives, and external equipment, such as video monitors or printers, varies from one manufacturer to another.

Equipment Log

Component	Manufacturer and Model Number	Serial Number	Date Installed
Server			
PHP I/O Baseboard			
I/O Riser Card			
CPU Baseboard			
Front Panel Board			
Processor 1			
Processor 2			
Processor 3			
Processor 4			
VRM 1			
VRM 2			
VRM 3			
VRM 4			
VRM 5			
VRM 6			
Memory Module 1			
Memory Module 2			
Midplane			
Peripheral Bay Backplane			
Hot-swappable Power Supply			
Hot-swappable Power Supply			
Hot-swappable Power Supply			
Video Monitor			
Keyboard			
Mouse			

continued

C Warnings

WARNING: English (US)


AVERTISSEMENT: Français

WARNUNG: Deutsch


AVVERTENZA: Italiano

ADVERTENCIAS: Español


WARNING: English (US)




The power supply in this product contains no user-serviceable parts. There may be more than one supply in this product. Refer servicing only to qualified personnel.



Do not attempt to modify or use the supplied AC power cord if it is not the exact type required.




The DC push-button on/off switch on the system does not turn off system AC power. To remove AC power from the system, you must unplug each AC power cord from the wall outlet or power supply.




SAFETY STEPS: Whenever you remove the chassis covers to access the inside of the system, follow these steps:

1. Turn off all peripheral devices connected to the system.
2. Turn off the system by using the push-button on/off power switch on the system.
3. Unplug all AC power cords from the system or from wall outlets.
4. Label and disconnect all cables connected to I/O connectors or ports on the back of the system.
5. Provide some electrostatic discharge (ESD) protection by wearing an antistatic wrist strap attached to chassis ground of the system—any unpainted metal surface—when handling components.
6. Do not operate the system with the chassis covers removed.

After you have completed the six SAFETY steps above, you can remove the system covers. To do this:




1. Remove and save all screws from the covers.
2. Remove the covers.




For proper cooling and airflow, always reinstall the chassis covers before turning on the system. Operating the system without the covers in place can damage system parts. To install the covers:

1. Check first to make sure you have not left loose tools or parts inside the system.
2. Check that cables, add-in boards, and other components are properly installed.
3. Attach the covers to the chassis with the screws removed earlier, and tighten them firmly.
4. Connect all external cables and the AC power cord(s) to the system.


continued

WARNING: English (continued)

A microprocessor and heat sink may be hot if the system has been running. Also, there may be sharp pins and edges on some board and chassis parts. Contact should be made with care. Consider wearing protective gloves.




Danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the equipment manufacturer. Discard used batteries according to manufacturer's instructions.




The system is designed to operate in a typical office environment. Choose a site that is:

- Clean and free of airborne particles (other than normal room dust).
- Well ventilated and away from sources of heat including direct sunlight.
- Away from sources of vibration or physical shock.
- Isolated from strong electromagnetic fields produced by electrical devices.
- In regions that are susceptible to electrical storms, we recommend you plug your system into a surge suppresser and disconnect telecommunication lines to your modem during an electrical storm.
- Provided with a properly grounded wall outlet.
- Provided with sufficient space to access the power supply cords, because they serve as the product's main power disconnect.


AVERTISSEMENT: Français




Le bloc d'alimentation de ce produit ne contient aucune pièce pouvant être réparée par l'utilisateur. Ce produit peut contenir plus d'un bloc d'alimentation. Veuillez contacter un technicien qualifié en cas de problème.



Ne pas essayer d'utiliser ni modifier le câble d'alimentation CA fourni, s'il ne correspond pas exactement au type requis.




Notez que le commutateur CC de mise sous tension /hors tension du panneau avant n'éteint pas l'alimentation CA du système. Pour mettre le système hors tension, vous devez débrancher chaque câble d'alimentation de sa prise.




CONSIGNES DE SÉCURITÉ - Lorsque vous ouvrez le boîtier pour accéder à l'intérieur du système, suivez les consignes suivantes :

1. Mettez hors tension tous les périphériques connectés au système.
2. Mettez le système hors tension en mettant l'interrupteur général en position OFF (bouton-poussoir).
3. Débranchez tous les cordons d'alimentation c.a. du système et des prises murales.
4. Identifiez et débranchez tous les câbles reliés aux connecteurs d'E-S ou aux accès derrière le système.
5. Pour prévenir les décharges électrostatiques lorsque vous touchez aux composants, portez une bande antistatique pour poignet et reliez-la à la masse du système (toute surface métallique non peinte du boîtier).
6. Ne faites pas fonctionner le système tandis que le boîtier est ouvert.



Une fois TOUTES les étapes précédentes accomplies, vous pouvez retirer les panneaux du système. Procédez comme suit :

1. Retirez toutes les vis des panneaux et mettez-les dans un endroit sûr.
2. Retirez les panneaux.




Afin de permettre le refroidissement et l'aération du système, réinstallez toujours les panneaux du boîtier avant de mettre le système sous tension. Le fonctionnement du système en l'absence des panneaux risque d'endommager ses pièces. Pour installer les panneaux, procédez comme suit :


1. Assurez-vous de ne pas avoir oublié d'outils ou de pièces démontées dans le système.
2. Assurez-vous que les câbles, les cartes d'extension et les autres composants sont bien installés.
3. Revissez solidement les panneaux du boîtier avec les vis retirées plus tôt.
4. Rebranchez tous les cordons d'alimentation c. a. et câbles externes au système.

suite


AVERTISSEMENT: Français (suite)



Le microprocesseur et le dissipateur de chaleur peuvent être chauds si le système a été sous tension. Faites également attention aux broches aiguës des cartes et aux bords tranchants du capot. Nous vous recommandons l'usage de gants de protection.




Danger d'explosion si la batterie n'est pas remontée correctement. Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le fabricant. Disposez des piles usées selon les instructions du fabricant.




Le système a été conçu pour fonctionner dans un cadre de travail normal. L'emplacement choisi doit être :

- Propre et dépourvu de poussière en suspension (sauf la poussière normale).
 - Bien aéré et loin des sources de chaleur, y compris du soleil direct.
 - A l'abri des chocs et des sources de vibrations.
 - Isolé de forts champs électromagnétiques générés par des appareils électriques.
 - Dans les régions sujettes aux orages magnétiques il est recommandé de brancher votre système à un supresseur de surtension, et de débrancher toutes les lignes de télécommunications de votre modem durant un orage.
 - Muni d'une prise murale correctement mise à la terre.
 - Suffisamment spacieux pour vous permettre d'accéder aux câbles d'alimentation (ceux-ci étant le seul moyen de mettre le système hors tension).
-


WARNUNG: Deutsch




Benutzer können am Netzgerät dieses Produkts keine Reparaturen vornehmen. Das Produkt enthält möglicherweise mehrere Netzgeräte. Wartungsarbeiten müssen von qualifizierten Technikern ausgeführt werden.



Versuchen Sie nicht, das mitgelieferte Netzkabel zu ändern oder zu verwenden, wenn es sich nicht genau um den erforderlichen Typ handelt.




Der Wechselstrom des Systems wird durch den Ein-/Aus-Schalter für Gleichstrom nicht ausgeschaltet. Ziehen Sie jedes Wechselstrom-Netzkabel aus der Steckdose bzw. dem Netzgerät, um den Stromanschluß des Systems zu unterbrechen.




SICHERHEISSCHRIITTE: Immer wenn Sie die Gehäuseabdeckung abnehmen um an das Systeminnere zu gelangen, sollten Sie folgende Schritte beachten:

1. Schalten Sie alle an Ihr System angeschlossenen Peripheriegeräte aus.
2. Schalten Sie das System mit dem Hauptschalter aus.
3. Ziehen Sie den Stromanschlußstecker Ihres Systems aus der Steckdose.
4. Auf der Rückseite des Systems beschrifteten und ziehen Sie alle Anschlußkabel von den I/O Anschlüssen oder Ports ab.
5. Tragen Sie ein geerdetes Antistatik Gelenkband, um elektrostatische Ladungen (ESD) über blanke Metallstellen bei der Handhabung der Komponenten zu vermeiden.
6. Schalten Sie das System niemals ohne ordnungsgemäß montiertes Gehäuse ein.



Nachdem Sie die oben erwähnten ersten sechs SICHERHEITSSCHRITTE durchgeführt haben, können Sie die Abdeckung abnehmen, indem Sie:


1. Entfernen Sie alle Schrauben der Gehäuseabdeckung.
2. Nehmen Sie die Abdeckung ab.




Zur ordnungsgemäßen Kühlung und Lüftung muß die Gehäuseabdeckung immer wieder vor dem Einschalten installiert werden. Ein Betrieb des Systems ohne angebrachte Abdeckung kann Ihrem System oder Teile darin beschädigen. Um die Abdeckung wieder anzubringen:

1. Vergewissern Sie sich, daß Sie keine Werkzeuge oder Teile im Innern des Systems zurückgelassen haben.
2. Überprüfen Sie alle Kabel, Zusatzkarten und andere Komponenten auf ordnungsgemäßen Sitz und Installation.
3. Bringen Sie die Abdeckungen wieder am Gehäuse an, indem Sie die zuvor gelösten Schrauben wieder anbringen. Ziehen Sie diese gut an.
4. Schließen Sie alle externen Kabel und den AC Stromanschlußstecker Ihres Systems wieder an.


Fortsetzung

WARNUNG: Deutsch (Fortsetzung)

Der Mikroprozessor und der Kühler sind möglicherweise erhitzt, wenn das System in Betrieb ist. Außerdem können einige Platinen und Gehäuseteile scharfe Spitzen und Kanten aufweisen. Arbeiten an Platinen und Gehäuse sollten vorsichtig ausgeführt werden. Sie sollten Schutzhandschuhe tragen.




Bei falschem Einsetzen einer neuen Batterie besteht Explosionsgefahr. Die Batterie darf nur durch denselben oder einen entsprechenden, vom Hersteller empfohlenen Batterietyp ersetzt werden. Entsorgen Sie verbrauchte Batterien den Anweisungen des Herstellers entsprechend.




Das System wurde für den Betrieb in einer normalen Büroumgebung entwickelt. Der Standort sollte:

- sauber und staubfrei sein (Hausstaub ausgenommen);
- gut gelüftet und keinen Heizquellen ausgesetzt sein (einschließlich direkter Sonneneinstrahlung);
- keinen Erschütterungen ausgesetzt sein;
- keine starken, von elektrischen Geräten erzeugten elektromagnetischen Felder aufweisen;
- in Regionen, in denen elektrische Stürme auftreten, mit einem Überspannungsschutzgerät verbunden sein; während eines elektrischen Sturms sollte keine Verbindung der Telekommunikationsleitungen mit dem Modem bestehen;
- mit einer geerdeten Wechselstromsteckdose ausgerüstet sein;
- über ausreichend Platz verfügen, um Zugang zu den Netzkabeln zu gewährleisten, da der Stromanschluß des Produkts hauptsächlich über die Kabel unterbrochen wird.


AVVERTENZA: Italiano




Rivolgersi ad un tecnico specializzato per la riparazione dei componenti dell'alimentazione di questo prodotto. È possibile che il prodotto disponga di più fonti di alimentazione.



Non modificare o utilizzare il cavo di alimentazione in c.a. fornito dal produttore, se non corrisponde esattamente al tipo richiesto.




L'interruttore attivato/disattivato nel pannello anteriore non interrompe l'alimentazione in c.a. del sistema. Per interromperla, è necessario scollegare tutti i cavi di alimentazione in c.a. dalle prese a muro o dall'alimentazione di corrente.




PASSI DI SICUREZZA: Qualora si rimuovano le coperture del telaio per accedere all'interno del sistema, seguire i seguenti passi:

1. Spegnerne tutti i dispositivi periferici collegati al sistema.
2. Spegnerne il sistema, usando il pulsante spento/acceso dell'interruttore del sistema.
3. Togliere tutte le spine dei cavi del sistema dalle prese elettriche.
4. Identificare e sconnettere tutti i cavi attaccati ai collegamenti I/O od alle prese installate sul retro del sistema.
5. Qualora si tocchino i componenti, proteggersi dallo scarico elettrostatico (SES), portando un cinghia anti-statica da polso che è attaccata alla presa a terra del telaio del sistema – qualsiasi superficie non dipinta – .
6. Non far operare il sistema quando il telaio è senza le coperture.



Dopo aver seguito i sei passi di SICUREZZA sopracitati, togliere le coperture del telaio del sistema come segue:


1. Togliere e mettere in un posto sicuro tutte le viti delle coperture.
2. Togliere le coperture.




Per il giusto flusso dell'aria e raffreddamento del sistema, rimettere sempre le coperture del telaio prima di riaccendere il sistema. Operare il sistema senza le coperture al loro proprio posto potrebbe danneggiare i componenti del sistema. Per rimettere le coperture del telaio:

1. Controllare prima che non si siano lasciati degli attrezzi o dei componenti dentro il sistema.
2. Controllare che i cavi, dei supporti aggiuntivi ed altri componenti siano stati installati appropriatamente.
3. Attaccare le coperture al telaio con le viti tolte in precedenza e avvitarle strettamente.
4. Ricollegare tutti i cavi esterni e le prolunghe AC del sistema.


continua

AVVERTENZA: Italiano (continua)

Se il sistema è stato a lungo in funzione, il microprocessore e il dissipatore di calore potrebbero essere surriscaldati. Fare attenzione alla presenza di piedini appuntiti e parti taglienti sulle schede e sul telaio. È consigliabile l'uso di guanti di protezione.




Esiste il pericolo di un'esplosione se la pila non viene sostituita in modo corretto. Utilizzare solo pile uguali o di tipo equivalente a quelle consigliate dal produttore. Per disfarsi delle pile usate, seguire le istruzioni del produttore.




Il sistema è progettato per funzionare in un ambiente di lavoro tipo. Scegliere una postazione che sia:

- Pulita e libera da particelle in sospensione (a parte la normale polvere presente nell'ambiente).
- Ben ventilata e lontana da fonti di calore, compresa la luce solare diretta.
- Al riparo da urti e lontana da fonti di vibrazione.
- Isolata dai forti campi magnetici prodotti da dispositivi elettrici.
- In aree soggette a temporali, è consigliabile collegare il sistema ad un limitatore di corrente. In caso di temporali, scollegare le linee di comunicazione dal modem.
- Dotata di una presa a muro correttamente installata.
- Dotata di spazio sufficiente ad accedere ai cavi di alimentazione, i quali rappresentano il mezzo principale di scollegamento del sistema.


ADVERTENCIAS: Español




El usuario debe abstenerse de manipular los componentes de la fuente de alimentación de este producto, cuya reparación debe dejarse exclusivamente en manos de personal técnico especializado. Puede que este producto disponga de más de una fuente de alimentación.



No intente modificar ni usar el cable de alimentación de corriente alterna, si no corresponde exactamente con el tipo requerido.




Nótese que el interruptor activado/desactivado en el panel frontal no desconecta la corriente alterna del sistema. Para desconectarla, deberá desenchufar todos los cables de corriente alterna de la pared o desconectar la fuente de alimentación.




INSTRUCCIONES DE SEGURIDAD: Cuando extraiga la tapa del chasis para acceder al interior del sistema, siga las siguientes instrucciones:

1. Apague todos los dispositivos periféricos conectados al sistema.
2. Apague el sistema presionando el interruptor encendido/apagado.
3. Desconecte todos los cables de alimentación CA del sistema o de las tomas de corriente alterna.
4. Identifique y desconecte todos los cables enchufados a los conectores E/S o a los puertos situados en la parte posterior del sistema.
5. Cuando manipule los componentes, es importante protegerse contra la descarga electrostática (ESD). Puede hacerlo si utiliza una muñequera antiestática sujeta a la toma de tierra del chasis — o a cualquier tipo de superficie de metal sin pintar.
6. No ponga en marcha el sistema si se han extraído las tapas del chasis.



Después de completar las seis instrucciones de SEGURIDAD mencionadas, ya puede extraer las tapas del sistema. Para ello:


1. Extraiga y guarde todos los tornillos de las tapas.
2. Extraiga las tapas.




Para obtener un enfriamiento y un flujo de aire adecuados, reinstale siempre las tapas del chasis antes de poner en marcha el sistema. Si pone en funcionamiento el sistema sin las tapas bien colocadas puede dañar los componentes del sistema. Para instalar las tapas:

1. Asegúrese primero de no haber dejado herramientas o componentes sueltos dentro del sistema.
2. Compruebe que los cables, las placas adicionales y otros componentes se hayan instalado correctamente.
3. Incorpore las tapas al chasis mediante los tornillos extraídos anteriormente, tensándolos firmemente.
4. Conecte todos los cables externos y los cables de alimentación CA al sistema.


continúa

ADVERTENCIAS: Español (continúa)

Si el sistema ha estado en funcionamiento, el microprocesador y el disipador de calor pueden estar aún calientes. También conviene tener en cuenta que en el chasis o en el tablero puede haber piezas cortantes o punzantes. Por ello, se recomienda precaución y el uso de guantes protectores.



Existe peligro de explosión si la pila no se cambia de forma adecuada. Utilice solamente pilas iguales o del mismo tipo que las recomendadas por el fabricante del equipo. Para deshacerse de las pilas usadas, siga igualmente las instrucciones del fabricante.



El sistema está diseñado para funcionar en un entorno de trabajo normal. Escoja un lugar:

- Limpio y libre de partículas en suspensión (salvo el polvo normal).
- Bien ventilado y alejado de fuentes de calor, incluida la luz solar directa.
- Alejado de fuentes de vibración.
- Aislado de campos electromagnéticos fuertes producidos por dispositivos eléctricos.
- En regiones con frecuentes tormentas eléctricas, se recomienda conectar su sistema a un eliminador de sobrevoltage y desconectar el módem de las líneas de telecomunicación durante las tormentas.
- Provisto de una toma de tierra correctamente instalada.
- Provisto de espacio suficiente como para acceder a los cables de alimentación, ya que éstos hacen de medio principal de desconexión del sistema.

Index

A

- AC filter and cable
 - reinstalling, 159
 - removing, 158
- Acoustic noise, 30
- Add-in boards, 146
 - current limitations, 146
 - installing, 146
 - ISA, 57, 146, 148
 - installing, 148
 - PCI, 57, 146, 148
 - removing, 149
- Agency certification, 285, 286

B

- Back panel, external connectors, 32
- Backplanes, peripheral bay, 183
- Battery
 - handling cautions, 258
 - replacing, 259
- BIOS
 - Setup utility, description, 43
 - Setup utility, running, 43
 - special recovery mode, 197
 - updating, 195
- Board management controller, 191
- Board set
 - CPU baseboard, 17
 - I/O baseboard, 17
 - I/O riser card, 17
 - memory module, 17
 - voltages and currents, 253
- brown out feature, 249

C

- Cautions, 132, 137, 143, 146, 156
- CD-ROM drive
 - activity LED, 24
 - headphone jack, 24
 - mounting screws, 170
 - open/close button, 24
 - removing, 168

- replacing, 170
- slide rails, 170
- volume control, 24
- Certifications, 285, 286
- CFG files, 58
- Connecting peripheral devices, 31
- Connectors on CPU baseboard
 - I/O power section, 204, 229
- Connectors on I/O riser card
 - keyboard and mouse ports, 213
 - parallel port, 214
 - serial ports, 213
 - video port, 215
- Connectors on memory module
 - signal section, 244
- Connectors on peripheral bay blindmate board
 - blind mate, 280
 - diskette drive, 281
 - IDE, 282
 - power, 281
 - Wide SCSI, 283
- Connectors on PHP I/O baseboard
 - 32-bit PCI, 205
 - 64-bit PCI, 206
 - diskette drive port, 208
 - F16 bus, 201
 - front panel, 211
 - I²C, 211
 - IDE port, 210
 - ISA, 207
 - legacy, 212
 - USB port, 212
 - wide/fast 16-bit SCSI port, 209
- connectors, peripheral bay blindmate, 279
- Controllers
 - board management, 191
 - diskette drive, 20
 - front panel, 191
 - hot-swap, 191
 - IDE, 190
 - keyboard/mouse, 20
 - Symbios 53C896 LVDS, 185
 - video, 20, 187

- Controls and indicators
 - CD-ROM drive, 24
 - diskette drive, 24
 - front panel, 24
 - status LEDs, hot-docking bays, 24

Cooling and airflow, 119

Cooling system, 18

Covers

- front bezel, removing, 121
- PCI hot-plug, removing, 123
- peripheral bay, removing, 120
- removable, 119
- top
 - reinstalling, 123
 - removing, 121

CPU baseboard, 19

- component layout, 222
- DC to DC converters, 218
- features, 217
- front side bus, 219
 - terminator module, 219
- I/O connector
 - power section, 204, 229
- I/O interface, 219
- jumpers, 220
 - changing a setting, 221
- processors, 217
- reinstalling, 144
- removing, 144
- EEPROM, 218
- symmetric multiprocessor, 217

CPU tray

- reinstalling, 140
- removing, 140

Current, usage, 253

D

DC to DC converters, 217, 218

- installing, 138
- removing, 138

DIMMs

- installing, 240
- removing, 242

Diskette drive

- controller, 20
- ejector button, 24
- removing, 166
- replacing, 166

Drive bay, 3.5-inch, 18

Drive fault light, slow blinking, 106

Drive indicators, SCSI

- drive active, 106
- drive failure, 106
- drive present, 106

Drivers

- SCSI, installing, 37
- video, installing, 37

Drives

- CD-ROM, 168
- diskette, 165

E

EDO DRAM array, 234

Electromagnetic compatibility, *See* EMC

EMC

- compatibility, 285
- notice of test and compliance, international, 286

Emergency Management Port

- FRU viewer, 88
- main console window, 82
- phonebook, 87
- requirements, 80
- server control operations, 84

EMI, 18

Environmental specifications, 30

Equipment log, 97, 101, 109, 119, 127, 165, 257, 287

Error messages

- beep codes, 270, 271, 272, 273, 274, 275, 276
- port 80h codes, 270, 271, 272, 273, 274, 275, 276
- POST error codes, 273

ESD, 30, 146

- add-in boards, 146

Expansion slots, 186

- 16-bit ISA, 20
- 32-bit PCI, 20
- 64-bit PCI, 20

F

fan

- failure LED, 98
- hot swapping, 98
- redundant, 98
- removing, 97
- replacing, 100

fan array housing

- reinstalling, 128
- removing, 128

Fans, 18, 98

- voltage settings, 278

FCC, Class A, 286

Features, server, 18, 19, 20

Front bezel

- reinstalling, 121
- removing, 121

Front panel

- board, 19
 - reinstalling, 143
 - removing, 142
- controller, 191
- switches, 19, 34

Front side bus, 219

- terminator module, 20, 219
 - reinstalling, 135
 - removing, 135

FRUSDR load utility, when to run, 89

H

Hard disk drive

- hot swapping SCSI drive, 106
- installing in hot-docking bay, 104
- SCSI, 102

hard drives, SCSI, hot-docking, 24

Hot-docking bay, status indicators, 106

Hot-swap controller, 191

Hot-swapping, hard disk drives, 18

I

I/O baseboard, 20

- reinstalling, 156
- removing, 156

I/O riser card, 20, 192

- connectors, 20

keyboard and mouse ports, 213

parallel port, 214

serial ports, 213

video port, 215

reinstalling, 150

removing, 150

I/O Tray

reinstalling, 152

removing, 152

ICMB

board

reinstalling, 154

removing, 154

bus, 19, 31, 32

IDE

controller, 190

interface, 20

Indicators

cooling fault LED (yellow), 24

drive fault LED (yellow), 24

front panel LCD, 24

power fault LED (yellow), 24

SCSI drive in recovery mode, 106

SCSI drive status descriptions, 106

Interconnect backplane, 20

ISA, 17

add-in board, installing, 148

bus master slot, 146

expansion slot, 186

J

Jumpers

boot option, 197

CMOS, 194

CPU baseboard, 220

changing a setting, 221

flash memory, 195

password, 195

K

Keyboard, connecting, 31

Keyboard/mouse controller, 20

L

LCD module

- reinstalling, 131
- removing, 131

Lights

- CD-ROM drive, 24
- DC power, 24
- diskette drive, 24
- power supply, 266

M

Mass storage device

- CD-ROM, 168
- diskette drive, 165

Memory module, 19

- DIMMs, 233
 - installing, 240
 - removing, 242
- interleaving, 234
- reinstalling, 133
- removing, 132

Memory module connector

- signal section, 244

Messages

- beep codes, 270, 271, 272, 273, 274, 275, 276
- port 80h codes, 270, 271, 272, 273, 274, 275, 276
- POST error codes, 273

midplane

- reinstalling, 158
- removing, 158

Monitor, connecting, 31

O

Operating systems, 17

OVL files, 57

P

Password

- administrative, 26
- protection, 26
- user, 26

PCI, 17

- bus master slots, 146
- video controller, 187

PCI bus hot-plug covers

- reinstalling, 124

peripheral bay backplane, 183

peripheral bay blindmate board

- connectors
 - blind mate, 280
 - diskette drive, 281
 - IDE, 282
 - power, 281
 - Wide SCSI, 283

Peripheral Bay Cover

- reinstalling, 120

Peripheral devices

- connecting, 31
- floppy disk drive, 43
- keyboard, connecting, 31
- monitor, connecting, 31

peripheral bay

- removing, 159

peripheral bay backplane

- reinstalling, 161
- removing, 159, 160

peripheral bay blind mate board

- reinstalling, 162
- removing, 162

PHP I/O baseboard

- component layout, 200
- connectors
 - 32-bit PCI, 205
 - 64-bit PCI, 206
 - diskette drive port, 208
 - F16 bus, 201
 - front panel, 211
 - I²C, 211
 - IDE port, 210
 - ISA, 207
 - legacy, 212
 - USB port, 212
 - wide/fast 16-bit SCSI port, 209

expansion slots, 185

I/O riser card, 192

IDE controller, 190

ISA expansion slot, 186

jumpers, 193

PHP I/O baseboard (continued)
 boot option, 197
 flash memory, 195
 PCI expansion slots, 186
 PCI video controller, 187
 server management, 190
 Physical specifications, 30
 POST
 description, 35, 41
 running, 35, 41
 Power cord, obtaining, 33
 Power requirements, 30
 Power supply, 18
 configuration constraints, 110
 failure LED, 110
 fan, 18
 handles, 29
 hot swapping, 110
 input voltages, 252
 output voltage, 252
 redundant, 110
 removing, 109
 replacing, 112
 safety interlock mechanism, 110
 warning, 110
 Power system, 18, 251
 Power usage
 calculating, 254
 worksheet, 254, 255
 power, brown out feature, 249
 Power-on self-test, 35, 41
 Processor, 19
 installing, 137
 removing, 137

R

Real-time clock, 258
 configuration settings, 43
 lithium battery, 258
 Recovery mode indicator, SCSI drive, 106
 Regulatory specifications
 declaration of manufacturer, 285
 electromagnetic compatibility, 285
 international notices, 286
 USA notice, 286
 safety compliance, 285
 RFI, 18

S

Safety, compliance, 285
 SCI files, 58
 SCSI
 hard disk drive, 102
 hot-swapping, 106
 indicator, drive in recovery mode, 106
 installing in hot-docking bay, 104
 status indicator LED locations, 107
 status indicators, 106
 hot-docking backplane, 20
 hot-docking bays, 101
 installing drivers, 37
 peripheral bay
 hard disk drives, 183
 peripheral bay backplane
 fault indicators, 183
 ID addresses, 184
 indicator LEDs, 183
 power control, 183
 temperature sensor, 183
 singled-ended devices, 102
 Security, 26
 boot sequence control, 26
 boot without keyboard, 27
 diskette write protect, 27
 emergency management port, 27
 locked power and reset switches, 27
 password protection, 26
 secure boot mode, 26
 setup utility, 26
 system setup utility (SSU), 26
 video blanking, 27
 Server
 after unpacking, 31
 back panel, 32
 board set, 17
 boot from CD, 36
 chassis, 18
 cooling and airflow, 119
 copy software to diskettes, 37
 dimensions and weight, 30
 features, 18, 19, 20
 install SCSI drivers, 37
 install video drivers, 37
 major components, 21
 management, 19, 190

Server (continued)
 on-site installation, 29
 won't boot from CD, 38

Setup utility, running, 43

Specifications
 environmental, 30
 physical, 30

SSU, *See* system setup utility

Status indicators
 drive activity LED (green), 24
 drive fault LED (yellow), 24
 drive power LED (green), 24
 SCSI drives, 106

Supplies, 97, 101, 109, 119, 127, 165, 257

Switches
 DC power, 261, 262
 NMI, 24
 power, 24
 reset, 24, 261
 server power, 110
 system power, 33, 41, 121

Symmetric multiprocessor, 217

System setup utility, 31
 CFG files, 58
 customizing, 60
 defining an ISA card, 63
 exiting, 74
 launching a task, 60
 location, 57
 OVL files, 57
 removing an ISA card, 64
 running, 59
 locally, 58
 remotely, 59
 SCI files, 58
 when to run, 57

T

Tools, 97, 101, 109, 119, 127, 165, 257

Troubleshooting
 additional procedures, 264
 application software, 269
 beep codes, 267, 270, 271, 272, 273, 274, 275, 276
 checklist, 262, 263
 cooling fans, 266
 DC power switch, 262

floppy drive light, 268
hard drive light, 268
initial system startup, 262
new software, 263
no characters on screen, 267
operating system prompt, 265
power distribution backplane, 269
screen characters incorrect, 267
server lights, 265
server problems, 263
 checklist, 263
specific problems
 corrective actions, 265
 power light, 266
video display, 267

U

USB ports, 20, 185

Utilities
 BIOS setup, 43
 FRUSDR load utility, 89
 SCSISelect, 41

V

Video
 controller, 20, 187
 drivers, installing, 37
 standard VGA modes, 187

W

Warnings
 translations
 English, 290
 French, 292
 German, 294
 Italian, 296
 Spanish, 298
 vacant power supply bay, 110

Weight of server, 29

X

XICMB, bus, 191, 214