




DG945GCLF

BIOS Configuration	
1-2	Normal
2-3	Configuration
No Jumper	Recovery

Audio	
Port1L	1 2 Ground
Port1R	3 4 Presence#
Port2R	5 6 Sense1_Ret
Sense_Send	7 Key (no pin)
Port2L	9 10 Sense2_Ret


USB	
+5 V	1 2 +5 V
D-	3 4 D-
D+	5 6 D+
Ground	7 8 Ground
Key (no pin)	10 NC

Front Panel	
Key (no pin)	9 NC
On/Off	8 7 Reset
Power LED +	4 3 HD LED
	2 1 +



CAUTION

Risk of explosion if the battery is replaced with an incorrect type. Batteries should be recycled where possible. Disposal of used batteries must be in accordance with local environmental regulations.



E35047-001

Attach this label near the back panel connectors.

Attach this label to the inside surface of the chassis.

*Other names and brands may be claimed as the property of others. Copyright © 2008, Intel Corporation. All rights reserved.