

Instructions for finding alternate assembly number (AA#), BIOS version, and Intel® ME firmware version

During boot, enter the BIOS setup by pressing F2.

The board's current BIOS version is shown at the top of the Main menu. Then click System Identification Information.

	System Setup		
Main Configuration Performance	Security Power Boot Exit		
BIOS Version	BLH6710H.86A.0076.2010.1115.1955		
Processor Type	Intel(R) Core(TM) i3-2120 CPU @ 3.30GHz		
Active Processor Cores	<all></all>		
Intel® Hyper-Threading Technology	<enable></enable>		
Host Clock Frequency	100 MHz		
Processor Turbo Speed	3.30 GHz		
Memory Speed	1333 MHz		
Active Processor Cores Intel® Hyper-Threading Technology Host Clock Frequency Processor Turbo Speed Memory Speed L2 Cache RAM L3 Cache RAM Total Memory DIMM3 (Memory Channel A Slot 0) DIMM1 (Memory Channel A Slot 1) DIMM4 (Memory Channel B Slot 0) DIMM2 (Memory Channel B Slot 1) System Identification Information	2 x 256 KB 3 MB 1 GB Not Installed 1 GB Not Installed Not Installed		
System Date System Time	<wed 01="" 2012="" 25=""> <02:44:09></wed>		

The board's AA# and Intel® ME firmware version are shown on the System Identification Information screen.

	System Setup			
Main				
Queten Tlent:Ciestien Tufennetien				
System Identification Information				
System Information Manufacturer				
Product Name				
Version				
Serial Number				
	7E9D8539-2668-E011-A698-00E04CA04AED			
Desktop Board Information				
Manufacturer	Intel Corporation			
Product Name	DH67BI			
Version	AAG10189-205			
Serial Number	BTBL1160030Z			
Chassis Information				
Manufacturer				
Version				
Serial Number				
Asset Tag				
R	00000607			
Processor Signature	000206A7			
M· 1 II 1 (D · · ·	Family 6h Model 2Ah Stepping 7h			
Microcode Update Revision	00000006			
Onboard LAN MAC Address	E0-69-95-72-0F-1D			
Intel® Management Engine Information				
Intel® Management Engine Firmware 7.0.1.1141				

Table 1

Board	3rd Gen-Ready AA#s	3rd Gen-Capable AA#s	3rd Gen-Transition BIOS version	3rd Gen-Ready BIOS version
DZ68DB	AAG27985-105 or later	All	DBZ6810H.86A.0032	DBZ6810H.86A.0040 or later
DZ68BC	AAG30742-403 or later	All	BCZ6810H.86A.0028	BCZ6810H.86A.0035 or later
DZ68ZV	AAG41861-302 or later	AAG41861-301	BGP6810J.86A.2111	BGP6810J.86A.2161 or later
DP67BG	AAG10491- 401 or later	AAG10491-400	BGP6810J.86A.2111	BGP6810J.86A.2161 or later
DP67DE	AAG10217-304 or later	AAG10217-301	BAP6710H.86A.0072	BAP6710H.86A.0077 or later
DP67BA	AAG10219-304 or later	AAG10219-301	BAP6710H.86A.0072	BAP6710H.86A.0077 or later
DH67GD	AAG10206-210 or later	AAG10206-206	BLH6710H.86A.0132	BLH6710H.86A.0151 or later
DH67CL	AAG10212-210 or later	AAG10212-206	BLH6710H.86A.0132	BLH6710H.86A.0151 or later
DH67CF	AAG10215-207 or later	AAG10215-204	BLH6710H.86A.0132	BLH6710H.86A.0151 or later
DH67BL	AAG10189-211 or later	AAG10189-206	BLH6710H.86A.0132	BLH6710H.86A.0151 or later
DH67BLR	AAG44434-201 or later	All	BLH6710H.86A.0132	BLH6710H.86A.0151 or later
DH61ZE	AAG43004-201 or later	All	BEH6110H.86A.0035	BEH6110H.86A.0041 or later
DH61WW	AAG23116-206 or later	AAG23116-204	BEH6110H.86A.0035	BEH6110H.86A.0041 or later
LADH61WW	AAG39552-206 or later	AAG39552-204	BEH6110H.86A.0035	BEH6110H.86A.0041 or later
DH61SA	AAG38870-204 or later	All	BEH6110H.86A.0035	BEH6110H.86A.0041 or later
LADH61SA	AAG38871-204 or later	All	BEH6110H.86A.0035	BEH6110H.86A.0041 or later
LADH61SAR	AAG44435-202 or later	All	BEH6110H.86A.0035	BEH6110H.86A.0041 or later
DH61HO	All	All	N/A	All
DH61DL	AAG14066-205 or later	All	BEH6110H.86A.0035	BEH6110H.86A.0041 or later
DH61CR	AAG14064-207 or later	AAG14064-204	BEH6110H.86A.0035	BEH6110H.86A.0041 or later
DH61BE	AAG14062-209 or later	AAG14062-206	BEH6110H.86A.0035	BEH6110H.86A.0041 or later
DH61AG	AAG23736-503 or later	All	AGH6110H.86A.0037	AGH6110H.86A.0039 or later

The following Intel® Desktop Boards will not include support for 3rd Generation Intel® Core™ processors:

- DH61KVCH
- DH61SKCH
- DB65AL
- DH67VR
- DQ67SW
- DQ67OW
- DQ67EP